

ROCmSMI

Generated by Doxygen 1.8.17

1 ROCm System Management Interface (ROCm SMI) Library	1
1.1 DISCLAIMER	1
1.2 Building ROCm SMI	1
1.3 Usage Basics	3
1.3.1 Device Indices	3
1.4 Hello ROCm SMI	3
2 Deprecated List	5
3 Module Index	7
3.1 Modules	7
4 Data Structure Index	9
4.1 Data Structures	9
5 File Index	11
5.1 File List	11
6 Module Documentation	13
6.1 Initialization and Shutdown	13
6.1.1 Detailed Description	13
6.1.2 Function Documentation	13
6.1.2.1 rsmi_init()	13
6.1.2.2 rsmi_shut_down()	14
6.2 Identifier Queries	15
6.2.1 Detailed Description	15
6.2.2 Function Documentation	15
6.2.2.1 rsmi_num_monitor_devices()	15
6.2.2.2 rsmi_dev_id_get()	16
6.2.2.3 rsmi_dev_sku_get()	16
6.2.2.4 rsmi_dev_vendor_id_get()	17
6.2.2.5 rsmi_dev_name_get()	17
6.2.2.6 rsmi_dev_brand_get()	18
6.2.2.7 rsmi_dev_vendor_name_get()	19
6.2.2.8 rsmi_dev_vram_vendor_get()	19
6.2.2.9 rsmi_dev_serial_number_get()	20
6.2.2.10 rsmi_dev_subsystem_id_get()	21
6.2.2.11 rsmi_dev_subsystem_name_get()	21
6.2.2.12 rsmi_dev_drm_render_minor_get()	22
6.2.2.13 rsmi_dev_subsystem_vendor_id_get()	22
6.2.2.14 rsmi_dev_unique_id_get()	23
6.3 PCIe Queries	24
6.3.1 Detailed Description	24
6.3.2 Function Documentation	24

6.3.2.1	<code>rsmi_dev_pci_bandwidth_get()</code>	24
6.3.2.2	<code>rsmi_dev_pci_id_get()</code>	25
6.3.2.3	<code>rsmi_topo_numa_affinity_get()</code>	25
6.3.2.4	<code>rsmi_dev_pci_throughput_get()</code>	27
6.3.2.5	<code>rsmi_dev_pci_replay_counter_get()</code>	28
6.4	PCIe Control	29
6.4.1	Detailed Description	29
6.4.2	Function Documentation	29
6.4.2.1	<code>rsmi_dev_pci_bandwidth_set()</code>	29
6.5	Power Queries	30
6.5.1	Detailed Description	30
6.5.2	Function Documentation	30
6.5.2.1	<code>rsmi_dev_power_ave_get()</code>	30
6.5.2.2	<code>rsmi_dev_energy_count_get()</code>	31
6.5.2.3	<code>rsmi_dev_power_cap_get()</code>	31
6.5.2.4	<code>rsmi_dev_power_cap_default_get()</code>	32
6.5.2.5	<code>rsmi_dev_power_cap_range_get()</code>	33
6.6	Power Control	34
6.6.1	Detailed Description	34
6.6.2	Function Documentation	34
6.6.2.1	<code>rsmi_dev_power_cap_set()</code>	34
6.6.2.2	<code>rsmi_dev_power_profile_set()</code>	35
6.7	Memory Queries	36
6.7.1	Detailed Description	36
6.7.2	Function Documentation	36
6.7.2.1	<code>rsmi_dev_memory_total_get()</code>	36
6.7.2.2	<code>rsmi_dev_memory_usage_get()</code>	37
6.7.2.3	<code>rsmi_dev_memory_busy_percent_get()</code>	37
6.7.2.4	<code>rsmi_dev_memory_reserved_pages_get()</code>	38
6.8	Physical State Queries	40
6.8.1	Detailed Description	40
6.8.2	Function Documentation	40
6.8.2.1	<code>rsmi_dev_fan_rpms_get()</code>	40
6.8.2.2	<code>rsmi_dev_fan_speed_get()</code>	41
6.8.2.3	<code>rsmi_dev_fan_speed_max_get()</code>	41
6.8.2.4	<code>rsmi_dev_temp_metric_get()</code>	42
6.8.2.5	<code>rsmi_dev_volt_metric_get()</code>	43
6.9	Physical State Control	44
6.9.1	Detailed Description	44
6.9.2	Function Documentation	44
6.9.2.1	<code>rsmi_dev_fan_reset()</code>	44
6.9.2.2	<code>rsmi_dev_fan_speed_set()</code>	44

6.10 Clock, Power and Performance Queries	46
6.10.1 Detailed Description	46
6.10.2 Function Documentation	47
6.10.2.1 rsmi_dev_busy_percent_get()	47
6.10.2.2 rsmi_utilization_count_get()	47
6.10.2.3 rsmi_dev_perf_level_get()	48
6.10.2.4 rsmi_perf_determinism_mode_set()	49
6.10.2.5 rsmi_dev_overdrive_level_get()	49
6.10.2.6 rsmi_dev_mem_overdrive_level_get()	50
6.10.2.7 rsmi_dev_gpu_clk_freq_get()	50
6.10.2.8 rsmi_dev_gpu_reset()	51
6.10.2.9 rsmi_dev_od_volt_info_get()	51
6.10.2.10 rsmi_dev_gpu_metrics_info_get()	52
6.10.2.11 rsmi_dev_clk_range_set()	53
6.10.2.12 rsmi_dev_od_clk_info_set()	53
6.10.2.13 rsmi_dev_od_volt_info_set()	54
6.10.2.14 rsmi_dev_od_volt_curve_regions_get()	54
6.10.2.15 rsmi_dev_power_profile_presets_get()	55
6.11 Clock, Power and Performance Control	57
6.11.1 Detailed Description	57
6.11.2 Function Documentation	57
6.11.2.1 rsmi_dev_perf_level_set()	57
6.11.2.2 rsmi_dev_perf_level_set_v1()	58
6.11.2.3 rsmi_dev_overdrive_level_set()	58
6.11.2.4 rsmi_dev_overdrive_level_set_v1()	59
6.11.2.5 rsmi_dev_gpu_clk_freq_set()	60
6.12 Version Queries	62
6.12.1 Detailed Description	62
6.12.2 Function Documentation	62
6.12.2.1 rsmi_version_get()	62
6.12.2.2 rsmi_version_str_get()	62
6.12.2.3 rsmi_dev_vbios_version_get()	63
6.12.2.4 rsmi_dev_firmware_version_get()	64
6.13 Error Queries	65
6.13.1 Detailed Description	65
6.13.2 Function Documentation	65
6.13.2.1 rsmi_dev_ecc_count_get()	65
6.13.2.2 rsmi_dev_ecc_enabled_get()	66
6.13.2.3 rsmi_dev_ecc_status_get()	66
6.13.2.4 rsmi_status_string()	68
6.14 Performance Counter Functions	69
6.14.1 Detailed Description	69

6.14.2 Important Notes about Counter Values	69
6.14.3 Function Documentation	70
6.14.3.1 rsmi_dev_counter_group_supported()	70
6.14.3.2 rsmi_dev_counter_create()	71
6.14.3.3 rsmi_dev_counter_destroy()	71
6.14.3.4 rsmi_counter_control()	72
6.14.3.5 rsmi_counter_read()	72
6.14.3.6 rsmi_counter_available_counters_get()	73
6.15 System Information Functions	74
6.15.1 Detailed Description	74
6.15.2 Function Documentation	74
6.15.2.1 rsmi_compute_process_info_get()	74
6.15.2.2 rsmi_compute_process_info_by_pid_get()	75
6.15.2.3 rsmi_compute_process_gpus_get()	75
6.16 XGMI Functions	77
6.16.1 Detailed Description	77
6.16.2 Function Documentation	77
6.16.2.1 rsmi_dev_xgmi_error_status()	77
6.16.2.2 rsmi_dev_xgmi_error_reset()	78
6.16.2.3 rsmi_dev_xgmi_hive_id_get()	78
6.17 Hardware Topology Functions	79
6.17.1 Detailed Description	79
6.17.2 Function Documentation	79
6.17.2.1 rsmi_topo_get_numa_node_number()	79
6.17.2.2 rsmi_topo_get_link_weight()	80
6.17.2.3 rsmi_minmax_bandwidth_get()	80
6.17.2.4 rsmi_topo_get_link_type()	81
6.17.2.5 rsmi_is_P2P_accessible()	81
6.18 Compute Partition Functions	83
6.18.1 Detailed Description	83
6.18.2 Function Documentation	83
6.18.2.1 rsmi_dev_compute_partition_get()	83
6.18.2.2 rsmi_dev_compute_partition_set()	84
6.18.2.3 rsmi_dev_compute_partition_reset()	84
6.19 NPS Mode Functions	86
6.19.1 Detailed Description	86
6.19.2 Function Documentation	86
6.19.2.1 rsmi_dev_nps_mode_get()	86
6.19.2.2 rsmi_dev_nps_mode_set()	87
6.19.2.3 rsmi_dev_nps_mode_reset()	87
6.20 Supported Functions	89
6.20.1 Detailed Description	89

6.20.2 Function Documentation	90
6.20.2.1 rsmi_dev_supported_func_iterator_open()	90
6.20.2.2 rsmi_dev_supported_variant_iterator_open()	91
6.20.2.3 rsmi_func_iter_next()	91
6.20.2.4 rsmi_dev_supported_func_iterator_close()	92
6.20.2.5 rsmi_func_iter_value_get()	92
6.21 Event Notification Functions	94
6.21.1 Detailed Description	94
6.21.2 Function Documentation	94
6.21.2.1 rsmi_event_notification_init()	94
6.21.2.2 rsmi_event_notification_mask_set()	95
6.21.2.3 rsmi_event_notification_get()	95
6.21.2.4 rsmi_event_notification_stop()	96
7 Data Structure Documentation	97
7.1 id Union Reference	97
7.1.1 Detailed Description	97
7.1.2 Field Documentation	98
7.1.2.1 memory_type	98
7.2 metrics_table_header_t Struct Reference	98
7.2.1 Detailed Description	98
7.3 rsmi_counter_value_t Struct Reference	98
7.3.1 Detailed Description	99
7.3.2 Field Documentation	99
7.3.2.1 time_enabled	99
7.3.2.2 time_running	99
7.4 rsmi_error_count_t Struct Reference	99
7.4.1 Detailed Description	99
7.5 rsmi_evt_notification_data_t Struct Reference	100
7.5.1 Detailed Description	100
7.6 rsmi_freq_volt_region_t Struct Reference	100
7.6.1 Detailed Description	100
7.7 rsmi_frequencies_t Struct Reference	101
7.7.1 Detailed Description	101
7.7.2 Field Documentation	101
7.7.2.1 num_supported	101
7.7.2.2 current	101
7.7.2.3 frequency	101
7.8 rsmi_gpu_metrics_t Struct Reference	102
7.9 rsmi_od_vddc_point_t Struct Reference	102
7.9.1 Detailed Description	102
7.10 rsmi_od_volt_curve_t Struct Reference	102

7.10.1 Detailed Description	102
7.10.2 Field Documentation	102
7.10.2.1 vc_points	103
7.11 rsmi_od_volt_freq_data_t Struct Reference	103
7.11.1 Detailed Description	103
7.11.2 Field Documentation	103
7.11.2.1 curr_mclk_range	103
7.12 rsmi_pcie_bandwidth_t Struct Reference	104
7.12.1 Detailed Description	104
7.12.2 Field Documentation	104
7.12.2.1 transfer_rate	104
7.12.2.2 lanes	104
7.13 rsmi_power_profile_status_t Struct Reference	104
7.13.1 Detailed Description	105
7.13.2 Field Documentation	105
7.13.2.1 available_profiles	105
7.13.2.2 current	105
7.13.2.3 num_profiles	105
7.14 rsmi_process_info_t Struct Reference	105
7.14.1 Detailed Description	106
7.15 rsmi_range_t Struct Reference	106
7.15.1 Detailed Description	106
7.16 rsmi_retired_page_record_t Struct Reference	106
7.16.1 Detailed Description	107
7.17 rsmi_utilization_counter_t Struct Reference	107
7.17.1 Detailed Description	107
7.18 rsmi_version_t Struct Reference	107
7.18.1 Detailed Description	108
8 File Documentation	109
8.1 rocm_smi.h File Reference	109
8.1.1 Detailed Description	118
8.1.2 Macro Definition Documentation	118
8.1.2.1 RSMI_MAX_FAN_SPEED	118
8.1.2.2 RSMI_EVENT_MASK_FROM_INDEX	118
8.1.2.3 RSMI_DEFAULT_VARIANT	119
8.1.3 Typedef Documentation	119
8.1.3.1 rsmi_event_handle_t	119
8.1.4 Enumeration Type Documentation	119
8.1.4.1 rsmi_status_t	119
8.1.4.2 rsmi_init_flags_t	120
8.1.4.3 rsmi_dev_perf_level_t	120

8.1.4.4 rsmi_sw_component_t	121
8.1.4.5 rsmi_event_group_t	121
8.1.4.6 rsmi_event_type_t	121
8.1.4.7 rsmi_counter_command_t	122
8.1.4.8 rsmi_evt_notification_type_t	122
8.1.4.9 rsmi_clk_type_t	123
8.1.4.10 rsmi_compute_partition_type_t	123
8.1.4.11 rsmi_nps_mode_type_t	123
8.1.4.12 rsmi_temperature_metric_t	124
8.1.4.13 rsmi_temperature_type_t	125
8.1.4.14 rsmi_voltage_metric_t	125
8.1.4.15 rsmi_voltage_type_t	125
8.1.4.16 rsmi_power_profile_preset_masks_t	126
8.1.4.17 rsmi_gpu_block_t	126
8.1.4.18 rsmi_ras_err_state_t	127
8.1.4.19 rsmi_memory_type_t	127
8.1.4.20 rsmi_freq_ind_t	127
8.1.4.21 rsmi_memory_page_status_t	128
8.1.4.22 _RSMI_IO_LINK_TYPE	128
8.1.4.23 RSMI_UTILIZATION_COUNTER_TYPE	128

Chapter 1

ROCm System Management Interface (ROCm SMI) Library

The ROCm System Management Interface Library, or ROCm SMI library, is part of the Radeon Open Compute ROCm software stack . It is a C library for Linux that provides a user space interface for applications to monitor and control GPU applications.

1.1 DISCLAIMER

The information contained herein is for informational purposes only, and is subject to change without notice. In addition, any stated support is planned and is also subject to change. While every precaution has been taken in the preparation of this document, it may contain technical inaccuracies, omissions and typographical errors, and AMD is under no obligation to update or otherwise correct this information. Advanced Micro Devices, Inc. makes no representations or warranties with respect to the accuracy or completeness of the contents of this document, and assumes no liability of any kind, including the implied warranties of noninfringement, merchantability or fitness for particular purposes, with respect to the operation or use of AMD hardware, software or other products described herein.

© 2022 Advanced Micro Devices, Inc. All Rights Reserved.

1.2 Building ROCm SMI

1.2.0.0.1 Additional Required software for building In order to build the ROCm SMI library, the following components are required. Note that the software versions listed are what was used in development. Earlier versions are not guaranteed to work:

- CMake (v3.5.0)
- g++ (5.4.0)

In order to build the latest documentation, the following are required:

- DOxygen (1.8.11)
- latex (pdfTeX 3.14159265-2.6-1.40.16)

The source code for ROCm SMI is available on [Github](#).

After the ROCm SMI library git repository has been cloned to a local Linux machine, building the library is achieved by following the typical CMake build sequence. Specifically,

```
$ mkdir -p build
```

```
$ cd build
```

```
$ cmake <location of root of ROCm SMI library CMakeLists.txt>
```

```
$ make
```

```
# Install library file and header; default location is /opt/rocm
```

```
$ make install The built library will appear in the build folder.
```

To build the rpm and deb packages follow the above steps with:

```
$ make package
```

1.2.0.0.2 Documentation The reference manual, `refman.pdf` will be in the `latex` directory upon a successful build.

1.2.0.0.3 Building the Tests In order to verify the build and capability of ROCm SMI on your system and to see an example of how ROCm SMI can be used, you may build and run the tests that are available in the repo. To build the tests, follow these steps:

```
# Set environment variables used in CMakeLists.txt file
```

```
$ ROCM_DIR=<parent dir. to lib/ and inc/, containing RSMI library and header>
```

```
$ mkdir <location for test build>
```

```
$ cd <location for test build>
```

```
$ cmake -DROCM_DIR=$ROCM_DIR <ROCm SMI source root>/tests/rocm_smi_test
```

```
$ make To run the test, execute the program rsmitst that is built from the steps above.
```

1.3 Usage Basics

1.3.1 Device Indices

Many of the functions in the library take a "device index". The device index is a number greater than or equal to 0, and less than the number of devices detected, as determined by `rsmi_num_monitor_devices()`. The index is used to distinguish the detected devices from one another. It is important to note that a device may end up with a different index after a reboot, so an index should not be relied upon to be constant over reboots.

1.4 Hello ROCm SMI

The only required ROCm-SMI call for any program that wants to use ROCm-SMI is the `rsmi_init()` call. This call initializes some internal data structures that will be used by subsequent ROCm-SMI calls.

When ROCm-SMI is no longer being used, `rsmi_shut_down()` should be called. This provides a way to do any releasing of resources that ROCm-SMI may have held. In many cases, this may have no effect, but may be necessary in future versions of the library.

A simple "Hello World" type program that displays the device ID of detected devices would look like this:

```
#include <stdint.h>
#include "rocm_smi/rocm_smi.h"
int main() {
    rsmi_status_t ret;
    uint32_t num_devices;
    uint16_t dev_id;
    // We will skip return code checks for this example, but it
    // is recommended to always check this as some calls may not
    // apply for some devices or ROCm releases
    ret = rsmi_init(0);
    ret = rsmi_num_monitor_devices(&num_devices);
    for (int i=0; i < num_devices; ++i) {
        ret = rsmi_dev_id_get(i, &dev_id);
        // dev_id holds the device ID of device i, upon a
        // successful call
    }
    ret = rsmi_shut_down();
    return 0;
}
```


Chapter 2

Deprecated List

Global [rsmi_dev_overdrive_level_set](#) (`int32_t dv_ind, uint32_t od`)

This function is deprecated. [rsmi_dev_overdrive_level_set_v1](#) has the same functionality, with an interface that more closely matches the rest of the rocm_smi API.

Global [rsmi_dev_perf_level_set](#) (`int32_t dv_ind, rsmi_dev_perf_level_t perf_lvl`)

[rsmi_dev_perf_level_set_v1\(\)](#) is preferred, with an interface that more closely matches the rest of the rocm_smi API.

Chapter 3

Module Index

3.1 Modules

Here is a list of all modules:

- Initialization and Shutdown 13
- Identifier Queries 15
- PCIe Queries 24
- PCIe Control 29
- Power Queries 30
- Power Control 34
- Memory Queries 36
- Physical State Queries 40
- Physical State Control 44
- Clock, Power and Performance Queries 46
- Clock, Power and Performance Control 57
- Version Queries 62
- Error Queries 65
- Performance Counter Functions 69
- System Information Functions 74
- XGMI Functions 77
- Hardware Topology Functions 79
- Compute Partition Functions 83
- NPS Mode Functions 86
- Supported Functions 89
- Event Notification Functions 94

Chapter 4

Data Structure Index

4.1 Data Structures

Here are the data structures with brief descriptions:

id	This union holds the value of an rsmi_func_id_iter_handle_t . The value may be a function name, or an enumerated variant value of types such as rsmi_memory_type_t , rsmi_temperature_metric_t , etc	97
metrics_table_header_t	The following structures hold the gpu metrics values for a device	98
rsmi_counter_value_t		98
rsmi_error_count_t	This structure holds error counts	99
rsmi_evt_notification_data_t		100
rsmi_freq_volt_region_t	This structure holds 2 rsmi_range_t 's, one for frequency and one for voltage. These 2 ranges indicate the range of possible values for the corresponding rsmi_od_vddc_point_t	100
rsmi_frequencies_t	This structure holds information about clock frequencies	101
rsmi_gpu_metrics_t		102
rsmi_od_vddc_point_t	This structure represents a point on the frequency-voltage plane	102
rsmi_od_volt_curve_t		102
rsmi_od_volt_freq_data_t	This structure holds the frequency-voltage values for a device	103
rsmi_pcie_bandwidth_t	This structure holds information about the possible PCIe bandwidths. Specifically, the possible transfer rates and their associated numbers of lanes are stored here	104
rsmi_power_profile_status_t	This structure contains information about which power profiles are supported by the system for a given device, and which power profile is currently active	104
rsmi_process_info_t	This structure contains information specific to a process	105
rsmi_range_t	This structure represents a range (e.g., frequencies or voltages)	106
rsmi_retired_page_record_t	Reserved Memory Page Record	106
rsmi_utilization_counter_t	The utilization counter data	107
rsmi_version_t	This structure holds version information	107

Chapter 5

File Index

5.1 File List

Here is a list of all documented files with brief descriptions:

[rocm_smi.h](#)
The rocm_smi library api is new, and therefore subject to change either at the ABI or API level. Instead of marking every function prototype as "unstable", we are instead saying the API is unstable (i.e., changes are possible) while the major version remains 0. This means that if the API/ABI changes, we will not increment the major version to 1. Once the ABI stabilizes, we will increment the major version to 1, and thereafter increment it on all ABI breaks 109

Chapter 6

Module Documentation

6.1 Initialization and Shutdown

These functions are used for initialization of ROCm SMI and clean up when done.

Functions

- [rsmi_status_t rsmi_init](#) (uint64_t init_flags)
Initialize ROCm SMI.
- [rsmi_status_t rsmi_shut_down](#) (void)
Shutdown ROCm SMI.

6.1.1 Detailed Description

These functions are used for initialization of ROCm SMI and clean up when done.

6.1.2 Function Documentation

6.1.2.1 rsmi_init()

```
rsmi_status_t rsmi_init (  
    uint64_t init_flags )
```

Initialize ROCm SMI.

When called, this initializes internal data structures, including those corresponding to sources of information that SMI provides.

Parameters

in	<i>init_flags</i>	Bit flags that tell SMI how to initialize. Values of rsmi_init_flags_t may be OR'd together and passed through <i>init_flags</i> to modify how RSMI initializes.
----	-------------------	--

Return values

RSMI_STATUS_SUCCESS	is returned upon successful call.
-------------------------------------	-----------------------------------

6.1.2.2 rsmi_shut_down()

```
rsmi_status_t rsmi_shut_down (  
    void )
```

Shutdown ROCm SMI.

Do any necessary clean up.

6.2 Identifier Queries

These functions provide identification information.

Functions

- [rsmi_status_t rsmi_num_monitor_devices](#) (uint32_t *num_devices)
Get the number of devices that have monitor information.
- [rsmi_status_t rsmi_dev_id_get](#) (uint32_t dv_ind, uint16_t *id)
Get the device id associated with the device with provided device index.
- [rsmi_status_t rsmi_dev_sku_get](#) (uint32_t dv_ind, char *sku)
Get the SKU for a desired device associated with the device with provided device index.
- [rsmi_status_t rsmi_dev_vendor_id_get](#) (uint32_t dv_ind, uint16_t *id)
Get the device vendor id associated with the device with provided device index.
- [rsmi_status_t rsmi_dev_name_get](#) (uint32_t dv_ind, char *name, size_t len)
Get the name string of a gpu device.
- [rsmi_status_t rsmi_dev_brand_get](#) (uint32_t dv_ind, char *brand, uint32_t len)
Get the brand string of a gpu device.
- [rsmi_status_t rsmi_dev_vendor_name_get](#) (uint32_t dv_ind, char *name, size_t len)
Get the name string for a give vendor ID.
- [rsmi_status_t rsmi_dev_vram_vendor_get](#) (uint32_t dv_ind, char *brand, uint32_t len)
Get the vram vendor string of a gpu device.
- [rsmi_status_t rsmi_dev_serial_number_get](#) (uint32_t dv_ind, char *serial_num, uint32_t len)
Get the serial number string for a device.
- [rsmi_status_t rsmi_dev_subsystem_id_get](#) (uint32_t dv_ind, uint16_t *id)
Get the subsystem device id associated with the device with provided device index.
- [rsmi_status_t rsmi_dev_subsystem_name_get](#) (uint32_t dv_ind, char *name, size_t len)
Get the name string for the device subsystem.
- [rsmi_status_t rsmi_dev_drm_render_minor_get](#) (uint32_t dv_ind, uint32_t *minor)
Get the drm minor number associated with this device.
- [rsmi_status_t rsmi_dev_subsystem_vendor_id_get](#) (uint32_t dv_ind, uint16_t *id)
Get the device subsystem vendor id associated with the device with provided device index.
- [rsmi_status_t rsmi_dev_unique_id_get](#) (uint32_t dv_ind, uint64_t *id)
Get Unique ID.

6.2.1 Detailed Description

These functions provide identification information.

6.2.2 Function Documentation

6.2.2.1 rsmi_num_monitor_devices()

```
rsmi_status_t rsmi_num_monitor_devices (
    uint32_t * num_devices )
```

Get the number of devices that have monitor information.

The number of devices which have monitors is returned. Monitors are referenced by the index which can be between 0 and `num_devices - 1`.

Parameters

in, out	<i>num_devices</i>	Caller provided pointer to uint32_t. Upon successful call, the value num_devices will contain the number of monitor devices.
---------	--------------------	--

Return values

RSMI_STATUS_SUCCESS	is returned upon successful call.
-------------------------------------	-----------------------------------

6.2.2.2 rsmi_dev_id_get()

```
rsmi_status_t rsmi_dev_id_get (
    uint32_t dv_ind,
    uint16_t * id )
```

Get the device id associated with the device with provided device index.

Given a device index *dv_ind* and a pointer to a uint32_t *id*, this function will write the device id value to the uint64_t pointed to by *id*. This ID is an identification of the type of device, so calling this function for different devices will give the same value if they are kind of device. Consequently, this function should not be used to distinguish one device from another. [rsmi_dev_pci_id_get\(\)](#) should be used to get a unique identifier.

Parameters

in	<i>dv_ind</i>	a device index
in, out	<i>id</i>	a pointer to uint64_t to which the device id will be written. If this parameter is nullptr, this function will return RSMI_STATUS_INVALID_ARGS if the function is supported with the provided arguments and RSMI_STATUS_NOT_SUPPORTED if it is not supported with the provided arguments.

Return values

RSMI_STATUS_SUCCESS	call was successful
RSMI_STATUS_NOT_SUPPORTED	installed software or hardware does not support this function with the given arguments
RSMI_STATUS_INVALID_ARGS	the provided arguments are not valid

6.2.2.3 rsmi_dev_sku_get()

```
rsmi_status_t rsmi_dev_sku_get (
    uint32_t dv_ind,
    char * sku )
```

Get the SKU for a desired device associated with the device with provided device index.

Given a device index *dv_ind* and a pointer to a char *sku*, this function will attempt to obtain the SKU from the Product Information FRU chip, present on server ASICs. It will write the sku value to the char array pointed to by *sku*.

Parameters

<code>in</code>	<code>dv_ind</code>	a device index
<code>in, out</code>	<code>sku</code>	a pointer to char to which the sku will be written

If this parameter is nullptr, this function will return [RSMI_STATUS_INVALID_ARGS](#) if the function is supported with the provided, arguments and [RSMI_STATUS_NOT_SUPPORTED](#) if it is not supported with the provided arguments.

Return values

RSMI_STATUS_SUCCESS	call was successful
RSMI_STATUS_NOT_SUPPORTED	installed software or hardware does not support this function with the given arguments
RSMI_STATUS_INVALID_ARGS	the provided arguments are not valid

6.2.2.4 `rsmi_dev_vendor_id_get()`

```
rsmi_status_t rsmi_dev_vendor_id_get (
    uint32_t dv_ind,
    uint16_t * id )
```

Get the device vendor id associated with the device with provided device index.

Given a device index `dv_ind` and a pointer to a `uint32_t id`, this function will write the device vendor id value to the `uint64_t` pointed to by `id`.

Parameters

<code>in</code>	<code>dv_ind</code>	a device index
<code>in, out</code>	<code>id</code>	a pointer to <code>uint64_t</code> to which the device vendor id will be written If this parameter is nullptr, this function will return RSMI_STATUS_INVALID_ARGS if the function is supported with the provided, arguments and RSMI_STATUS_NOT_SUPPORTED if it is not supported with the provided arguments.

Return values

RSMI_STATUS_SUCCESS	call was successful
RSMI_STATUS_NOT_SUPPORTED	installed software or hardware does not support this function with the given arguments
RSMI_STATUS_INVALID_ARGS	the provided arguments are not valid

6.2.2.5 `rsmi_dev_name_get()`

```
rsmi_status_t rsmi_dev_name_get (
    uint32_t dv_ind,
```

```
char * name,
size_t len )
```

Get the name string of a gpu device.

Given a device index `dv_ind`, a pointer to a caller provided char buffer `name`, and a length of this buffer `len`, this function will write the name of the device (up to `len` characters) to the buffer `name`.

If the integer ID associated with the device is not found in one of the system files containing device name information (e.g. `/usr/share/misc/pci.ids`), then this function will return the hex device ID as a string. Updating the system name files can be accomplished with "sudo update-pciids".

Parameters

in	<code>dv_ind</code>	a device index
in, out	<code>name</code>	a pointer to a caller provided char buffer to which the name will be written If this parameter is nullptr, this function will return RSMI_STATUS_INVALID_ARGS if the function is supported with the provided, arguments and RSMI_STATUS_NOT_SUPPORTED if it is not supported with the provided arguments.
in	<code>len</code>	the length of the caller provided buffer <code>name</code> .

Return values

RSMI_STATUS_SUCCESS	call was successful
RSMI_STATUS_NOT_SUPPORTED	installed software or hardware does not support this function with the given arguments
RSMI_STATUS_INVALID_ARGS	the provided arguments are not valid
RSMI_STATUS_INSUFFICIENT_SIZE	is returned if <code>len</code> bytes is not large enough to hold the entire name. In this case, only <code>len</code> bytes will be written.

6.2.2.6 `rsmi_dev_brand_get()`

```
rsmi_status_t rsmi_dev_brand_get (
    uint32_t dv_ind,
    char * brand,
    uint32_t len )
```

Get the brand string of a gpu device.

Given a device index `dv_ind`, a pointer to a caller provided char buffer `brand`, and a length of this buffer `len`, this function will write the brand of the device (up to `len` characters) to the buffer `brand`.

If the sku associated with the device is not found as one of the values contained within `rsmi_dev_brand_get`, then this function will return the device marketing name as a string instead of the brand name.

Parameters

in	<code>dv_ind</code>	a device index
in, out	<code>brand</code>	a pointer to a caller provided char buffer to which the brand will be written If this parameter is nullptr, this function will return RSMI_STATUS_INVALID_ARGS if the function is supported with the provided, arguments and RSMI_STATUS_NOT_SUPPORTED if it is not supported with the provided arguments.
in	<code>len</code>	the length of the caller provided buffer <code>brand</code> .

Return values

<i>RSMI_STATUS_SUCCESS</i>	call was successful
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function with the given arguments
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid
<i>RSMI_STATUS_INSUFFICIENT_SIZE</i>	is returned if <code>len</code> bytes is not large enough to hold the entire name. In this case, only <code>len</code> bytes will be written.

6.2.2.7 `rsmi_dev_vendor_name_get()`

```
rsmi_status_t rsmi_dev_vendor_name_get (
    uint32_t dv_ind,
    char * name,
    size_t len )
```

Get the name string for a give vendor ID.

Given a device index `dv_ind`, a pointer to a caller provided char buffer `name`, and a length of this buffer `len`, this function will write the name of the vendor (up to `len` characters) buffer `name`. The `id` may be a device vendor or subsystem vendor ID.

If the integer ID associated with the vendor is not found in one of the system files containing device name information (e.g. `/usr/share/misc/pci.ids`), then this function will return the hex vendor ID as a string. Updating the system name files can be accomplished with "sudo update-pciids".

Parameters

in	<i>dv_ind</i>	a device index
in, out	<i>name</i>	a pointer to a caller provided char buffer to which the name will be written. If this parameter is nullptr, this function will return <i>RSMI_STATUS_INVALID_ARGS</i> if the function is supported with the provided arguments and <i>RSMI_STATUS_NOT_SUPPORTED</i> if it is not supported with the provided arguments.
in	<i>len</i>	the length of the caller provided buffer <code>name</code> .

Return values

<i>RSMI_STATUS_SUCCESS</i>	call was successful
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function with the given arguments
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid
<i>RSMI_STATUS_INSUFFICIENT_SIZE</i>	is returned if <code>len</code> bytes is not large enough to hold the entire name. In this case, only <code>len</code> bytes will be written.

6.2.2.8 `rsmi_dev_vram_vendor_get()`

```
rsmi_status_t rsmi_dev_vram_vendor_get (
```

```
uint32_t dv_ind,
char * brand,
uint32_t len )
```

Get the vram vendor string of a gpu device.

Given a device index `dv_ind`, a pointer to a caller provided char buffer `brand`, and a length of this buffer `len`, this function will write the vram vendor of the device (up to `len` characters) to the buffer `brand`.

If the vram vendor for the device is not found as one of the values contained within `rsmi_dev_vram_vendor_get`, then this function will return the string 'unknown' instead of the vram vendor.

Parameters

in	<code>dv_ind</code>	a device index
in, out	<code>brand</code>	a pointer to a caller provided char buffer to which the vram vendor will be written
in	<code>len</code>	the length of the caller provided buffer <code>brand</code> .

Return values

<code>RSMI_STATUS_SUCCESS</code>	is returned upon successful call.
--	-----------------------------------

6.2.2.9 `rsmi_dev_serial_number_get()`

```
rsmi_status_t rsmi_dev_serial_number_get (
uint32_t dv_ind,
char * serial_num,
uint32_t len )
```

Get the serial number string for a device.

Given a device index `dv_ind`, a pointer to a buffer of chars `serial_num`, and the length of the provided buffer `len`, this function will write the serial number string (up to `len` characters) to the buffer pointed to by `serial_num`.

Parameters

in	<code>dv_ind</code>	a device index
in, out	<code>serial_num</code>	a pointer to caller-provided memory to which the serial number will be written If this parameter is nullptr, this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided, arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.
in	<code>len</code>	the length of the caller provided buffer <code>serial_num</code> .

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments

Return values

RSMI_STATUS_INVALID_ARGS	the provided arguments are not valid
RSMI_STATUS_INSUFFICIENT_SIZE	is returned if <code>len</code> bytes is not large enough to hold the entire name. In this case, only <code>len</code> bytes will be written.

6.2.2.10 `rsmi_dev_subsystem_id_get()`

```
rsmi_status_t rsmi_dev_subsystem_id_get (
    uint32_t dv_ind,
    uint16_t * id )
```

Get the subsystem device id associated with the device with provided device index.

Given a device index `dv_ind` and a pointer to a `uint32_t id`, this function will write the subsystem device id value to the `uint64_t` pointed to by `id`.

Parameters

in	<code>dv_ind</code>	a device index
in, out	<code>id</code>	a pointer to <code>uint64_t</code> to which the subsystem device id will be written. If this parameter is <code>nullptr</code> , this function will return RSMI_STATUS_INVALID_ARGS if the function is supported with the provided arguments and RSMI_STATUS_NOT_SUPPORTED if it is not supported with the provided arguments.

Return values

RSMI_STATUS_SUCCESS	call was successful
RSMI_STATUS_NOT_SUPPORTED	installed software or hardware does not support this function with the given arguments
RSMI_STATUS_INVALID_ARGS	the provided arguments are not valid

6.2.2.11 `rsmi_dev_subsystem_name_get()`

```
rsmi_status_t rsmi_dev_subsystem_name_get (
    uint32_t dv_ind,
    char * name,
    size_t len )
```

Get the name string for the device subsystem.

Given a device index `dv_ind`, a pointer to a caller provided char buffer `name`, and a length of this buffer `len`, this function will write the name of the device subsystem (up to `len` characters) to the buffer `name`.

If the integer ID associated with the sub-system is not found in one of the system files containing device name information (e.g. `/usr/share/misc/pci.ids`), then this function will return the hex sub-system ID as a string. Updating the system name files can be accomplished with "sudo update-pciids".

Parameters

in	<i>dv_ind</i>	a device index
in, out	<i>name</i>	a pointer to a caller provided char buffer to which the name will be written. If this parameter is nullptr, this function will return RSMI_STATUS_INVALID_ARGS if the function is supported with the provided arguments and RSMI_STATUS_NOT_SUPPORTED if it is not supported with the provided arguments.
in	<i>len</i>	the length of the caller provided buffer <i>name</i> .

Return values

RSMI_STATUS_SUCCESS	call was successful
RSMI_STATUS_NOT_SUPPORTED	installed software or hardware does not support this function with the given arguments
RSMI_STATUS_INVALID_ARGS	the provided arguments are not valid
RSMI_STATUS_INSUFFICIENT_SIZE	is returned if <i>len</i> bytes is not large enough to hold the entire name. In this case, only <i>len</i> bytes will be written.

6.2.2.12 `rsmi_dev_drm_render_minor_get()`

```
rsmi_status_t rsmi_dev_drm_render_minor_get (
    uint32_t dv_ind,
    uint32_t * minor )
```

Get the drm minor number associated with this device.

Given a device index *dv_ind*, find its render device file `/dev/dri/renderDN` where N corresponds to its minor number.

Parameters

in	<i>dv_ind</i>	a device index
in, out	<i>minor</i>	a pointer to a <code>uint32_t</code> into which minor number will be copied

Return values

RSMI_STATUS_SUCCESS	is returned upon successful call.
RSMI_STATUS_INIT_ERROR	if failed to get minor number during initialization.
RSMI_STATUS_INVALID_ARGS	the provided arguments are not valid

6.2.2.13 `rsmi_dev_subsystem_vendor_id_get()`

```
rsmi_status_t rsmi_dev_subsystem_vendor_id_get (
    uint32_t dv_ind,
    uint16_t * id )
```


Get the device subsystem vendor id associated with the device with provided device index.

Given a device index `dv_ind` and a pointer to a `uint32_t id`, this function will write the device subsystem vendor id value to the `uint64_t` pointed to by `id`.

Parameters

<code>in</code>	<code>dv_ind</code>	a device index
<code>in, out</code>	<code>id</code>	a pointer to <code>uint64_t</code> to which the device subsystem vendor id will be written. If this parameter is <code>nullptr</code> , this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments
<code>RSMI_STATUS_INVALID_ARGS</code>	the provided arguments are not valid

6.2.2.14 `rsmi_dev_unique_id_get()`

```
rsmi_status_t rsmi_dev_unique_id_get (
    uint32_t dv_ind,
    uint64_t * id )
```

Get Unique ID.

Given a device index `dv_ind` and a pointer to a `uint64_t id`, this function will write the unique ID of the GPU pointed to `id`.

Parameters

<code>in</code>	<code>dv_ind</code>	a device index
<code>in, out</code>	<code>id</code>	a pointer to <code>uint64_t</code> to which the unique ID of the GPU is written. If this parameter is <code>nullptr</code> , this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments
<code>RSMI_STATUS_INVALID_ARGS</code>	the provided arguments are not valid

6.3 PCIe Queries

These functions provide information about PCIe.

Functions

- [rsmi_status_t rsmi_dev_pci_bandwidth_get](#) (uint32_t dv_ind, [rsmi_pcie_bandwidth_t](#) *bandwidth)
Get the list of possible PCIe bandwidths that are available.
- [rsmi_status_t rsmi_dev_pci_id_get](#) (uint32_t dv_ind, uint64_t *bdfid)
Get the unique PCI device identifier associated for a device.
- [rsmi_status_t rsmi_topo_numa_affinity_get](#) (uint32_t dv_ind, uint32_t *numa_node)
Get the NUMA node associated with a device.
- [rsmi_status_t rsmi_dev_pci_throughput_get](#) (uint32_t dv_ind, uint64_t *sent, uint64_t *received, uint64_t *max_pkt_sz)
Get PCIe traffic information.
- [rsmi_status_t rsmi_dev_pci_replay_counter_get](#) (uint32_t dv_ind, uint64_t *counter)
Get PCIe replay counter.

6.3.1 Detailed Description

These functions provide information about PCIe.

6.3.2 Function Documentation

6.3.2.1 rsmi_dev_pci_bandwidth_get()

```
rsmi_status_t rsmi_dev_pci_bandwidth_get (
    uint32_t dv_ind,
    rsmi_pcie_bandwidth_t * bandwidth )
```

Get the list of possible PCIe bandwidths that are available.

Given a device index `dv_ind` and a pointer to a to an [rsmi_pcie_bandwidth_t](#) structure `bandwidth`, this function will fill in `bandwidth` with the possible T/s values and associated number of lanes, and indication of the current selection.

Parameters

in	<code>dv_ind</code>	a device index
in, out	<code>bandwidth</code>	a pointer to a caller provided rsmi_pcie_bandwidth_t structure to which the frequency information will be written

Return values

RSMI_STATUS_SUCCESS	is returned upon successful call.
-------------------------------------	-----------------------------------

6.3.2.2 rsmi_dev_pci_id_get()

```
rsmi_status_t rsmi_dev_pci_id_get (
    uint32_t dv_ind,
    uint64_t * bdfid )
```

Get the unique PCI device identifier associated for a device.

Give a device index `dv_ind` and a pointer to a `uint64_t bdfid`, this function will write the Bus/Device/Function PCI identifier (BDFID) associated with device `dv_ind` to the value pointed to by `bdfid`.

The format of `bdfid` will be as follows:

```
BDFID = ((DOMAIN & 0xffffffff) << 32) | ((BUS & 0xff) << 8) |
        ((DEVICE & 0x1f) << 3) | (FUNCTION & 0x7)
```

Name	Field
Domain	[64:32]
Reserved	[31:16]
Bus	[15: 8]
Device	[7: 3]
Function	[2: 0]

Parameters

in	<i>dv_ind</i>	a device index
in, out	<i>bdfid</i>	a pointer to <code>uint64_t</code> to which the device bdfid value will be written. If this parameter is <code>nullptr</code> , this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments
<code>RSMI_STATUS_INVALID_ARGS</code>	the provided arguments are not valid

6.3.2.3 rsmi_topo_numa_affinity_get()

```
rsmi_status_t rsmi_topo_numa_affinity_get (
    uint32_t dv_ind,
    uint32_t * numa_node )
```

Get the NUMA node associated with a device.

Given a device index `dv_ind` and a pointer to a `uint32_t numa_node`, this function will retrieve the NUMA node value associated with device `dv_ind` and store the value at location pointed to by `numa_node`.

Parameters

in	<i>dv_ind</i>	a device index
in, out	<i>numa_node</i>	pointer to location where NUMA node value will be written. If this parameter is nullptr, this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments
<code>RSMI_STATUS_INVALID_ARGS</code>	the provided arguments are not valid

6.3.2.4 `rsmi_dev_pci_throughput_get()`

```
rsmi_status_t rsmi_dev_pci_throughput_get (
    uint32_t dv_ind,
    uint64_t * sent,
    uint64_t * received,
    uint64_t * max_pkt_sz )
```

Get PCIe traffic information.

Give a device index `dv_ind` and pointers to a `uint64_t`'s, `sent`, `received` and `max_pkt_sz`, this function will write the number of bytes sent and received in 1 second to `sent` and `received`, respectively. The maximum possible packet size will be written to `max_pkt_sz`.

Parameters

in	<i>dv_ind</i>	a device index
in, out	<i>sent</i>	a pointer to <code>uint64_t</code> to which the number of bytes sent will be written in 1 second. If pointer is NULL, it will be ignored.
in, out	<i>received</i>	a pointer to <code>uint64_t</code> to which the number of bytes received will be written. If pointer is NULL, it will be ignored.
in, out	<i>max_pkt_sz</i>	a pointer to <code>uint64_t</code> to which the maximum packet size will be written. If pointer is NULL, it will be ignored.

Return values

<code>RSMI_STATUS_SUCCESS</code>	is returned upon successful call.
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments

6.3.2.5 rsmi_dev_pci_replay_counter_get()

```
rsmi_status_t rsmi_dev_pci_replay_counter_get (
    uint32_t dv_ind,
    uint64_t * counter )
```

Get PCIe replay counter.

Given a device index `dv_ind` and a pointer to a `uint64_t counter`, this function will write the sum of the number of NAK's received by the GPU and the NAK's generated by the GPU to memory pointed to by `counter`.

Parameters

in	<code>dv_ind</code>	a device index
in, out	<code>counter</code>	a pointer to <code>uint64_t</code> to which the sum of the NAK's received and generated by the GPU is written. If this parameter is <code>nullptr</code> , this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments
<code>RSMI_STATUS_INVALID_ARGS</code>	the provided arguments are not valid

6.4 PCIe Control

These functions provide some control over PCIe.

Functions

- [rsmi_status_t rsmi_dev_pci_bandwidth_set](#) (uint32_t dv_ind, uint64_t bw_bitmask)
Control the set of allowed PCIe bandwidths that can be used.

6.4.1 Detailed Description

These functions provide some control over PCIe.

6.4.2 Function Documentation

6.4.2.1 rsmi_dev_pci_bandwidth_set()

```
rsmi_status_t rsmi_dev_pci_bandwidth_set (
    uint32_t dv_ind,
    uint64_t bw_bitmask )
```

Control the set of allowed PCIe bandwidths that can be used.

Given a device index `dv_ind` and a 64 bit bitmask `bw_bitmask`, this function will limit the set of allowable bandwidths. If a bit in `bw_bitmask` has a value of 1, then the frequency (as ordered in an [rsmi_frequencies_t](#) returned by [rsmi_dev_gpu_clk_freq_get\(\)](#)) corresponding to that bit index will be allowed.

This function will change the performance level to [RSMI_DEV_PERF_LEVEL_MANUAL](#) in order to modify the set of allowable band_widths. Caller will need to set to [RSMI_DEV_PERF_LEVEL_AUTO](#) in order to get back to default state.

All bits with indices greater than or equal to the value of the [rsmi_frequencies_t::num_supported](#) field of [rsmi_pcie_bandwidth_t](#) will be ignored.

Parameters

in	<code>dv_ind</code>	a device index
in	<code>bw_bitmask</code>	A bitmask indicating the indices of the bandwidths that are to be enabled (1) and disabled (0). Only the lowest rsmi_frequencies_t::num_supported (of rsmi_pcie_bandwidth_t) bits of this mask are relevant.

Return values

RSMI_STATUS_SUCCESS	call was successful
RSMI_STATUS_PERMISSION	function requires root access

6.5 Power Queries

These functions provide information about power usage.

Functions

- [rsmi_status_t rsmi_dev_power_ave_get](#) (uint32_t dv_ind, uint32_t sensor_ind, uint64_t *power)
Get the average power consumption of the device with provided device index.
- [rsmi_status_t rsmi_dev_energy_count_get](#) (uint32_t dv_ind, uint64_t *power, float *counter_resolution, uint64_t *timestamp)
Get the energy accumulator counter of the device with provided device index.
- [rsmi_status_t rsmi_dev_power_cap_get](#) (uint32_t dv_ind, uint32_t sensor_ind, uint64_t *cap)
Get the cap on power which, when reached, causes the system to take action to reduce power.
- [rsmi_status_t rsmi_dev_power_cap_default_get](#) (uint32_t dv_ind, uint64_t *default_cap)
Get the default power cap for the device specified by dv_ind.
- [rsmi_status_t rsmi_dev_power_cap_range_get](#) (uint32_t dv_ind, uint32_t sensor_ind, uint64_t *max, uint64_t *min)
Get the range of valid values for the power cap.

6.5.1 Detailed Description

These functions provide information about power usage.

6.5.2 Function Documentation

6.5.2.1 rsmi_dev_power_ave_get()

```
rsmi_status_t rsmi_dev_power_ave_get (
    uint32_t dv_ind,
    uint32_t sensor_ind,
    uint64_t * power )
```

Get the average power consumption of the device with provided device index.

Given a device index `dv_ind` and a pointer to a `uint64_t power`, this function will write the current average power consumption (in microwatts) to the `uint64_t` pointed to by `power`.

Parameters

in	<i>dv_ind</i>	a device index
in	<i>sensor_ind</i>	a 0-based sensor index. Normally, this will be 0. If a device has more than one sensor, it could be greater than 0.
in, out	<i>power</i>	a pointer to <code>uint64_t</code> to which the average power consumption will be written. If this parameter is <code>nullptr</code> , this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.

Return values

<i>RSMI_STATUS_SUCCESS</i>	call was successful
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function with the given arguments
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid

6.5.2.2 `rsmi_dev_energy_count_get()`

```
rsmi_status_t rsmi_dev_energy_count_get (
    uint32_t dv_ind,
    uint64_t * power,
    float * counter_resolution,
    uint64_t * timestamp )
```

Get the energy accumulator counter of the device with provided device index.

Given a device index `dv_ind`, a pointer to a `uint64_t` `power`, and a pointer to a `uint64_t` `timestamp`, this function will write amount of energy consumed to the `uint64_t` pointed to by `power`, and the timestamp to the `uint64_t` pointed to by `timestamp`. The [`rsmi_dev_power_ave_get\(\)`](#) is an average of a short time. This function accumulates all energy consumed.

Parameters

in	<i>dv_ind</i>	a device index
in, out	<i>counter_resolution</i>	resolution of the counter <code>power</code> in micro Joules
in, out	<i>power</i>	a pointer to <code>uint64_t</code> to which the energy counter will be written. If this parameter is <code>nullptr</code> , this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided, and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.
in, out	<i>timestamp</i>	a pointer to <code>uint64_t</code> to which the timestamp will be written. Resolution: 1 ns.

Return values

<i>RSMI_STATUS_SUCCESS</i>	call was successful
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function with the given arguments
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid

6.5.2.3 `rsmi_dev_power_cap_get()`

```
rsmi_status_t rsmi_dev_power_cap_get (
    uint32_t dv_ind,
    uint32_t sensor_ind,
    uint64_t * cap )
```

Get the cap on power which, when reached, causes the system to take action to reduce power.

When power use rises above the value `power`, the system will take action to reduce power use. The power level returned through `power` will be in microWatts.

Parameters

in	<i>dv_ind</i>	a device index
in	<i>sensor_ind</i>	a 0-based sensor index. Normally, this will be 0. If a device has more than one sensor, it could be greater than 0.
in, out	<i>cap</i>	a pointer to a <code>uint64_t</code> that indicates the power cap, in microwatts If this parameter is <code>nullptr</code> , this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided, arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments
<code>RSMI_STATUS_INVALID_ARGS</code>	the provided arguments are not valid

6.5.2.4 `rsmi_dev_power_cap_default_get()`

```
rsmi_status_t rsmi_dev_power_cap_default_get (
    uint32_t dv_ind,
    uint64_t * default_cap )
```

Get the default power cap for the device specified by `dv_ind`.

The maximum power cap be temporarily changed by the user. However, this function always returns the default reset power cap. The power level returned through `power` will be in microWatts.

Parameters

in	<i>dv_ind</i>	a device index
in, out	<i>default_cap</i>	a pointer to a <code>uint64_t</code> that indicates the default power cap, in microwatts If this parameter is <code>nullptr</code> , this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided, arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments
<code>RSMI_STATUS_INVALID_ARGS</code>	the provided arguments are not valid

6.5.2.5 `rsmi_dev_power_cap_range_get()`

```
rsmi_status_t rsmi_dev_power_cap_range_get (
    uint32_t dv_ind,
    uint32_t sensor_ind,
    uint64_t * max,
    uint64_t * min )
```

Get the range of valid values for the power cap.

This function will return the maximum possible valid power cap `max` and the minimum possible valid power cap `min`

Parameters

in	<i>dv_ind</i>	a device index
in	<i>sensor_ind</i>	a 0-based sensor index. Normally, this will be 0. If a device has more than one sensor, it could be greater than 0.
in, out	<i>max</i>	a pointer to a <code>uint64_t</code> that indicates the maximum possible power cap, in microwatts. If this parameter is <code>nullptr</code> , this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.
in, out	<i>min</i>	a pointer to a <code>uint64_t</code> that indicates the minimum possible power cap, in microwatts. If this parameter is <code>nullptr</code> , this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments
<code>RSMI_STATUS_INVALID_ARGS</code>	the provided arguments are not valid

6.6 Power Control

These functions provide ways to control power usage.

Functions

- [rsmi_status_t rsmi_dev_power_cap_set](#) (uint32_t *dv_ind*, uint32_t *sensor_ind*, uint64_t *cap*)
Set the power cap value.
- [rsmi_status_t rsmi_dev_power_profile_set](#) (uint32_t *dv_ind*, uint32_t *reserved*, [rsmi_power_profile_preset_masks_t](#) *profile*)
Set the power profile.

6.6.1 Detailed Description

These functions provide ways to control power usage.

6.6.2 Function Documentation

6.6.2.1 rsmi_dev_power_cap_set()

```
rsmi_status_t rsmi_dev_power_cap_set (
    uint32_t dv_ind,
    uint32_t sensor_ind,
    uint64_t cap )
```

Set the power cap value.

This function will set the power cap to the provided value *cap*. *cap* must be between the minimum and maximum power cap values set by the system, which can be obtained from [rsmi_dev_power_cap_range_get](#).

Parameters

in	<i>dv_ind</i>	a device index
in	<i>sensor_ind</i>	a 0-based sensor index. Normally, this will be 0. If a device has more than one sensor, it could be greater than 0.
in	<i>cap</i>	a uint64_t that indicates the desired power cap, in microwatts

Return values

RSMI_STATUS_SUCCESS	is returned upon successful call.
RSMI_STATUS_INVALID_ARGS	the provided arguments are not valid
RSMI_STATUS_PERMISSION	function requires root access

6.6.2.2 rsmi_dev_power_profile_set()

```
rsmi_status_t rsmi_dev_power_profile_set (
    uint32_t dv_ind,
    uint32_t reserved,
    rsmi_power_profile_preset_masks_t profile )
```

Set the power profile.

Given a device index `dv_ind` and a `profile`, this function will attempt to set the current profile to the provided profile. The provided profile must be one of the currently supported profiles, as indicated by a call to [rsmi_dev_power_profile_presets_get\(\)](#)

Parameters

in	<i>dv_ind</i>	a device index
in	<i>reserved</i>	Not currently used. Set to 0.
in	<i>profile</i>	a rsmi_power_profile_preset_masks_t that hold the mask of the desired new power profile

Return values

RSMI_STATUS_SUCCESS	is returned upon successful call.
RSMI_STATUS_PERMISSION	function requires root access

6.7 Memory Queries

These functions provide information about memory systems.

Functions

- `rsmi_status_t rsmi_dev_memory_total_get` (uint32_t `dv_ind`, `rsmi_memory_type_t` `mem_type`, uint64_t `*total`)
Get the total amount of memory that exists.
- `rsmi_status_t rsmi_dev_memory_usage_get` (uint32_t `dv_ind`, `rsmi_memory_type_t` `mem_type`, uint64_t `*used`)
Get the current memory usage.
- `rsmi_status_t rsmi_dev_memory_busy_percent_get` (uint32_t `dv_ind`, uint32_t `*busy_percent`)
Get percentage of time any device memory is being used.
- `rsmi_status_t rsmi_dev_memory_reserved_pages_get` (uint32_t `dv_ind`, uint32_t `*num_pages`, `rsmi_retired_page_record_t` `*records`)
Get information about reserved ("retired") memory pages.

6.7.1 Detailed Description

These functions provide information about memory systems.

6.7.2 Function Documentation

6.7.2.1 `rsmi_dev_memory_total_get()`

```
rsmi_status_t rsmi_dev_memory_total_get (
    uint32_t dv_ind,
    rsmi_memory_type_t mem_type,
    uint64_t * total )
```

Get the total amount of memory that exists.

Given a device index `dv_ind`, a type of memory `mem_type`, and a pointer to a `uint64_t` `total`, this function will write the total amount of `mem_type` memory that exists to the location pointed to by `total`.

Parameters

in	<code>dv_ind</code>	a device index
in	<code>mem_type</code>	The type of memory for which the total amount will be found
in, out	<code>total</code>	a pointer to <code>uint64_t</code> to which the total amount of memory will be written If this parameter is <code>nullptr</code> , this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.

Return values

<i>RSMI_STATUS_SUCCESS</i>	call was successful
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function with the given arguments
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid

6.7.2.2 `rsmi_dev_memory_usage_get()`

```
rsmi_status_t rsmi_dev_memory_usage_get (
    uint32_t dv_ind,
    rsmi_memory_type_t mem_type,
    uint64_t * used )
```

Get the current memory usage.

Given a device index `dv_ind`, a type of memory `mem_type`, and a pointer to a `uint64_t` usage, this function will write the amount of `mem_type` memory that is currently being used to the location pointed to by `used`.

Parameters

in	<i>dv_ind</i>	a device index
in	<i>mem_type</i>	The type of memory for which the amount being used will be found
in, out	<i>used</i>	a pointer to <code>uint64_t</code> to which the amount of memory currently being used will be written. If this parameter is <code>nullptr</code> , this function will return <i>RSMI_STATUS_INVALID_ARGS</i> if the function is supported with the provided arguments and <i>RSMI_STATUS_NOT_SUPPORTED</i> if it is not supported with the provided arguments.

Return values

<i>RSMI_STATUS_SUCCESS</i>	call was successful
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function with the given arguments
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid

6.7.2.3 `rsmi_dev_memory_busy_percent_get()`

```
rsmi_status_t rsmi_dev_memory_busy_percent_get (
    uint32_t dv_ind,
    uint32_t * busy_percent )
```

Get percentage of time any device memory is being used.

Given a device index `dv_ind`, this function returns the percentage of time that any device memory is being used for the specified device.

Parameters

in	<i>dv_ind</i>	a device index
in, out	<i>busy_percent</i>	a pointer to the <code>uint32_t</code> to which the busy percent will be written. If this parameter is <code>nullptr</code> , this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments
<code>RSMI_STATUS_INVALID_ARGS</code>	the provided arguments are not valid

6.7.2.4 `rsmi_dev_memory_reserved_pages_get()`

```
rsmi_status_t rsmi_dev_memory_reserved_pages_get (
    uint32_t dv_ind,
    uint32_t * num_pages,
    rsmi_retired_page_record_t * records )
```

Get information about reserved ("retired") memory pages.

Given a device index `dv_ind`, this function returns retired page information `records` corresponding to the device with the provided device index `dv_ind`. The number of retired page records is returned through `num_pages`. `records` may be `NULL` on input. In this case, the number of records available for retrieval will be returned through `num_pages`.

Parameters

in	<i>dv_ind</i>	a device index
in, out	<i>num_pages</i>	a pointer to a <code>uint32_t</code> . As input, the value passed through this parameter is the number of <code>rsmi_retired_page_record_t</code> 's that may be safely written to the memory pointed to by <code>records</code> . This is the limit on how many records will be written to <code>records</code> . On return, <code>num_pages</code> will contain the number of records written to <code>records</code> , or the number of records that could have been written if enough memory had been provided. If this parameter is <code>nullptr</code> , this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.
in, out	<i>records</i>	A pointer to a block of memory to which the <code>rsmi_retired_page_record_t</code> values will be written. This value may be <code>NULL</code> . In this case, this function can be used to query how many records are available to read.

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
----------------------------------	---------------------

Return values

<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function with the given arguments
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid
<i>RSMI_STATUS_INSUFFICIENT_SIZE</i>	is returned if more records were available than allowed by the provided, allocated memory.

6.8 Physical State Queries

These functions provide information about the physical characteristics of the device.

Functions

- [rsmi_status_t rsmi_dev_fan_rpms_get](#) (uint32_t dv_ind, uint32_t sensor_ind, int64_t *speed)
Get the fan speed in RPMs of the device with the specified device index and 0-based sensor index.
- [rsmi_status_t rsmi_dev_fan_speed_get](#) (uint32_t dv_ind, uint32_t sensor_ind, int64_t *speed)
Get the fan speed for the specified device as a value relative to [RSMI_MAX_FAN_SPEED](#).
- [rsmi_status_t rsmi_dev_fan_speed_max_get](#) (uint32_t dv_ind, uint32_t sensor_ind, uint64_t *max_speed)
Get the max. fan speed of the device with provided device index.
- [rsmi_status_t rsmi_dev_temp_metric_get](#) (uint32_t dv_ind, uint32_t sensor_type, [rsmi_temperature_metric_t](#) metric, int64_t *temperature)
Get the temperature metric value for the specified metric, from the specified temperature sensor on the specified device.
- [rsmi_status_t rsmi_dev_volt_metric_get](#) (uint32_t dv_ind, [rsmi_voltage_type_t](#) sensor_type, [rsmi_voltage_metric_t](#) metric, int64_t *voltage)
Get the voltage metric value for the specified metric, from the specified voltage sensor on the specified device.

6.8.1 Detailed Description

These functions provide information about the physical characteristics of the device.

6.8.2 Function Documentation

6.8.2.1 rsmi_dev_fan_rpms_get()

```
rsmi_status_t rsmi_dev_fan_rpms_get (
    uint32_t dv_ind,
    uint32_t sensor_ind,
    int64_t * speed )
```

Get the fan speed in RPMs of the device with the specified device index and 0-based sensor index.

Given a device index `dv_ind` and a pointer to a `uint32_t` `speed`, this function will write the current fan speed in RPMs to the `uint32_t` pointed to by `speed`

Parameters

in	<code>dv_ind</code>	a device index
in	<code>sensor_ind</code>	a 0-based sensor index. Normally, this will be 0. If a device has more than one sensor, it could be greater than 0.
in, out	<code>speed</code>	a pointer to <code>uint32_t</code> to which the speed will be written If this parameter is nullptr, this function will return RSMI_STATUS_INVALID_ARGS if the function is supported with the provided, arguments and RSMI_STATUS_NOT_SUPPORTED if it is not supported with the provided arguments.

Return values

<i>RSMI_STATUS_SUCCESS</i>	call was successful
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function with the given arguments
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid

6.8.2.2 `rsmi_dev_fan_speed_get()`

```
rsmi_status_t rsmi_dev_fan_speed_get (
    uint32_t dv_ind,
    uint32_t sensor_ind,
    int64_t * speed )
```

Get the fan speed for the specified device as a value relative to [`RSMI_MAX_FAN_SPEED`](#).

Given a device index `dv_ind` and a pointer to a `uint32_t` `speed`, this function will write the current fan speed (a value between 0 and the maximum fan speed, [`RSMI_MAX_FAN_SPEED`](#)) to the `uint32_t` pointed to by `speed`

Parameters

in	<i>dv_ind</i>	a device index
in	<i>sensor_ind</i>	a 0-based sensor index. Normally, this will be 0. If a device has more than one sensor, it could be greater than 0.
in, out	<i>speed</i>	a pointer to <code>uint32_t</code> to which the speed will be written. If this parameter is nullptr, this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.

Return values

<i>RSMI_STATUS_SUCCESS</i>	call was successful
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function with the given arguments
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid

6.8.2.3 `rsmi_dev_fan_speed_max_get()`

```
rsmi_status_t rsmi_dev_fan_speed_max_get (
    uint32_t dv_ind,
    uint32_t sensor_ind,
    uint64_t * max_speed )
```

Get the max. fan speed of the device with provided device index.

Given a device index `dv_ind` and a pointer to a `uint32_t` `max_speed`, this function will write the maximum fan speed possible to the `uint32_t` pointed to by `max_speed`

Parameters

in	<i>dv_ind</i>	a device index
in	<i>sensor_ind</i>	a 0-based sensor index. Normally, this will be 0. If a device has more than one sensor, it could be greater than 0.
in, out	<i>max_speed</i>	a pointer to <code>uint32_t</code> to which the maximum speed will be written. If this parameter is <code>nullptr</code> , this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments
<code>RSMI_STATUS_INVALID_ARGS</code>	the provided arguments are not valid

6.8.2.4 `rsmi_dev_temp_metric_get()`

```
rsmi_status_t rsmi_dev_temp_metric_get (
    uint32_t dv_ind,
    uint32_t sensor_type,
    rsmi_temperature_metric_t metric,
    int64_t * temperature )
```

Get the temperature metric value for the specified metric, from the specified temperature sensor on the specified device.

Given a device index `dv_ind`, a sensor type `sensor_type`, a `rsmi_temperature_metric_t` `metric` and a pointer to an `int64_t` `temperature`, this function will write the value of the metric indicated by `metric` and `sensor_type` to the memory location `temperature`.

Parameters

in	<i>dv_ind</i>	a device index
in	<i>sensor_type</i>	part of device from which temperature should be obtained. This should come from the enum <code>rsmi_temperature_type_t</code>
in	<i>metric</i>	enum indicated which temperature value should be retrieved
in, out	<i>temperature</i>	a pointer to <code>int64_t</code> to which the temperature will be written, in millidegrees Celcius. If this parameter is <code>nullptr</code> , this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments

Return values

RSMI_STATUS_INVALID_ARGS	the provided arguments are not valid
--	--------------------------------------

6.8.2.5 rsmi_dev_volt_metric_get()

```
rsmi_status_t rsmi_dev_volt_metric_get (
    uint32_t dv_ind,
    rsmi_voltage_type_t sensor_type,
    rsmi_voltage_metric_t metric,
    int64_t * voltage )
```

Get the voltage metric value for the specified metric, from the specified voltage sensor on the specified device.

Given a device index `dv_ind`, a sensor type `sensor_type`, a [rsmi_voltage_metric_t](#) `metric` and a pointer to an `int64_t` `voltage`, this function will write the value of the metric indicated by `metric` and `sensor_type` to the memory location `voltage`.

Parameters

in	<code>dv_ind</code>	a device index
in	<code>sensor_type</code>	part of device from which voltage should be obtained. This should come from the enum rsmi_voltage_type_t
in	<code>metric</code>	enum indicated which voltage value should be retrieved
in, out	<code>voltage</code>	a pointer to <code>int64_t</code> to which the voltage will be written, in millivolts. If this parameter is <code>nullptr</code> , this function will return RSMI_STATUS_INVALID_ARGS if the function is supported with the provided, arguments and RSMI_STATUS_NOT_SUPPORTED if it is not supported with the provided arguments.

Return values

RSMI_STATUS_SUCCESS	call was successful
RSMI_STATUS_NOT_SUPPORTED	installed software or hardware does not support this function with the given arguments
RSMI_STATUS_INVALID_ARGS	the provided arguments are not valid

6.9 Physical State Control

These functions provide control over the physical state of a device.

Functions

- `rsmi_status_t rsmi_dev_fan_reset` (uint32_t dv_ind, uint32_t sensor_ind)
Reset the fan to automatic driver control.
- `rsmi_status_t rsmi_dev_fan_speed_set` (uint32_t dv_ind, uint32_t sensor_ind, uint64_t speed)
Set the fan speed for the specified device with the provided speed, in RPMs.

6.9.1 Detailed Description

These functions provide control over the physical state of a device.

6.9.2 Function Documentation

6.9.2.1 rsmi_dev_fan_reset()

```
rsmi_status_t rsmi_dev_fan_reset (
    uint32_t dv_ind,
    uint32_t sensor_ind )
```

Reset the fan to automatic driver control.

This function returns control of the fan to the system

Parameters

in	<code>dv_ind</code>	a device index
in	<code>sensor_ind</code>	a 0-based sensor index. Normally, this will be 0. If a device has more than one sensor, it could be greater than 0.

Return values

<code>RSMI_STATUS_SUCCESS</code>	is returned upon successful call.
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments

6.9.2.2 rsmi_dev_fan_speed_set()

```
rsmi_status_t rsmi_dev_fan_speed_set (
```

```
uint32_t dv_ind,  
uint32_t sensor_ind,  
uint64_t speed )
```

Set the fan speed for the specified device with the provided speed, in RPMs.

Given a device index `dv_ind` and a integer value indicating speed `speed`, this function will attempt to set the fan speed to `speed`. An error will be returned if the specified speed is outside the allowable range for the device. The maximum value is 255 and the minimum is 0.

Parameters

in	<i>dv_ind</i>	a device index
in	<i>sensor_ind</i>	a 0-based sensor index. Normally, this will be 0. If a device has more than one sensor, it could be greater than 0.
in	<i>speed</i>	the speed to which the function will attempt to set the fan

Return values

<i>RSMI_STATUS_SUCCESS</i>	is returned upon successful call.
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function with the given arguments
<i>RSMI_STATUS_PERMISSION</i>	function requires root access

6.10 Clock, Power and Performance Queries

These functions provide information about clock frequencies and performance.

Functions

- [rsmi_status_t rsmi_dev_busy_percent_get](#) (uint32_t dv_ind, uint32_t *busy_percent)
Get percentage of time device is busy doing any processing.
- [rsmi_status_t rsmi_utilization_count_get](#) (uint32_t dv_ind, [rsmi_utilization_counter_t](#) utilization_counters[], uint32_t count, uint64_t *timestamp)
Get coarse grain utilization counter of the specified device.
- [rsmi_status_t rsmi_dev_perf_level_get](#) (uint32_t dv_ind, [rsmi_dev_perf_level_t](#) *perf)
Get the performance level of the device with provided device index.
- [rsmi_status_t rsmi_perf_determinism_mode_set](#) (uint32_t dv_ind, uint64_t clkvalue)
Enter performance determinism mode with provided device index.
- [rsmi_status_t rsmi_dev_overdrive_level_get](#) (uint32_t dv_ind, uint32_t *od)
Get the overdrive percent associated with the device with provided device index.
- [rsmi_status_t rsmi_dev_mem_overdrive_level_get](#) (uint32_t dv_ind, uint32_t *od)
Get the memory clock overdrive percent associated with the device with provided device index.
- [rsmi_status_t rsmi_dev_gpu_clk_freq_get](#) (uint32_t dv_ind, [rsmi_clk_type_t](#) clk_type, [rsmi_frequencies_t](#) *f)
Get the list of possible system clock speeds of device for a specified clock type.
- [rsmi_status_t rsmi_dev_gpu_reset](#) (int32_t dv_ind)
Reset the gpu associated with the device with provided device index.
- [rsmi_status_t rsmi_dev_od_volt_info_get](#) (uint32_t dv_ind, [rsmi_od_volt_freq_data_t](#) *odv)
This function retrieves the voltage/frequency curve information.
- [rsmi_status_t rsmi_dev_gpu_metrics_info_get](#) (uint32_t dv_ind, [rsmi_gpu_metrics_t](#) *pgpu_metrics)
This function retrieves the gpu metrics information.
- [rsmi_status_t rsmi_dev_clk_range_set](#) (uint32_t dv_ind, uint64_t minclkvalue, uint64_t maxclkvalue, [rsmi_clk_type_t](#) clkType)
This function sets the clock range information.
- [rsmi_status_t rsmi_dev_od_clk_info_set](#) (uint32_t dv_ind, [rsmi_freq_ind_t](#) level, uint64_t clkvalue, [rsmi_clk_type_t](#) clkType)
This function sets the clock frequency information.
- [rsmi_status_t rsmi_dev_od_volt_info_set](#) (uint32_t dv_ind, uint32_t vpoint, uint64_t clkvalue, uint64_t volt-value)
This function sets 1 of the 3 voltage curve points.
- [rsmi_status_t rsmi_dev_od_volt_curve_regions_get](#) (uint32_t dv_ind, uint32_t *num_regions, [rsmi_freq_volt_region_t](#) *buffer)
This function will retrieve the current valid regions in the frequency/voltage space.
- [rsmi_status_t rsmi_dev_power_profile_presets_get](#) (uint32_t dv_ind, uint32_t sensor_ind, [rsmi_power_profile_status_t](#) *status)
Get the list of available preset power profiles and an indication of which profile is currently active.

6.10.1 Detailed Description

These functions provide information about clock frequencies and performance.

6.10.2 Function Documentation

6.10.2.1 `rsmi_dev_busy_percent_get()`

```
rsmi_status_t rsmi_dev_busy_percent_get (
    uint32_t dv_ind,
    uint32_t * busy_percent )
```

Get percentage of time device is busy doing any processing.

Given a device index `dv_ind`, this function returns the percentage of time that the specified device is busy. The device is considered busy if any one or more of its sub-blocks are working, and idle if none of the sub-blocks are working.

Parameters

in	<code>dv_ind</code>	a device index
in, out	<code>busy_percent</code>	a pointer to the <code>uint32_t</code> to which the busy percent will be written. If this parameter is nullptr, this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments
<code>RSMI_STATUS_INVALID_ARGS</code>	the provided arguments are not valid

6.10.2.2 `rsmi_utilization_count_get()`

```
rsmi_status_t rsmi_utilization_count_get (
    uint32_t dv_ind,
    rsmi_utilization_counter_t utilization_counters[],
    uint32_t count,
    uint64_t * timestamp )
```

Get coarse grain utilization counter of the specified device.

Given a device index `dv_ind`, the array of the utilization counters, the size of the array, this function returns the coarse grain utilization counters and timestamp. The counter is the accumulated percentages. Every milliseconds the firmware calculates % busy count and then accumulates that value in the counter. This provides minimally invasive coarse grain GPU usage information.

Parameters

in	<i>dv_ind</i>	a device index
in, out	<i>utilization_counters</i>	Multiple utilization counters can be retrieved with a single call. The caller must allocate enough space to the <i>utilization_counters</i> array. The caller also needs to set valid <code>RSMI_UTILIZATION_COUNTER_TYPE</code> type for each element of the array. <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.

If the function returns `RSMI_STATUS_SUCCESS`, the counter will be set in the *value* field of the `rsmi_utilization_counter_t`.

Parameters

in	<i>count</i>	The size of <i>@utilization_counters</i> array.
in, out	<i>timestamp</i>	The timestamp when the counter is retrieved. Resolution: 1 ns.

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments
<code>RSMI_STATUS_INVALID_ARGS</code>	the provided arguments are not valid

6.10.2.3 `rsmi_dev_perf_level_get()`

```
rsmi_status_t rsmi_dev_perf_level_get (
    uint32_t dv_ind,
    rsmi_dev_perf_level_t * perf )
```

Get the performance level of the device with provided device index.

Given a device index *dv_ind* and a pointer to a `uint32_t` *perf*, this function will write the `rsmi_dev_perf_level_t` to the `uint32_t` pointed to by *perf*

Parameters

in	<i>dv_ind</i>	a device index
in, out	<i>perf</i>	a pointer to <code>rsmi_dev_perf_level_t</code> to which the performance level will be written. If this parameter is <code>nullptr</code> , this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments

Return values

RSMI_STATUS_INVALID_ARGS	the provided arguments are not valid
--	--------------------------------------

6.10.2.4 `rsmi_perf_determinism_mode_set()`

```
rsmi_status_t rsmi_perf_determinism_mode_set (
    uint32_t dv_ind,
    uint64_t clkvalue )
```

Enter performance determinism mode with provided device index.

Given a device index `dv_ind` and `clkvalue` this function will enable performance determinism mode, which enforces a GFXCLK frequency SoftMax limit per GPU set by the user. This prevents the GFXCLK PLL from stretching when running the same workload on different GPUS, making performance variation minimal. This call will result in the performance level `rsmi_dev_perf_level_t` of the device being `RSMI_DEV_PERF_LEVEL_DETERMINISM`.

Parameters

in	<code>dv_ind</code>	a device index
in	<code>clkvalue</code>	Softmax value for GFXCLK in MHz.

Return values

RSMI_STATUS_SUCCESS	call was successful
RSMI_STATUS_NOT_SUPPORTED	installed software or hardware does not support this function with the given arguments
RSMI_STATUS_INVALID_ARGS	the provided arguments are not valid

6.10.2.5 `rsmi_dev_overdrive_level_get()`

```
rsmi_status_t rsmi_dev_overdrive_level_get (
    uint32_t dv_ind,
    uint32_t * od )
```

Get the overdrive percent associated with the device with provided device index.

Given a device index `dv_ind` and a pointer to a `uint32_t od`, this function will write the overdrive percentage to the `uint32_t` pointed to by `od`

Parameters

in	<code>dv_ind</code>	a device index
in, out	<code>od</code>	a pointer to <code>uint32_t</code> to which the overdrive percentage will be written. If this parameter is nullptr, this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.

Return values

<i>RSMI_STATUS_SUCCESS</i>	call was successful
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function with the given arguments
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid

6.10.2.6 rsmi_dev_mem_overdrive_level_get()

```
rsmi_status_t rsmi_dev_mem_overdrive_level_get (
    uint32_t dv_ind,
    uint32_t * od )
```

Get the memory clock overdrive percent associated with the device with provided device index.

Given a device index `dv_ind` and a pointer to a `uint32_t` `od`, this function will write the memory overdrive percentage to the `uint32_t` pointed to by `od`

Parameters

<code>in</code>	<code>dv_ind</code>	a device index
<code>in, out</code>	<code>od</code>	a pointer to <code>uint32_t</code> to which the overdrive percentage will be written. If this parameter is <code>nullptr</code> , this function will return <i>RSMI_STATUS_INVALID_ARGS</i> if the function is not supported with the provided arguments and <i>RSMI_STATUS_NOT_SUPPORTED</i> if it is not supported with the provided arguments.

Return values

<i>RSMI_STATUS_SUCCESS</i>	call was successful
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function with the given arguments
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid

6.10.2.7 rsmi_dev_gpu_clk_freq_get()

```
rsmi_status_t rsmi_dev_gpu_clk_freq_get (
    uint32_t dv_ind,
    rsmi_clk_type_t clk_type,
    rsmi_frequencies_t * f )
```

Get the list of possible system clock speeds of device for a specified clock type.

Given a device index `dv_ind`, a clock type `clk_type`, and a pointer to a `rsmi_frequencies_t` structure `f`, this function will fill in `f` with the possible clock speeds, and indication of the current clock speed selection.

Parameters

in	<i>dv_ind</i>	a device index
in	<i>clk_type</i>	the type of clock for which the frequency is desired
in, out	<i>f</i>	a pointer to a caller provided <code>rsmi_frequencies_t</code> structure to which the frequency information will be written. Frequency values are in Hz. If this parameter is nullptr, this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments. If multiple current frequencies are found, a warning is shown. If no current frequency is found, it is reflected as -1. If frequencies are not read from low to high a warning is shown as well.

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments
<code>RSMI_STATUS_INVALID_ARGS</code>	the provided arguments are not valid

6.10.2.8 `rsmi_dev_gpu_reset()`

```
rsmi_status_t rsmi_dev_gpu_reset (
    int32_t dv_ind )
```

Reset the gpu associated with the device with provided device index.

Given a device index `dv_ind`, this function will reset the GPU

Parameters

in	<i>dv_ind</i>	a device index
----	---------------	----------------

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments
<code>RSMI_STATUS_INVALID_ARGS</code>	the provided arguments are not valid

6.10.2.9 `rsmi_dev_od_volt_info_get()`

```
rsmi_status_t rsmi_dev_od_volt_info_get (
    uint32_t dv_ind,
    rsmi_od_volt_freq_data_t * odv )
```

This function retrieves the voltage/frequency curve information.

Given a device index `dv_ind` and a pointer to a `rsmi_od_volt_freq_data_t` structure `odv`, this function will populate `odv`. See `rsmi_od_volt_freq_data_t` for more details.

Parameters

in	<code>dv_ind</code>	a device index
in, out	<code>odv</code>	a pointer to an <code>rsmi_od_volt_freq_data_t</code> structure. If this parameter is nullptr, this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments
<code>RSMI_STATUS_INVALID_ARGS</code>	the provided arguments are not valid

6.10.2.10 `rsmi_dev_gpu_metrics_info_get()`

```
rsmi_status_t rsmi_dev_gpu_metrics_info_get (
    uint32_t dv_ind,
    rsmi_gpu_metrics_t * pgpu_metrics )
```

This function retrieves the gpu metrics information.

Given a device index `dv_ind` and a pointer to a `rsmi_gpu_metrics_t` structure `pgpu_metrics`, this function will populate `pgpu_metrics`. See `rsmi_gpu_metrics_t` for more details.

Parameters

in	<code>dv_ind</code>	a device index
in, out	<code>pgpu_metrics</code>	a pointer to an <code>rsmi_gpu_metrics_t</code> structure. If this parameter is nullptr, this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments
<code>RSMI_STATUS_INVALID_ARGS</code>	the provided arguments are not valid

6.10.2.11 `rsmi_dev_clk_range_set()`

```
rsmi_status_t rsmi_dev_clk_range_set (
    uint32_t dv_ind,
    uint64_t minclkvalue,
    uint64_t maxclkvalue,
    rsmi_clk_type_t clkType )
```

This function sets the clock range information.

Given a device index `dv_ind`, a minimum clock value `minclkvalue`, a maximum clock value `maxclkvalue` and a clock type `clkType` this function will set the `sclk|mclk` range

Parameters

in	<code>dv_ind</code>	a device index
in	<code>minclkvalue</code>	value to apply to the clock range. Frequency values are in MHz.
in	<code>maxclkvalue</code>	value to apply to the clock range. Frequency values are in MHz.
in	<code>clkType</code>	RSMI_CLK_TYPE_SYS RSMI_CLK_TYPE_MEM range type

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments
<code>RSMI_STATUS_INVALID_ARGS</code>	the provided arguments are not valid

6.10.2.12 `rsmi_dev_od_clk_info_set()`

```
rsmi_status_t rsmi_dev_od_clk_info_set (
    uint32_t dv_ind,
    rsmi_freq_ind_t level,
    uint64_t clkvalue,
    rsmi_clk_type_t clkType )
```

This function sets the clock frequency information.

Given a device index `dv_ind`, a frequency level `level`, a clock value `clkvalue` and a clock type `clkType` this function will set the `sclk|mclk` range

Parameters

in	<code>dv_ind</code>	a device index
in	<code>level</code>	RSMI_FREQ_IND_MIN RSMI_FREQ_IND_MAX to set the minimum (0) or maximum (1) speed.
in	<code>clkvalue</code>	value to apply to the clock range. Frequency values are in MHz.
in	<code>clkType</code>	RSMI_CLK_TYPE_SYS RSMI_CLK_TYPE_MEM range type

Return values

<i>RSMI_STATUS_SUCCESS</i>	call was successful
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function with the given arguments
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid

6.10.2.13 rsmi_dev_od_volt_info_set()

```
rsmi_status_t rsmi_dev_od_volt_info_set (
    uint32_t dv_ind,
    uint32_t vpoint,
    uint64_t clkvalue,
    uint64_t voltvalue )
```

This function sets 1 of the 3 voltage curve points.

Given a device index `dv_ind`, a voltage point `vpoint` and a voltage value `voltvalue` this function will set voltage curve point

Parameters

in	<i>dv_ind</i>	a device index
in	<i>vpoint</i>	voltage point [0 1 2] on the voltage curve
in	<i>clkvalue</i>	clock value component of voltage curve point. Frequency values are in MHz.
in	<i>voltvalue</i>	voltage value component of voltage curve point. Voltage is in mV.

Return values

<i>RSMI_STATUS_SUCCESS</i>	call was successful
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function with the given arguments
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid

6.10.2.14 rsmi_dev_od_volt_curve_regions_get()

```
rsmi_status_t rsmi_dev_od_volt_curve_regions_get (
    uint32_t dv_ind,
    uint32_t * num_regions,
    rsmi_freq_volt_region_t * buffer )
```

This function will retrieve the current valid regions in the frequency/voltage space.

Given a device index `dv_ind`, a pointer to an unsigned integer `num_regions` and a buffer of [`rsmi_freq_volt_region_t`](#) structures, `buffer`, this function will populate `buffer` with the current frequency-volt space regions. The caller should assign `buffer` to memory that can be written to by this function. The caller

should also indicate the number of `rsmi_freq_volt_region_t` structures that can safely be written to `buffer` in `num_regions`.

The number of regions to expect this function provide (`num_regions`) can be obtained by calling `rsmi_dev_od_volt_info_get()`.

Parameters

<code>in</code>	<code>dv_ind</code>	a device index
<code>in, out</code>	<code>num_regions</code>	As input, this is the number of <code>rsmi_freq_volt_region_t</code> structures that can be written to <code>buffer</code> . As output, this is the number of <code>rsmi_freq_volt_region_t</code> structures that were actually written. If this parameter is <code>nullptr</code> , this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided, arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.
<code>in, out</code>	<code>buffer</code>	a caller provided buffer to which <code>rsmi_freq_volt_region_t</code> structures will be written. If this parameter is <code>nullptr</code> , this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided, arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments
<code>RSMI_STATUS_INVALID_ARGS</code>	the provided arguments are not valid

6.10.2.15 `rsmi_dev_power_profile_presets_get()`

```
rsmi_status_t rsmi_dev_power_profile_presets_get (
    uint32_t dv_ind,
    uint32_t sensor_ind,
    rsmi_power_profile_status_t * status )
```

Get the list of available preset power profiles and an indication of which profile is currently active.

Given a device index `dv_ind` and a pointer to a `rsmi_power_profile_status_t` `status`, this function will set the bits of the `rsmi_power_profile_status_t.available_profiles` bit field of `status` to 1 if the profile corresponding to the respective `rsmi_power_profile_preset_masks_t` profiles are enabled. For example, if both the VID↔EO and VR power profiles are available selections, then `RSMI_PWR_PROF_PRST_VIDEO_MASK` AND'ed with `rsmi_power_profile_status_t.available_profiles` will be non-zero as will `RSMI_PWR_PROF_PRST_VR_MASK` AND'ed with `rsmi_power_profile_status_t.available_profiles`. Additionally, `rsmi_power_profile_status_t.current` will be set to the `rsmi_power_profile_preset_masks_t` of the profile that is currently active.

Parameters

<code>in</code>	<code>dv_ind</code>	a device index
<code>in</code>	<code>sensor_ind</code>	a 0-based sensor index. Normally, this will be 0. If a device has more than one sensor, it could be greater than 0.
<code>in, out</code>	<code>status</code>	a pointer to <code>rsmi_power_profile_status_t</code> that will be populated by a call to this function. If this parameter is <code>nullptr</code> , this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided, arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.
Generated by Doxygen		

Return values

<i>RSMI_STATUS_SUCCESS</i>	call was successful
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function with the given arguments
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid

6.11 Clock, Power and Performance Control

These functions provide control over clock frequencies, power and performance.

Functions

- [rsmi_status_t rsmi_dev_perf_level_set](#) (int32_t dv_ind, [rsmi_dev_perf_level_t](#) perf_lvl)
Set the PowerPlay performance level associated with the device with provided device index with the provided value.
- [rsmi_status_t rsmi_dev_perf_level_set_v1](#) (uint32_t dv_ind, [rsmi_dev_perf_level_t](#) perf_lvl)
Set the PowerPlay performance level associated with the device with provided device index with the provided value.
- [rsmi_status_t rsmi_dev_overdrive_level_set](#) (int32_t dv_ind, uint32_t od)
Set the overdrive percent associated with the device with provided device index with the provided value. See details for WARNING.
- [rsmi_status_t rsmi_dev_overdrive_level_set_v1](#) (uint32_t dv_ind, uint32_t od)
Set the overdrive percent associated with the device with provided device index with the provided value. See details for WARNING.
- [rsmi_status_t rsmi_dev_gpu_clk_freq_set](#) (uint32_t dv_ind, [rsmi_clk_type_t](#) clk_type, uint64_t freq_bitmask)
Control the set of allowed frequencies that can be used for the specified clock.

6.11.1 Detailed Description

These functions provide control over clock frequencies, power and performance.

6.11.2 Function Documentation

6.11.2.1 rsmi_dev_perf_level_set()

```
rsmi_status_t rsmi_dev_perf_level_set (
    int32_t dv_ind,
    rsmi_dev_perf_level_t perf_lvl )
```

Set the PowerPlay performance level associated with the device with provided device index with the provided value.

Deprecated [rsmi_dev_perf_level_set_v1\(\)](#) is preferred, with an interface that more closely matches the rest of the rocm_smi API.

Given a device index `dv_ind` and an [rsmi_dev_perf_level_t](#) `perf_level`, this function will set the PowerPlay performance level for the device to the value `perf_lvl`.

Parameters

in	<code>dv_ind</code>	a device index
in	<code>perf_lvl</code>	the value to which the performance level should be set

Return values

<i>RSMI_STATUS_SUCCESS</i>	is returned upon successful call.
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function with the given arguments
<i>RSMI_STATUS_PERMISSION</i>	function requires root access

6.11.2.2 `rsmi_dev_perf_level_set_v1()`

```
rsmi_status_t rsmi_dev_perf_level_set_v1 (
    uint32_t dv_ind,
    rsmi_dev_perf_level_t perf_lvl )
```

Set the PowerPlay performance level associated with the device with provided device index with the provided value.

Given a device index `dv_ind` and an [`rsmi_dev_perf_level_t`](#) `perf_level`, this function will set the PowerPlay performance level for the device to the value `perf_lvl`.

Parameters

in	<i>dv_ind</i>	a device index
in	<i>perf_↔ _lvl</i>	the value to which the performance level should be set

Return values

<i>RSMI_STATUS_SUCCESS</i>	is returned upon successful call.
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function with the given arguments
<i>RSMI_STATUS_PERMISSION</i>	function requires root access

6.11.2.3 `rsmi_dev_overdrive_level_set()`

```
rsmi_status_t rsmi_dev_overdrive_level_set (
    int32_t dv_ind,
    uint32_t od )
```

Set the overdrive percent associated with the device with provided device index with the provided value. See details for WARNING.

Deprecated This function is deprecated. [`rsmi_dev_overdrive_level_set_v1`](#) has the same functionality, with an interface that more closely matches the rest of the `rocm_smi` API.

Given a device index `dv_ind` and an overdrive level `od`, this function will set the overdrive level for the device to the value `od`. The overdrive level is an integer value between 0 and 20, inclusive, which represents the overdrive percentage; e.g., a value of 5 specifies an overclocking of 5%.

The overdrive level is specific to the gpu system clock.

The overdrive level is the percentage above the maximum Performance Level to which overclocking will be limited. The overclocking percentage does not apply to clock speeds other than the maximum. This percentage is limited to 20%.

*****WARNING***** Operating your AMD GPU outside of official AMD specifications or outside of factory settings, including but not limited to the conducting of overclocking (including use of this overclocking software, even if such software has been directly or indirectly provided by AMD or otherwise affiliated in any way with AMD), may cause damage to your AMD GPU, system components and/or result in system failure, as well as cause other problems. DAMAGES CAUSED BY USE OF YOUR AMD GPU OUTSIDE OF OFFICIAL AMD SPECIFICATIONS OR OUTSIDE OF FACTORY SETTINGS ARE NOT COVERED UNDER ANY AMD PRODUCT WARRANTY AND MAY NOT BE COVERED BY YOUR BOARD OR SYSTEM MANUFACTURER'S WARRANTY. Please use this utility with caution.

Parameters

in	<code>dv_ind</code>	a device index
in	<code>od</code>	the value to which the overdrive level should be set

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments
<code>RSMI_STATUS_PERMISSION</code>	function requires root access

6.11.2.4 `rsmi_dev_overdrive_level_set_v1()`

```
rsmi_status_t rsmi_dev_overdrive_level_set_v1 (
    uint32_t dv_ind,
    uint32_t od )
```

Set the overdrive percent associated with the device with provided device index with the provided value. See details for WARNING.

Given a device index `dv_ind` and an overdrive level `od`, this function will set the overdrive level for the device to the value `od`. The overdrive level is an integer value between 0 and 20, inclusive, which represents the overdrive percentage; e.g., a value of 5 specifies an overclocking of 5%.

The overdrive level is specific to the gpu system clock.

The overdrive level is the percentage above the maximum Performance Level to which overclocking will be limited. The overclocking percentage does not apply to clock speeds other than the maximum. This percentage is limited to 20%.

*****WARNING***** Operating your AMD GPU outside of official AMD specifications or outside of factory settings, including but not limited to the conducting of overclocking (including use of this overclocking software,

even if such software has been directly or indirectly provided by AMD or otherwise affiliated in any way with AMD), may cause damage to your AMD GPU, system components and/or result in system failure, as well as cause other problems. DAMAGES CAUSED BY USE OF YOUR AMD GPU OUTSIDE OF OFFICIAL AMD SPECIFICATIONS OR OUTSIDE OF FACTORY SETTINGS ARE NOT COVERED UNDER ANY AMD PRODUCT WARRANTY AND MAY NOT BE COVERED BY YOUR BOARD OR SYSTEM MANUFACTURER'S WARRANTY. Please use this utility with caution.

Parameters

in	<i>dv_ind</i>	a device index
in	<i>od</i>	the value to which the overdrive level should be set

Return values

<i>RSMI_STATUS_SUCCESS</i>	call was successful
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function with the given arguments
<i>RSMI_STATUS_PERMISSION</i>	function requires root access

6.11.2.5 rsmi_dev_gpu_clk_freq_set()

```
rsmi_status_t rsmi_dev_gpu_clk_freq_set (
    uint32_t dv_ind,
    rsmi_clk_type_t clk_type,
    uint64_t freq_bitmask )
```

Control the set of allowed frequencies that can be used for the specified clock.

Given a device index *dv_ind*, a clock type *clk_type*, and a 64 bit bitmask *freq_bitmask*, this function will limit the set of allowable frequencies. If a bit in *freq_bitmask* has a value of 1, then the frequency (as ordered in an [*rsmi_frequencies_t*](#) returned by [*rsmi_dev_gpu_clk_freq_get\(\)*](#)) corresponding to that bit index will be allowed.

This function will change the performance level to [*RSMI_DEV_PERF_LEVEL_MANUAL*](#) in order to modify the set of allowable frequencies. Caller will need to set to [*RSMI_DEV_PERF_LEVEL_AUTO*](#) in order to get back to default state.

All bits with indices greater than or equal to [*rsmi_frequencies_t::num_supported*](#) will be ignored.

Parameters

in	<i>dv_ind</i>	a device index
in	<i>clk_type</i>	the type of clock for which the set of frequencies will be modified
in	<i>freq_bitmask</i>	A bitmask indicating the indices of the frequencies that are to be enabled (1) and disabled (0). Only the lowest <i>rsmi_frequencies_t.num_supported</i> bits of this mask are relevant.

Return values

<i>RSMI_STATUS_SUCCESS</i>	is returned upon successful call.
--	-----------------------------------

Return values

<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function with the given arguments
<i>RSMI_STATUS_PERMISSION</i>	function requires root access

6.12 Version Queries

These functions provide version information about various subsystems.

Functions

- [rsmi_status_t rsmi_version_get](#) ([rsmi_version_t](#) *version)
Get the build version information for the currently running build of RSMI.
- [rsmi_status_t rsmi_version_str_get](#) ([rsmi_sw_component_t](#) component, char *ver_str, uint32_t len)
Get the driver version string for the current system.
- [rsmi_status_t rsmi_dev_vbios_version_get](#) (uint32_t dv_ind, char *vbios, uint32_t len)
Get the VBIOS identifier string.
- [rsmi_status_t rsmi_dev_firmware_version_get](#) (uint32_t dv_ind, [rsmi_fw_block_t](#) block, uint64_t *fw_version)
Get the firmware versions for a device.

6.12.1 Detailed Description

These functions provide version information about various subsystems.

6.12.2 Function Documentation

6.12.2.1 rsmi_version_get()

```
rsmi_status_t rsmi_version_get (
    rsmi_version_t * version )
```

Get the build version information for the currently running build of RSMI.

Get the major, minor, patch and build string for RSMI build currently in use through `version`

Parameters

<code>in, out</code>	<code>version</code>	A pointer to an rsmi_version_t structure that will be updated with the version information upon return.
----------------------	----------------------	---

Return values

RSMI_STATUS_SUCCESS	is returned upon successful call
-------------------------------------	----------------------------------

6.12.2.2 rsmi_version_str_get()

```
rsmi_status_t rsmi_version_str_get (
```



```

rsmi_sw_component_t component,
char * ver_str,
uint32_t len )

```

Get the driver version string for the current system.

Given a software component `component`, a pointer to a char buffer, `ver_str`, this function will write the driver version string (up to `len` characters) for the current system to `ver_str`. The caller must ensure that it is safe to write at least `len` characters to `ver_str`.

Parameters

in	<code>component</code>	The component for which the version string is being requested
in, out	<code>ver_str</code>	A pointer to a buffer of char's to which the version of <code>component</code> will be written
in	<code>len</code>	the length of the caller provided buffer name.

Return values

<i>RSMI_STATUS_SUCCESS</i>	call was successful
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function with the given arguments
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid
<i>RSMI_STATUS_INSUFFICIENT_SIZE</i>	is returned if <code>len</code> bytes is not large enough to hold the entire name. In this case, only <code>len</code> bytes will be written.

6.12.2.3 rsmi_dev_vbios_version_get()

```

rsmi_status_t rsmi_dev_vbios_version_get (
    uint32_t dv_ind,
    char * vbios,
    uint32_t len )

```

Get the VBIOS identifier string.

Given a device ID `dv_ind`, and a pointer to a char buffer, `vbios`, this function will write the VBIOS string (up to `len` characters) for device `dv_ind` to `vbios`. The caller must ensure that it is safe to write at least `len` characters to `vbios`.

Parameters

in	<code>dv_ind</code>	a device index
in, out	<code>vbios</code>	A pointer to a buffer of char's to which the VBIOS name will be written. If this parameter is nullptr, this function will return <i>RSMI_STATUS_INVALID_ARGS</i> if the function is supported with the provided arguments and <i>RSMI_STATUS_NOT_SUPPORTED</i> if it is not supported with the provided arguments.
in	<code>len</code>	The number of char's pointed to by <code>vbios</code> which can safely be written to by this function.

Return values

<i>RSMI_STATUS_SUCCESS</i>	call was successful
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function with the given arguments
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid

6.12.2.4 `rsmi_dev_firmware_version_get()`

```
rsmi_status_t rsmi_dev_firmware_version_get (
    uint32_t dv_ind,
    rsmi_fw_block_t block,
    uint64_t * fw_version )
```

Get the firmware versions for a device.

Given a device ID `dv_ind`, and a pointer to a `uint64_t`, `fw_version`, this function will write the FW Versions as a string (up to `len` characters) for device `dv_ind` to `vbios`. The caller must ensure that it is safe to write at least `len` characters to `vbios`.

Parameters

in	<i>dv_ind</i>	a device index
in	<i>block</i>	The firmware block for which the version is being requested
in, out	<i>fw_version</i>	The version for the firmware block If this parameter is nullptr, this function will return <i>RSMI_STATUS_INVALID_ARGS</i> if the function is supported with the provided, arguments and <i>RSMI_STATUS_NOT_SUPPORTED</i> if it is not supported with the provided arguments.

Return values

<i>RSMI_STATUS_SUCCESS</i>	call was successful
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function with the given arguments
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid

6.13 Error Queries

These functions provide error information about RSMI calls as well as device errors.

Functions

- `rsmi_status_t rsmi_dev_ecc_count_get` (`uint32_t dv_ind`, `rsmi_gpu_block_t block`, `rsmi_error_count_t *ec`)
Retrieve the error counts for a GPU block.
- `rsmi_status_t rsmi_dev_ecc_enabled_get` (`uint32_t dv_ind`, `uint64_t *enabled_blocks`)
Retrieve the enabled ECC bit-mask.
- `rsmi_status_t rsmi_dev_ecc_status_get` (`uint32_t dv_ind`, `rsmi_gpu_block_t block`, `rsmi_ras_err_state_t *state`)
Retrieve the ECC status for a GPU block.
- `rsmi_status_t rsmi_status_string` (`rsmi_status_t status`, `const char **status_string`)
Get a description of a provided RSMI error status.

6.13.1 Detailed Description

These functions provide error information about RSMI calls as well as device errors.

6.13.2 Function Documentation

6.13.2.1 `rsmi_dev_ecc_count_get()`

```
rsmi_status_t rsmi_dev_ecc_count_get (
    uint32_t dv_ind,
    rsmi_gpu_block_t block,
    rsmi_error_count_t * ec )
```

Retrieve the error counts for a GPU block.

Given a device index `dv_ind`, an `rsmi_gpu_block_t` `block` and a pointer to an `rsmi_error_count_t` `ec`, this function will write the error count values for the GPU block indicated by `block` to memory pointed to by `ec`.

Parameters

in	<code>dv_ind</code>	a device index
in	<code>block</code>	The block for which error counts should be retrieved
in, out	<code>ec</code>	A pointer to an <code>rsmi_error_count_t</code> to which the error counts should be written. If this parameter is nullptr, this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.

Return values

<i>RSMI_STATUS_SUCCESS</i>	call was successful
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function with the given arguments
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid

6.13.2.2 rsmi_dev_ecc_enabled_get()

```
rsmi_status_t rsmi_dev_ecc_enabled_get (
    uint32_t dv_ind,
    uint64_t * enabled_blocks )
```

Retrieve the enabled ECC bit-mask.

Given a device index `dv_ind`, and a pointer to a `uint64_t` `enabled_mask`, this function will write bits to memory pointed to by `enabled_blocks`. Upon a successful call, `enabled_blocks` can then be AND'd with elements of the `rsmi_gpu_block_t` enumeration to determine if the corresponding block has ECC enabled. Note that whether a block has ECC enabled or not in the device is independent of whether there is kernel support for error counting for that block. Although a block may be enabled, but there may not be kernel support for reading error counters for that block.

Parameters

in	<i>dv_ind</i>	a device index
in, out	<i>enabled_blocks</i>	A pointer to a <code>uint64_t</code> to which the enabled blocks bits will be written. If this parameter is <code>nullptr</code> , this function will return <i>RSMI_STATUS_INVALID_ARGS</i> if the function is supported with the provided arguments and <i>RSMI_STATUS_NOT_SUPPORTED</i> if it is not supported with the provided arguments.

Return values

<i>RSMI_STATUS_SUCCESS</i>	call was successful
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function with the given arguments
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid

6.13.2.3 rsmi_dev_ecc_status_get()

```
rsmi_status_t rsmi_dev_ecc_status_get (
    uint32_t dv_ind,
    rsmi_gpu_block_t block,
    rsmi_ras_err_state_t * state )
```

Retrieve the ECC status for a GPU block.

Given a device index `dv_ind`, an `rsmi_gpu_block_t` `block` and a pointer to an `rsmi_ras_err_state_t` `state`, this function will write the current state for the GPU block indicated by `block` to memory pointed to by `state`.

Parameters

in	<i>dv_ind</i>	a device index
in	<i>block</i>	The block for which error counts should be retrieved
in, out	<i>state</i>	A pointer to an rsmi_ras_err_state_t to which the ECC state should be written. If this parameter is nullptr, this function will return RSMI_STATUS_INVALID_ARGS if the function is supported with the provided arguments and RSMI_STATUS_NOT_SUPPORTED if it is not supported with the provided arguments.

Return values

RSMI_STATUS_SUCCESS	call was successful
RSMI_STATUS_NOT_SUPPORTED	installed software or hardware does not support this function with the given arguments
RSMI_STATUS_INVALID_ARGS	the provided arguments are not valid

6.13.2.4 `rsmi_status_string()`

```
rsmi_status_t rsmi_status_string (
    rsmi_status_t status,
    const char ** status_string )
```

Get a description of a provided RSMI error status.

Set the provided pointer to a const char *, `status_string`, to a string containing a description of the provided error code `status`.

Parameters

in	<i>status</i>	The error status for which a description is desired
in, out	<i>status_string</i>	A pointer to a const char * which will be made to point to a description of the provided error code

Return values

RSMI_STATUS_SUCCESS	is returned upon successful call
-------------------------------------	----------------------------------

6.14 Performance Counter Functions

These functions are used to configure, query and control performance counting.

Functions

- [rsmi_status_t rsmi_dev_counter_group_supported](#) (uint32_t dv_ind, rsmi_event_group_t group)
Tell if an event group is supported by a given device.
- [rsmi_status_t rsmi_dev_counter_create](#) (uint32_t dv_ind, rsmi_event_type_t type, rsmi_event_handle_t *evnt_handle)
Create a performance counter object.
- [rsmi_status_t rsmi_dev_counter_destroy](#) (rsmi_event_handle_t evnt_handle)
Deallocate a performance counter object.
- [rsmi_status_t rsmi_counter_control](#) (rsmi_event_handle_t evt_handle, rsmi_counter_command_t cmd, void *cmd_args)
Issue performance counter control commands.
- [rsmi_status_t rsmi_counter_read](#) (rsmi_event_handle_t evt_handle, rsmi_counter_value_t *value)
Read the current value of a performance counter.
- [rsmi_status_t rsmi_counter_available_counters_get](#) (uint32_t dv_ind, rsmi_event_group_t grp, uint32_t *available)
Get the number of currently available counters.

6.14.1 Detailed Description

These functions are used to configure, query and control performance counting.

These functions use the same mechanisms as the "perf" command line utility. They share the same underlying resources and have some similarities in how they are used. The events supported by this API should have corresponding perf events that can be seen with "perf stat ...". The events supported by perf can be seen with "perf list"

The types of events available and the ability to count those events are dependent on which device is being targeted and if counters are still available for that device, respectively. [rsmi_dev_counter_group_supported\(\)](#) can be used to see which event types ([rsmi_event_group_t](#)) are supported for a given device. Assuming a device supports a given event type, we can then check to see if there are counters available to count a specific event with [rsmi_counter_available_counters_get\(\)](#). Counters may be occupied by other perf based programs.

Once it is determined that events are supported and counters are available, an event counter can be created/destroyed and controlled.

[rsmi_dev_counter_create\(\)](#) allocates internal data structures that will be used to control the event counter, and return a handle to this data structure.

Once an event counter handle is obtained, the event counter can be controlled (i.e., started, stopped,...) with [rsmi_counter_control\(\)](#) by passing [rsmi_counter_command_t](#) commands. [RSMI_CNTR_CMD_START](#) starts an event counter and [RSMI_CNTR_CMD_STOP](#) stops a counter. [rsmi_counter_read\(\)](#) reads an event counter.

Once the counter is no longer needed, the resources it uses should be freed by calling [rsmi_dev_counter_destroy\(\)](#).

6.14.2 Important Notes about Counter Values

- A running "absolute" counter is kept internally. For the discussion that follows, we will call the internal counter value at time t val_t
- Issuing [RSMI_CNTR_CMD_START](#) or calling [rsmi_counter_read\(\)](#), causes RSMI (in kernel) to internally record the current absolute counter value
- [rsmi_counter_read\(\)](#) returns the number of events that have occurred since the previously recorded value (ie, a relative value, $val_t - val_{t-1}$) from the issuing of [RSMI_CNTR_CMD_START](#) or calling [rsmi_counter_read\(\)](#)

Example of event counting sequence:

```

rsmi_counter_value_t value;
// Determine if RSMI_EVNT_GRP_XGMI is supported for device dv_ind
ret = rsmi_dev_counter_group_supported(dv_ind, RSMI_EVNT_GRP_XGMI);
// See if there are counters available for device dv_ind for event
// RSMI_EVNT_GRP_XGMI
ret = rsmi_counter_available_counters_get(dv_ind,
                                         RSMI_EVNT_GRP_XGMI, &counters_available);
// Assuming RSMI_EVNT_GRP_XGMI is supported and there is at least 1
// counter available for RSMI_EVNT_GRP_XGMI on device dv_ind, create
// an event object for an event of group RSMI_EVNT_GRP_XGMI (e.g.,
// RSMI_EVNT_XGMI_0_BEATS_TX) and get the handle
// (rsmi_event_handle_t).
ret = rsmi_dev_counter_create(dv_ind, RSMI_EVNT_XGMI_0_BEATS_TX,
                              &evnt_handle);
// A program that generates the events of interest can be started
// immediately before or after starting the counters.
// Start counting:
ret = rsmi_counter_control(evnt_handle, RSMI_CNTR_CMD_START, NULL);
// Wait...
// Get the number of events since RSMI_CNTR_CMD_START was issued:
ret = rsmi_counter_read(rsmi_event_handle_t evt_handle, &value)
// Wait...
// Get the number of events since rsmi_counter_read() was last called:
ret = rsmi_counter_read(rsmi_event_handle_t evt_handle, &value)
// Stop counting.
ret = rsmi_counter_control(evnt_handle, RSMI_CNTR_CMD_STOP, NULL);
// Release all resources (e.g., counter and memory resources) associated
// with evnt_handle.
ret = rsmi_dev_counter_destroy(evnt_handle);

```

6.14.3 Function Documentation

6.14.3.1 rsmi_dev_counter_group_supported()

```

rsmi_status_t rsmi_dev_counter_group_supported (
    uint32_t dv_ind,
    rsmi_event_group_t group )

```

Tell if an event group is supported by a given device.

Given a device index `dv_ind` and an event group specifier `group`, tell if `group` type events are supported by the device associated with `dv_ind`

Parameters

in	<code>dv_ind</code>	device index of device being queried
in	<code>group</code>	<code>rsmi_event_group_t</code> identifier of group for which support is being queried

Return values

<code>RSMI_STATUS_SUCCESS</code>	if the device associatee with <code>dv_ind</code> support counting events of the type indicated by <code>group</code> .
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments <code>group</code>

6.14.3.2 `rsmi_dev_counter_create()`

```
rsmi_status_t rsmi_dev_counter_create (
    uint32_t dv_ind,
    rsmi_event_type_t type,
    rsmi_event_handle_t * evnt_handle )
```

Create a performance counter object.

Create a performance counter object of type `type` for the device with a device index of `dv_ind`, and write a handle to the object to the memory location pointed to by `evnt_handle`. `evnt_handle` can be used with other performance event operations. The handle should be deallocated with `rsmi_dev_counter_destroy()` when no longer needed.

Parameters

in	<code>dv_ind</code>	a device index
in	<code>type</code>	the <code>rsmi_event_type_t</code> of performance event to create
in, out	<code>evnt_handle</code>	A pointer to a <code>rsmi_event_handle_t</code> which will be associated with a newly allocated counter. If this parameter is nullptr, this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments
<code>RSMI_STATUS_INVALID_ARGS</code>	the provided arguments are not valid
<code>RSMI_STATUS_OUT_OF_RESOURCES</code>	unable to allocate memory for counter
<code>RSMI_STATUS_PERMISSION</code>	function requires root access

6.14.3.3 `rsmi_dev_counter_destroy()`

```
rsmi_status_t rsmi_dev_counter_destroy (
    rsmi_event_handle_t evnt_handle )
```

Deallocate a performance counter object.

Deallocate the performance counter object with the provided `rsmi_event_handle_t` `evnt_handle`

Parameters

in	<code>evnt_handle</code>	handle to event object to be deallocated
----	--------------------------	--

Return values

<code>RSMI_STATUS_SUCCESS</code>	is returned upon successful call
----------------------------------	----------------------------------

Return values

RSMI_STATUS_INVALID_ARGS	the provided arguments are not valid
RSMI_STATUS_PERMISSION	function requires root access

6.14.3.4 rsmi_counter_control()

```
rsmi_status_t rsmi_counter_control (
    rsmi_event_handle_t evt_handle,
    rsmi_counter_command_t cmd,
    void * cmd_args )
```

Issue performance counter control commands.

Issue a command `cmd` on the event counter associated with the provided handle `evt_handle`.

Parameters

in	<i>evt_handle</i>	an event handle
in	<i>cmd</i>	The event counter command to be issued
in, out	<i>cmd_args</i>	Currently not used. Should be set to NULL.

Return values

RSMI_STATUS_SUCCESS	is returned upon successful call
RSMI_STATUS_INVALID_ARGS	the provided arguments are not valid
RSMI_STATUS_PERMISSION	function requires root access

6.14.3.5 rsmi_counter_read()

```
rsmi_status_t rsmi_counter_read (
    rsmi_event_handle_t evt_handle,
    rsmi_counter_value_t * value )
```

Read the current value of a performance counter.

Read the current counter value of the counter associated with the provided handle `evt_handle` and write the value to the location pointed to by `value`.

Parameters

in	<i>evt_handle</i>	an event handle
in, out	<i>value</i>	pointer to memory of size of rsmi_counter_value_t to which the counter value will be written

Return values

<i>RSMI_STATUS_SUCCESS</i>	is returned upon successful call
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid
<i>RSMI_STATUS_PERMISSION</i>	function requires root access

6.14.3.6 `rsmi_counter_available_counters_get()`

```
rsmi_status_t rsmi_counter_available_counters_get (
    uint32_t dv_ind,
    rsmi_event_group_t grp,
    uint32_t * available )
```

Get the number of currently available counters.

Given a device index `dv_ind`, a performance event group `grp`, and a pointer to a `uint32_t` `available`, this function will write the number of `grp` type counters that are available on the device with index `dv_ind` to the memory that `available` points to.

Parameters

in	<i>dv_ind</i>	a device index
in	<i>grp</i>	an event device group
in, out	<i>available</i>	A pointer to a <code>uint32_t</code> to which the number of available counters will be written

Return values

<i>RSMI_STATUS_SUCCESS</i>	is returned upon successful call
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid

6.15 System Information Functions

These functions are used to configure, query and control performance counting.

Functions

- `rsmi_status_t rsmi_compute_process_info_get (rsmi_process_info_t *procs, uint32_t *num_items)`
Get process information about processes currently using GPU.
- `rsmi_status_t rsmi_compute_process_info_by_pid_get (uint32_t pid, rsmi_process_info_t *proc)`
Get process information about a specific process.
- `rsmi_status_t rsmi_compute_process_gpus_get (uint32_t pid, uint32_t *dv_indices, uint32_t *num_devices)`
Get the device indices currently being used by a process.

6.15.1 Detailed Description

These functions are used to configure, query and control performance counting.

6.15.2 Function Documentation

6.15.2.1 rsmi_compute_process_info_get()

```
rsmi_status_t rsmi_compute_process_info_get (
    rsmi_process_info_t * procs,
    uint32_t * num_items )
```

Get process information about processes currently using GPU.

Given a non-NULL pointer to an array `procs` of `rsmi_process_info_t`'s, of length `*num_items`, this function will write up to `*num_items` instances of `rsmi_process_info_t` to the memory pointed to by `procs`. These instances contain information about each process utilizing a GPU. If `procs` is not NULL, `num_items` will be updated with the number of processes actually written. If `procs` is NULL, `num_items` will be updated with the number of processes for which there is current process information. Calling this function with `procs` being NULL is a way to determine how much memory should be allocated for when `procs` is not NULL.

Parameters

in, out	<code>procs</code>	a pointer to memory provided by the caller to which process information will be written. This may be NULL in which case only <code>num_items</code> will be updated with the number of processes found.
in, out	<code>num_items</code>	A pointer to a <code>uint32_t</code> , which on input, should contain the amount of memory in <code>rsmi_process_info_t</code> 's which have been provided by the <code>procs</code> argument. On output, if <code>procs</code> is non-NULL, this will be updated with the number <code>rsmi_process_info_t</code> structs actually written. If <code>procs</code> is NULL, this argument will be updated with the number processes for which there is information.

Return values

<i>RSMI_STATUS_SUCCESS</i>	is returned upon successful call
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid
<i>RSMI_STATUS_INSUFFICIENT_SIZE</i>	is returned if there were more processes for which information was available, but not enough space was provided as indicated by <code>procs</code> and <code>num_items</code> , on input.

6.15.2.2 `rsmi_compute_process_info_by_pid_get()`

```
rsmi_status_t rsmi_compute_process_info_by_pid_get (
    uint32_t pid,
    rsmi_process_info_t * proc )
```

Get process information about a specific process.

Given a pointer to an `rsmi_process_info_t` `proc` and a process id `pid`, this function will write the process information for `pid`, if available, to the memory pointed to by `proc`.

Parameters

<code>in</code>	<code>pid</code>	The process ID for which process information is being requested
<code>in, out</code>	<code>proc</code>	a pointer to a <code>rsmi_process_info_t</code> to which process information for <code>pid</code> will be written if it is found.

Return values

<i>RSMI_STATUS_SUCCESS</i>	is returned upon successful call
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid
<i>RSMI_STATUS_NOT_FOUND</i>	is returned if there was no process information found for the provided <code>pid</code>

6.15.2.3 `rsmi_compute_process_gpus_get()`

```
rsmi_status_t rsmi_compute_process_gpus_get (
    uint32_t pid,
    uint32_t * dv_indices,
    uint32_t * num_devices )
```

Get the device indices currently being used by a process.

Given a process id `pid`, a non-NULL pointer to an array of `uint32_t`'s `dv_indices` of length `*num_devices`, this function will write up to `num_devices` device indices to the memory pointed to by `dv_indices`. If `dv_indices` is not NULL, `num_devices` will be updated with the number of gpus currently being used by process `pid`. If `dv_indices` is NULL, `dv_indices` will be updated with the number of gpus currently being used by `pid`. Calling this function with `dv_indices` being NULL is a way to determine how much memory is required for when `dv_indices` is not NULL.

Parameters

in	<i>pid</i>	The process id of the process for which the number of gpus currently being used is requested
in, out	<i>dv_indices</i>	a pointer to memory provided by the caller to which indices of devices currently being used by the process will be written. This may be NULL in which case only <i>num_devices</i> will be updated with the number of devices being used.
in, out	<i>num_devices</i>	A pointer to a <code>uint32_t</code> , which on input, should contain the amount of memory in <code>uint32_t</code> 's which have been provided by the <i>dv_indices</i> argument. On output, if <i>dv_indices</i> is non-NULL, this will be updated with the number <code>uint32_t</code> 's actually written. If <i>dv_indices</i> is NULL, this argument will be updated with the number devices being used.

Return values

<i>RSMI_STATUS_SUCCESS</i>	is returned upon successful call
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid
<i>RSMI_STATUS_INSUFFICIENT_SIZE</i>	is returned if there were more gpu indices that could have been written, but not enough space was provided as indicated by <i>dv_indices</i> and <i>num_devices</i> , on input.

6.16 XGMI Functions

These functions are used to configure, query and control XGMI.

Functions

- `rsmi_status_t rsmi_dev_xgmi_error_status` (uint32_t dv_ind, `rsmi_xgmi_status_t` *status)
Retrieve the XGMI error status for a device.
- `rsmi_status_t rsmi_dev_xgmi_error_reset` (uint32_t dv_ind)
Reset the XGMI error status for a device.
- `rsmi_status_t rsmi_dev_xgmi_hive_id_get` (uint32_t dv_ind, uint64_t *hive_id)
Retrieve the XGMI hive id for a device.

6.16.1 Detailed Description

These functions are used to configure, query and control XGMI.

6.16.2 Function Documentation

6.16.2.1 rsmi_dev_xgmi_error_status()

```
rsmi_status_t rsmi_dev_xgmi_error_status (
    uint32_t dv_ind,
    rsmi_xgmi_status_t * status )
```

Retrieve the XGMI error status for a device.

Given a device index `dv_ind`, and a pointer to an `rsmi_xgmi_status_t` `status`, this function will write the current XGMI error state `rsmi_xgmi_status_t` for the device `dv_ind` to the memory pointed to by `status`.

Parameters

in	<code>dv_ind</code>	a device index
in, out	<code>status</code>	A pointer to an <code>rsmi_xgmi_status_t</code> to which the XGMI error state should be written. If this parameter is nullptr, this function will return <code>RSMI_STATUS_INVALID_ARGS</code> if the function is supported with the provided arguments and <code>RSMI_STATUS_NOT_SUPPORTED</code> if it is not supported with the provided arguments.

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments
<code>RSMI_STATUS_INVALID_ARGS</code>	the provided arguments are not valid

6.16.2.2 rsmi_dev_xgmi_error_reset()

```
rsmi_status_t rsmi_dev_xgmi_error_reset (
    uint32_t dv_ind )
```

Reset the XGMI error status for a device.

Given a device index `dv_ind`, this function will reset the current XGMI error state `rsmi_xgmi_status_t` for the device `dv_ind` to `rsmi_xgmi_status_t::RSMI_XGMI_STATUS_NO_ERRORS`

Parameters

in	<code>dv_ind</code>	a device index
----	---------------------	----------------

Return values

<code>RSMI_STATUS_SUCCESS</code>	is returned upon successful call.
----------------------------------	-----------------------------------

6.16.2.3 rsmi_dev_xgmi_hive_id_get()

```
rsmi_status_t rsmi_dev_xgmi_hive_id_get (
    uint32_t dv_ind,
    uint64_t * hive_id )
```

Retrieve the XGMI hive id for a device.

Given a device index `dv_ind`, and a pointer to an `uint64_t` `hive_id`, this function will write the current XGMI hive id for the device `dv_ind` to the memory pointed to by `hive_id`.

Parameters

in	<code>dv_ind</code>	a device index
in, out	<code>hive_id</code>	A pointer to an <code>uint64_t</code> to which the XGMI hive id should be written

Return values

<code>RSMI_STATUS_SUCCESS</code>	call was successful
<code>RSMI_STATUS_NOT_SUPPORTED</code>	installed software or hardware does not support this function with the given arguments
<code>RSMI_STATUS_INVALID_ARGS</code>	the provided arguments are not valid

6.17 Hardware Topology Functions

These functions are used to query Hardware topology.

Functions

- [rsmi_status_t rsmi_topo_get_numa_node_number](#) (uint32_t dv_ind, uint32_t *numa_node)
Retrieve the NUMA CPU node number for a device.
- [rsmi_status_t rsmi_topo_get_link_weight](#) (uint32_t dv_ind_src, uint32_t dv_ind_dst, uint64_t *weight)
Retrieve the weight for a connection between 2 GPUs.
- [rsmi_status_t rsmi_minmax_bandwidth_get](#) (uint32_t dv_ind_src, uint32_t dv_ind_dst, uint64_t *min_↔ bandwidth, uint64_t *max_bandwidth)
Retrieve minimal and maximal io link bandwidth between 2 GPUs.
- [rsmi_status_t rsmi_topo_get_link_type](#) (uint32_t dv_ind_src, uint32_t dv_ind_dst, uint64_t *hops, [RSMI_IO_LINK_TYPE](#) *type)
Retrieve the hops and the connection type between 2 GPUs.
- [rsmi_status_t rsmi_is_P2P_accessible](#) (uint32_t dv_ind_src, uint32_t dv_ind_dst, bool *accessible)
Return P2P availability status between 2 GPUs.

6.17.1 Detailed Description

These functions are used to query Hardware topology.

6.17.2 Function Documentation

6.17.2.1 rsmi_topo_get_numa_node_number()

```
rsmi_status_t rsmi_topo_get_numa_node_number (
    uint32_t dv_ind,
    uint32_t * numa_node )
```

Retrieve the NUMA CPU node number for a device.

Given a device index `dv_ind`, and a pointer to an `uint32_t numa_node`, this function will write the node number of NUMA CPU for the device `dv_ind` to the memory pointed to by `numa_node`.

Parameters

in	<code>dv_ind</code>	a device index
in, out	<code>numa_node</code>	A pointer to an <code>uint32_t</code> to which the numa node number should be written.

Return values

RSMI_STATUS_SUCCESS	call was successful
RSMI_STATUS_INVALID_ARGS	the provided arguments are not valid

6.17.2.2 rsmi_topo_get_link_weight()

```
rsmi_status_t rsmi_topo_get_link_weight (
    uint32_t dv_ind_src,
    uint32_t dv_ind_dst,
    uint64_t * weight )
```

Retrieve the weight for a connection between 2 GPUs.

Given a source device index `dv_ind_src` and a destination device index `dv_ind_dst`, and a pointer to an `uint64_t` `weight`, this function will write the weight for the connection between the device `dv_ind_src` and `dv_ind_dst` to the memory pointed to by `weight`.

Parameters

in	<code>dv_ind_src</code>	the source device index
in	<code>dv_ind_dst</code>	the destination device index
in, out	<code>weight</code>	A pointer to an <code>uint64_t</code> to which the weight for the connection should be written.

Return values

<i>RSMI_STATUS_SUCCESS</i>	call was successful
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid

6.17.2.3 rsmi_minmax_bandwidth_get()

```
rsmi_status_t rsmi_minmax_bandwidth_get (
    uint32_t dv_ind_src,
    uint32_t dv_ind_dst,
    uint64_t * min_bandwidth,
    uint64_t * max_bandwidth )
```

Retrieve minimal and maximal io link bandwidth between 2 GPUs.

Given a source device index `dv_ind_src` and a destination device index `dv_ind_dst`, pointer to an `uint64_t` `min_bandwidth`, and a pointer to `uint64_t` `max_bandwidth`, this function will write theoretical minimal and maximal bandwidth limits. API works if `src` and `dst` are connected via `xgmi` and have 1 hop distance.

Parameters

in	<code>dv_ind_src</code>	the source device index
in	<code>dv_ind_dst</code>	the destination device index
in, out	<code>min_bandwidth</code>	A pointer to an <code>uint64_t</code> to which the minimal bandwidth for the connection should be written.
in, out	<code>max_bandwidth</code>	A pointer to an <code>uint64_t</code> to which the maximal bandwidth for the connection should be written.

Return values

RSMI_STATUS_SUCCESS	call was successful
RSMI_STATUS_INVALID_ARGS	the provided arguments are not valid

6.17.2.4 `rsmi_topo_get_link_type()`

```
rsmi_status_t rsmi_topo_get_link_type (
    uint32_t dv_ind_src,
    uint32_t dv_ind_dst,
    uint64_t * hops,
    RSMI_IO_LINK_TYPE * type )
```

Retrieve the hops and the connection type between 2 GPUs.

Given a source device index `dv_ind_src` and a destination device index `dv_ind_dst`, and a pointer to an `uint64_t` `hops` and a pointer to an `RSMI_IO_LINK_TYPE` `type`, this function will write the number of hops and the connection type between the device `dv_ind_src` and `dv_ind_dst` to the memory pointed to by `hops` and `type`.

Parameters

in	<code>dv_ind_src</code>	the source device index
in	<code>dv_ind_dst</code>	the destination device index
in, out	<code>hops</code>	A pointer to an <code>uint64_t</code> to which the hops for the connection should be written.
in, out	<code>type</code>	A pointer to an <code>RSMI_IO_LINK_TYPE</code> to which the type for the connection should be written.

Return values

RSMI_STATUS_SUCCESS	call was successful
RSMI_STATUS_INVALID_ARGS	the provided arguments are not valid

6.17.2.5 `rsmi_is_P2P_accessible()`

```
rsmi_status_t rsmi_is_P2P_accessible (
    uint32_t dv_ind_src,
    uint32_t dv_ind_dst,
    bool * accessible )
```

Return P2P availability status between 2 GPUs.

Given a source device index `dv_ind_src` and a destination device index `dv_ind_dst`, and a pointer to a `bool` `@accessible`, this function will write the P2P connection status between the device `dv_ind_src` and `dv_ind_dst` to the memory pointed to by `accessible`.

Parameters

in	<i>dv_ind_src</i>	the source device index
in	<i>dv_ind_dst</i>	the destination device index
in, out	<i>accessible</i>	A pointer to a bool to which the status for the P2P connection availability should be written.

Return values

<i>RSMI_STATUS_SUCCESS</i>	call was successful
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid

6.18 Compute Partition Functions

These functions are used to configure and query the device's compute partition setting.

Functions

- [rsmi_status_t rsmi_dev_compute_partition_get](#) (uint32_t dv_ind, char *compute_partition, uint32_t len)
Retrieves the current compute partitioning for a desired device.
- [rsmi_status_t rsmi_dev_compute_partition_set](#) (uint32_t dv_ind, rsmi_compute_partition_type_t compute_partition)
Modifies a selected device's compute partition setting.
- [rsmi_status_t rsmi_dev_compute_partition_reset](#) (uint32_t dv_ind)
Reverts a selected device's compute partition setting back to its boot state.

6.18.1 Detailed Description

These functions are used to configure and query the device's compute partition setting.

6.18.2 Function Documentation

6.18.2.1 rsmi_dev_compute_partition_get()

```
rsmi_status_t rsmi_dev_compute_partition_get (
    uint32_t dv_ind,
    char * compute_partition,
    uint32_t len )
```

Retrieves the current compute partitioning for a desired device.

Given a device index `dv_ind` and a string `compute_partition`, and `uint32 len`, this function will attempt to obtain the device's current compute partition setting string. Upon successful retrieval, the obtained device's compute partition settings string shall be stored in the passed `compute_partition` char string variable.

Parameters

in	<code>dv_ind</code>	a device index
in, out	<code>compute_partition</code>	a pointer to a char string variable, which the device's current compute partition will be written to.
in	<code>len</code>	the length of the caller provided buffer <code>compute_partition</code> , suggested length is 4 or greater.

Return values

RSMI_STATUS_SUCCESS	call was successful
RSMI_STATUS_INVALID_ARGS	the provided arguments are not valid

Return values

<i>RSMI_STATUS_UNEXPECTED_DATA</i>	data provided to function is not valid
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function
<i>RSMI_STATUS_INSUFFICIENT_SIZE</i>	is returned if <code>len</code> bytes is not large enough to hold the entire compute partition value. In this case, only <code>len</code> bytes will be written.

6.18.2.2 `rsmi_dev_compute_partition_set()`

```
rsmi_status_t rsmi_dev_compute_partition_set (
    uint32_t dv_ind,
    rsmi_compute_partition_type_t compute_partition )
```

Modifies a selected device's compute partition setting.

Given a device index `dv_ind`, a type of compute partition `compute_partition`, this function will attempt to update the selected device's compute partition setting.

Parameters

in	<code>dv_ind</code>	a device index
in	<code>compute_partition</code>	using enum <code>rsmi_compute_partition_type_t</code> , define what the selected device's compute partition setting should be updated to.

Return values

<i>RSMI_STATUS_SUCCESS</i>	call was successful
<i>RSMI_STATUS_PERMISSION</i>	function requires root access
<i>RSMI_STATUS_INVALID_ARGS</i>	the provided arguments are not valid
<i>RSMI_STATUS_SETTING_UNAVAILABLE</i>	the provided setting is unavailable for current device
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function

6.18.2.3 `rsmi_dev_compute_partition_reset()`

```
rsmi_status_t rsmi_dev_compute_partition_reset (
    uint32_t dv_ind )
```

Reverts a selected device's compute partition setting back to its boot state.

Given a device index `dv_ind`, this function will attempt to revert its compute partition setting back to its boot state.

Parameters

in	<code>dv_ind</code>	a device index
----	---------------------	----------------

Return values

<i>RSMI_STATUS_SUCCESS</i>	call was successful
<i>RSMI_STATUS_PERMISSION</i>	function requires root access
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function

6.19 NPS Mode Functions

These functions are used to query the device's NPS mode (memory partition).

Functions

- [rsmi_status_t rsmi_dev_nps_mode_get](#) (uint32_t dv_ind, char *nps_mode, uint32_t len)
Retrieves the NPS mode (memory partition) for a desired device.
- [rsmi_status_t rsmi_dev_nps_mode_set](#) (uint32_t dv_ind, [rsmi_nps_mode_type_t](#) nps_mode)
Modifies a selected device's NPS mode (memory partition) setting.
- [rsmi_status_t rsmi_dev_nps_mode_reset](#) (uint32_t dv_ind)
Reverts a selected device's NPS mode setting back to its boot state.

6.19.1 Detailed Description

These functions are used to query the device's NPS mode (memory partition).

6.19.2 Function Documentation

6.19.2.1 rsmi_dev_nps_mode_get()

```
rsmi_status_t rsmi_dev_nps_mode_get (
    uint32_t dv_ind,
    char * nps_mode,
    uint32_t len )
```

Retrieves the NPS mode (memory partition) for a desired device.

Given a device index `dv_ind` and a string `nps_mode`, and `uint32 len`, this function will attempt to obtain the device's nps mode string. Upon successful retrieval, the obtained device's nps mode string shall be stored in the passed `nps_mode` char string variable.

Parameters

in	<code>dv_ind</code>	a device index
in, out	<code>nps_mode</code>	a pointer to a char string variable, which the device's nps mode will be written to.
in	<code>len</code>	the length of the caller provided buffer <code>nps_mode</code> , suggested length is 5 or greater.

Return values

RSMI_STATUS_SUCCESS	call was successful
RSMI_STATUS_INVALID_ARGS	the provided arguments are not valid
RSMI_STATUS_UNEXPECTED_DATA	data provided to function is not valid
RSMI_STATUS_NOT_SUPPORTED	installed software or hardware does not support this function

Return values

RSMI_STATUS_INSUFFICIENT_SIZE	is returned if <code>len</code> bytes is not large enough to hold the entire nps mode value. In this case, only <code>len</code> bytes will be written.
---	---

6.19.2.2 `rsmi_dev_nps_mode_set()`

```
rsmi_status_t rsmi_dev_nps_mode_set (
    uint32_t dv_ind,
    rsmi_nps_mode_type_t nps_mode )
```

Modifies a selected device's NPS mode (memory partition) setting.

Given a device index `dv_ind` and a type of nps mode `nps_mode`, this function will attempt to update the selected device's nps mode setting.

Parameters

in	<code>dv_ind</code>	a device index
in	<code>nps_mode</code>	using enum rsmi_nps_mode_type_t , define what the selected device's NPS mode setting should be updated to.

Return values

RSMI_STATUS_SUCCESS	call was successful
RSMI_STATUS_PERMISSION	function requires root access
RSMI_STATUS_INVALID_ARGS	the provided arguments are not valid
RSMI_STATUS_NOT_SUPPORTED	installed software or hardware does not support this function
RSMI_STATUS_AMDGPU_RESTART_ERR	could not successfully restart the amdgpu driver

6.19.2.3 `rsmi_dev_nps_mode_reset()`

```
rsmi_status_t rsmi_dev_nps_mode_reset (
    uint32_t dv_ind )
```

Reverts a selected device's NPS mode setting back to its boot state.

Given a device index `dv_ind`, this function will attempt to revert its NPS mode setting back to its boot state.

Parameters

in	<code>dv_ind</code>	a device index
----	---------------------	----------------

Return values

<i>RSMI_STATUS_SUCCESS</i>	call was successful
<i>RSMI_STATUS_PERMISSION</i>	function requires root access
<i>RSMI_STATUS_NOT_SUPPORTED</i>	installed software or hardware does not support this function
<i>RSMI_STATUS_AMDGPU_RESTART_ERR</i>	could not successfully restart the amdgpu driver

6.20 Supported Functions

API function support varies by both GPU type and the version of the installed ROCm stack. The functions described in this section can be used to determine, up front, which functions are supported for a given device on a system. If such "up front" knowledge of support for a function is not needed, alternatively, one can call a device related function and check the return code.

Functions

- `rsmi_status_t rsmi_dev_supported_func_iterator_open` (`uint32_t dev_ind`, `rsmi_func_id_iter_handle_t *handle`)
Get a function name iterator of supported RSMI functions for a device.
- `rsmi_status_t rsmi_dev_supported_variant_iterator_open` (`rsmi_func_id_iter_handle_t obj_h`, `rsmi_func_id_iter_handle_t *var_iter`)
Get a variant iterator for a given handle.
- `rsmi_status_t rsmi_func_iter_next` (`rsmi_func_id_iter_handle_t handle`)
Advance a function identifier iterator.
- `rsmi_status_t rsmi_dev_supported_func_iterator_close` (`rsmi_func_id_iter_handle_t *handle`)
Close a variant iterator handle.
- `rsmi_status_t rsmi_func_iter_value_get` (`rsmi_func_id_iter_handle_t handle`, `rsmi_func_id_value_t *value`)
Get the value associated with a function/variant iterator.

6.20.1 Detailed Description

API function support varies by both GPU type and the version of the installed ROCm stack. The functions described in this section can be used to determine, up front, which functions are supported for a given device on a system. If such "up front" knowledge of support for a function is not needed, alternatively, one can call a device related function and check the return code.

Some functions have several variations ("variants") where some variants are supported and others are not. For example, on a given device, `rsmi_dev_temp_metric_get` may support some types of temperature metrics (e.g., `RSMI_TEMP_CRITICAL_HYST`), but not others (e.g., `RSMI_TEMP_EMERGENCY`).

In addition to a top level of variant support for a function, a function may have varying support for monitors/sensors. These are considered "sub-variants" in functions described in this section. Continuing the `rsmi_dev_temp_metric_get` example, if variant `RSMI_TEMP_CRITICAL_HYST` is supported, perhaps only the sub-variant sensors `RSMI_TEMP_TYPE_EDGE` and `RSMI_TEMP_TYPE_EDGE` are supported, but not `RSMI_TEMP_TYPE_MEMORY`.

In cases where a function takes in a sensor id parameter but does not have any "top level" variants, the functions in this section will indicate a default "variant", `RSMI_DEFAULT_VARIANT`, for the top level variant, and the various monitor support will be sub-variants of this.

The functions in this section use the "iterator" concept to list which functions are supported; to list which variants of the supported functions are supported; and finally which monitors/sensors are supported for a variant.

Here is example code that prints out all supported functions, their supported variants and sub-variants. Please see the related descriptions functions and RSMI types.

```

rsmi_func_id_iter_handle_t iter_handle, var_iter, sub_var_iter;
rsmi_func_id_value_t value;
rsmi_status_t err;
for (uint32_t i = 0; i < <number of devices>; ++i) {
    std::cout << "Supported RSMI Functions:" << std::endl;
    std::cout << "\tVariants (Monitors)" << std::endl;
    err = rsmi_dev_supported_func_iterator_open(i, &iter_handle);
    while (1) {
        err = rsmi_func_iter_value_get(iter_handle, &value);
        std::cout << "Function Name: " << value.name << std::endl;
        err = rsmi_dev_supported_variant_iterator_open(iter_handle, &var_iter);
        if (err != RSMI_STATUS_NO_DATA) {
            std::cout << "\tVariants/Monitors: ";
            while (1) {
                err = rsmi_func_iter_value_get(var_iter, &value);
                if (value.id == RSMI_DEFAULT_VARIANT) {
                    std::cout << "Default Variant ";
                } else {
                    std::cout << value.id;
                }
                std::cout << " ";
                err =
                    rsmi_dev_supported_variant_iterator_open(var_iter, &sub_var_iter);
                if (err != RSMI_STATUS_NO_DATA) {
                    while (1) {
                        err = rsmi_func_iter_value_get(sub_var_iter, &value);
                        std::cout << value.id << ", ";
                        err = rsmi_func_iter_next(sub_var_iter);
                        if (err == RSMI_STATUS_NO_DATA) {
                            break;
                        }
                    }
                    err = rsmi_dev_supported_func_iterator_close(&sub_var_iter);
                }
                std::cout << ", ";
                err = rsmi_func_iter_next(var_iter);
                if (err == RSMI_STATUS_NO_DATA) {
                    break;
                }
            }
            std::cout << std::endl;
            err = rsmi_dev_supported_func_iterator_close(&var_iter);
        }
        err = rsmi_func_iter_next(iter_handle);
        if (err == RSMI_STATUS_NO_DATA) {
            break;
        }
    }
    err = rsmi_dev_supported_func_iterator_close(&iter_handle);
}

```

6.20.2 Function Documentation

6.20.2.1 rsmi_dev_supported_func_iterator_open()

```

rsmi_status_t rsmi_dev_supported_func_iterator_open (
    uint32_t dv_ind,
    rsmi_func_id_iter_handle_t * handle )

```

Get a function name iterator of supported RSMI functions for a device.

Given a device index `dv_ind`, this function will write a function iterator handle to the caller-provided memory pointed to by `handle`. This handle can be used to iterate through all the supported functions.

Note that although this function takes in `dv_ind` as an argument, `rsmi_dev_supported_func_iterator_open` itself will not be among the functions listed as supported. This is because `rsmi_dev_supported_func_iterator_open` does not depend on hardware or driver support and should always be supported.

Parameters

<code>in</code>	<code>dv_ind</code>	a device index of device for which support information is requested
<code>in, out</code>	<code>handle</code>	A pointer to caller-provided memory to which the function iterator will be written.

Return values

<code>RSMI_STATUS_SUCCESS</code>	is returned upon successful call.
----------------------------------	-----------------------------------

6.20.2.2 `rsmi_dev_supported_variant_iterator_open()`

```
rsmi_status_t rsmi_dev_supported_variant_iterator_open (
    rsmi_func_id_iter_handle_t obj_h,
    rsmi_func_id_iter_handle_t * var_iter )
```

Get a variant iterator for a given handle.

Given a `rsmi_func_id_iter_handle_t` `obj_h`, this function will write a function iterator handle to the caller-provided memory pointed to by `var_iter`. This handle can be used to iterate through all the supported variants of the provided handle. `obj_h` may be a handle to a function object, as provided by a call to `rsmi_dev_supported_func_iterator_open`, or it may be a variant itself (from a call to `rsmi_dev_supported_variant_iterator_open`), in which case `var_iter` will be an iterator of the sub-variants of `obj_h` (e.g., monitors).

This call allocates a small amount of memory to `var_iter`. To free this memory `rsmi_dev_supported_func_iterator_close` should be called on the returned iterator handle `var_iter` when it is no longer needed.

Parameters

<code>in</code>	<code>obj_h</code>	an iterator handle for which the variants are being requested
<code>in, out</code>	<code>var_iter</code>	A pointer to caller-provided memory to which the sub-variant iterator will be written.

Return values

<code>RSMI_STATUS_SUCCESS</code>	is returned upon successful call.
----------------------------------	-----------------------------------

6.20.2.3 `rsmi_func_iter_next()`

```
rsmi_status_t rsmi_func_iter_next (
    rsmi_func_id_iter_handle_t handle )
```

Advance a function identifier iterator.

Given a function id iterator handle (`rsmi_func_id_iter_handle_t`) `handle`, this function will increment the iterator to point to the next identifier. After a successful call to this function, obtaining the value of the iterator `handle` will provide the value of the next item in the list of functions/variants.

If there are no more items in the list, `RSMI_STATUS_NO_DATA` is returned.

Parameters

in	<i>handle</i>	A pointer to an iterator handle to be incremented
----	---------------	---

Return values

RSMI_STATUS_SUCCESS	is returned upon successful call.
RSMI_STATUS_NO_DATA	is returned when list of identifiers has been exhausted

6.20.2.4 rsmi_dev_supported_func_iterator_close()

```
rsmi_status_t rsmi_dev_supported_func_iterator_close (
    rsmi_func_id_iter_handle_t * handle )
```

Close a variant iterator handle.

Given a pointer to an [rsmi_func_id_iter_handle_t](#) handle, this function will free the resources being used by the handle

Parameters

in	<i>handle</i>	A pointer to an iterator handle to be closed
----	---------------	--

Return values

RSMI_STATUS_SUCCESS	is returned upon successful call.
-------------------------------------	-----------------------------------

6.20.2.5 rsmi_func_iter_value_get()

```
rsmi_status_t rsmi_func_iter_value_get (
    rsmi_func_id_iter_handle_t handle,
    rsmi_func_id_value_t * value )
```

Get the value associated with a function/variant iterator.

Given an [rsmi_func_id_iter_handle_t](#) handle, this function will write the identifier of the function/variant to the user provided memory pointed to by *value*.

value may point to a function name, a variant id, or a monitor/sensor index, depending on what kind of iterator handle is

Parameters

in	<i>handle</i>	An iterator for which the value is being requested
in, out	<i>value</i>	A pointer to an rsmi_func_id_value_t provided by the caller to which this function will write the value associated with <i>handle</i>

Return values

<i>RSMI_STATUS_SUCCESS</i>	is returned upon successful call.
----------------------------	-----------------------------------

6.21 Event Notification Functions

These functions are used to configure for and get asynchronous event notifications.

Functions

- [rsmi_status_t rsmi_event_notification_init](#) (uint32_t dv_ind)
Prepare to collect event notifications for a GPU.
- [rsmi_status_t rsmi_event_notification_mask_set](#) (uint32_t dv_ind, uint64_t mask)
Specify which events to collect for a device.
- [rsmi_status_t rsmi_event_notification_get](#) (int timeout_ms, uint32_t *num_elem, [rsmi_evt_notification_data_t](#) *data)
Collect event notifications, waiting a specified amount of time.
- [rsmi_status_t rsmi_event_notification_stop](#) (uint32_t dv_ind)
Close any file handles and free any resources used by event notification for a GPU.

6.21.1 Detailed Description

These functions are used to configure for and get asynchronous event notifications.

6.21.2 Function Documentation

6.21.2.1 rsmi_event_notification_init()

```
rsmi_status_t rsmi_event_notification_init (
    uint32_t dv_ind )
```

Prepare to collect event notifications for a GPU.

This function prepares to collect events for the GPU with device ID `dv_ind`, by initializing any required system parameters. This call may open files which will remain open until [rsmi_event_notification_stop\(\)](#) is called.

Parameters

<code>dv_ind</code>	a device index corresponding to the device on which to listen for events
---------------------	--

Return values

RSMI_STATUS_SUCCESS	is returned upon successful call.
-------------------------------------	-----------------------------------

6.21.2.2 `rsmi_event_notification_mask_set()`

```
rsmi_status_t rsmi_event_notification_mask_set (
    uint32_t dv_ind,
    uint64_t mask )
```

Specify which events to collect for a device.

Given a device index `dv_ind` and a `mask` consisting of elements of `rsmi_evt_notification_type_t` OR'd together, this function will listen for the events specified in `mask` on the device corresponding to `dv_ind`.

Parameters

<code>dv_ind</code>	a device index corresponding to the device on which to listen for events
<code>mask</code>	Bitmask generated by OR'ing 1 or more elements of <code>rsmi_evt_notification_type_t</code> indicating which event types to listen for, where the <code>rsmi_evt_notification_type_t</code> value indicates the bit field, with bit position starting from 1. For example, if the mask field is 0x0000000000000003, which means first bit, bit 1 (bit position start from 1) and bit 2 are set, which indicate interest in receiving <code>RSMI_EVT_NOTIF_VMFAULT</code> (which has a value of 1) and <code>RSMI_EVT_NOTIF_THERMAL_THROTTLE</code> event (which has a value of 2).

Return values

<code>RSMI_STATUS_INIT_ERROR</code>	is returned if <code>rsmi_event_notification_init()</code> has not been called before a call to this function
<code>RSMI_STATUS_SUCCESS</code>	is returned upon successful call

6.21.2.3 `rsmi_event_notification_get()`

```
rsmi_status_t rsmi_event_notification_get (
    int timeout_ms,
    uint32_t * num_elem,
    rsmi_evt_notification_data_t * data )
```

Collect event notifications, waiting a specified amount of time.

Given a time period `timeout_ms` in milliseconds and a caller- provided buffer of `rsmi_evt_notification_data_t`'s `data` with a length (in `rsmi_evt_notification_data_t`'s, also specified by the caller) in the memory location pointed to by `num_elem`, this function will collect `rsmi_evt_notification_type_t` events for up to `timeout_ms` milliseconds, and write up to `*num_elem` event items to `data`. Upon return `num_elem` is updated with the number of events that were actually written. If events are already present when this function is called, it will write the events to the buffer then poll for new events if there is still caller-provided buffer available to write any new events that would be found.

This function requires prior calls to `rsmi_event_notification_init()` and `rsmi_event_notification_mask_set()`. This function polls for the occurrence of the events on the respective devices that were previously specified by `rsmi_event_notification_mask_set()`.

Parameters

<code>in</code>	<code>timeout_ms</code>	number of milliseconds to wait for an event to occur
-----------------	-------------------------	--

Parameters

in, out	<i>num_elem</i>	pointer to <code>uint32_t</code> , provided by the caller. On input, this value tells how many <code>rsmi_evt_notification_data_t</code> elements are being provided by the caller with <code>data</code> . On output, the location pointed to by <code>num_elem</code> will contain the number of items written to the provided buffer.
out	<i>data</i>	pointer to a caller-provided memory buffer of size <code>num_elem</code> <code>rsmi_evt_notification_data_t</code> to which this function may safely write. If there are events found, up to <code>num_elem</code> event items will be written to <code>data</code> .

Return values

<code>RSMI_STATUS_SUCCESS</code>	The function ran successfully. The events that were found are written to <code>data</code> and <code>num_elems</code> is updated with the number of elements that were written.
<code>RSMI_STATUS_NO_DATA</code>	No events were found to collect.

6.21.2.4 `rsmi_event_notification_stop()`

```
rsmi_status_t rsmi_event_notification_stop (
    uint32_t dv_ind )
```

Close any file handles and free any resources used by event notification for a GPU.

Any resources used by event notification for the GPU with device index `dv_ind` will be free with this function. This includes freeing any memory and closing file handles. This should be called for every call to `rsmi_event_notification_init()`

Parameters

in	<i>dv_ind</i>	The device index of the GPU for which event notification resources will be free
----	---------------	---

Return values

<code>RSMI_STATUS_INVALID_ARGS</code>	resources for the given device have either already been freed, or were never allocated by <code>rsmi_event_notification_init()</code>
<code>RSMI_STATUS_SUCCESS</code>	is returned upon successful call

Chapter 7

Data Structure Documentation

7.1 id Union Reference

This union holds the value of an [rsmi_func_id_iter_handle_t](#). The value may be a function name, or an enumerated variant value of types such as [rsmi_memory_type_t](#), [rsmi_temperature_metric_t](#), etc.

```
#include <rocm_smi.h>
```

Data Fields

- `uint64_t id`
uint64_t representation of value
- `const char * name`
name string (applicable to functions only)
- union {
 [rsmi_memory_type_t](#) `memory_type`
 < Used for [rsmi_memory_type_t](#) variants
 [rsmi_temperature_metric_t](#) `temp_metric`
 Used for [rsmi_event_type_t](#) variants.
 [rsmi_event_type_t](#) `evnt_type`
 Used for [rsmi_event_group_t](#) variants.
 [rsmi_event_group_t](#) `evnt_group`
 Used for [rsmi_clk_type_t](#) variants.
 [rsmi_clk_type_t](#) `clk_type`
 Used for [rsmi_fw_block_t](#) variants.
 [rsmi_fw_block_t](#) `fw_block`
 Used for [rsmi_gpu_block_t](#) variants.
 [rsmi_gpu_block_t](#) `gpu_block_type`
};

7.1.1 Detailed Description

This union holds the value of an [rsmi_func_id_iter_handle_t](#). The value may be a function name, or an enumerated variant value of types such as [rsmi_memory_type_t](#), [rsmi_temperature_metric_t](#), etc.

7.1.2 Field Documentation

7.1.2.1 memory_type

```
rsmi_memory_type_t id::memory_type
```

< Used for [rsmi_memory_type_t](#) variants

Used for [rsmi_temperature_metric_t](#) variants

The documentation for this union was generated from the following file:

- [rocm_smi.h](#)

7.2 metrics_table_header_t Struct Reference

The following structures hold the gpu metrics values for a device.

```
#include <rocm_smi.h>
```

7.2.1 Detailed Description

The following structures hold the gpu metrics values for a device.

Size and version information of metrics data

The documentation for this struct was generated from the following file:

- [rocm_smi.h](#)

7.3 rsmi_counter_value_t Struct Reference

```
#include <rocm_smi.h>
```

Data Fields

- [uint64_t value](#)
Counter value.
- [uint64_t time_enabled](#)
- [uint64_t time_running](#)

7.3.1 Detailed Description

Counter value

7.3.2 Field Documentation

7.3.2.1 time_enabled

```
uint64_t rsmi_counter_value_t::time_enabled
```

Time that the counter was enabled (in nanoseconds)

7.3.2.2 time_running

```
uint64_t rsmi_counter_value_t::time_running
```

Time that the counter was running (in nanoseconds)

The documentation for this struct was generated from the following file:

- [rocm_smi.h](#)

7.4 rsmi_error_count_t Struct Reference

This structure holds error counts.

```
#include <rocm_smi.h>
```

Data Fields

- `uint64_t` [correctable_err](#)
Accumulated correctable errors.
- `uint64_t` [uncorrectable_err](#)
Accumulated uncorrectable errors.

7.4.1 Detailed Description

This structure holds error counts.

The documentation for this struct was generated from the following file:

- [rocm_smi.h](#)

7.5 rsmi_evt_notification_data_t Struct Reference

```
#include <rocm_smi.h>
```

Data Fields

- [uint32_t dv_ind](#)
Index of device that corresponds to the event.
- [rsmi_evt_notification_type_t event](#)
Event type.
- char [message](#) [[MAX_EVENT_NOTIFICATION_MSG_SIZE](#)]
Event message.

7.5.1 Detailed Description

Event notification data returned from event notification API

The documentation for this struct was generated from the following file:

- [rocm_smi.h](#)

7.6 rsmi_freq_volt_region_t Struct Reference

This structure holds 2 [rsmi_range_t](#)'s, one for frequency and one for voltage. These 2 ranges indicate the range of possible values for the corresponding [rsmi_od_vddc_point_t](#).

```
#include <rocm_smi.h>
```

Data Fields

- [rsmi_range_t freq_range](#)
The frequency range for this VDDC Curve point.
- [rsmi_range_t volt_range](#)
The voltage range for this VDDC Curve point.

7.6.1 Detailed Description

This structure holds 2 [rsmi_range_t](#)'s, one for frequency and one for voltage. These 2 ranges indicate the range of possible values for the corresponding [rsmi_od_vddc_point_t](#).

The documentation for this struct was generated from the following file:

- [rocm_smi.h](#)

7.7 rsmi_frequencies_t Struct Reference

This structure holds information about clock frequencies.

```
#include <rocm_smi.h>
```

Data Fields

- uint32_t [num_supported](#)
- uint32_t [current](#)
- uint64_t [frequency](#) [[RSMI_MAX_NUM_FREQUENCIES](#)]

7.7.1 Detailed Description

This structure holds information about clock frequencies.

7.7.2 Field Documentation

7.7.2.1 num_supported

```
uint32_t rsmi_frequencies_t::num_supported
```

The number of supported frequencies

7.7.2.2 current

```
uint32_t rsmi_frequencies_t::current
```

The current frequency index

7.7.2.3 frequency

```
uint64_t rsmi_frequencies_t::frequency [RSMI\_MAX\_NUM\_FREQUENCIES]
```

List of frequencies. Only the first num_supported frequencies are valid.

The documentation for this struct was generated from the following file:

- [rocm_smi.h](#)

7.8 rsmi_gpu_metrics_t Struct Reference

The documentation for this struct was generated from the following file:

- [rocm_smi.h](#)

7.9 rsmi_od_vddc_point_t Struct Reference

This structure represents a point on the frequency-voltage plane.

```
#include <rocm_smi.h>
```

Data Fields

- `uint64_t` [frequency](#)
Frequency coordinate (in Hz)
- `uint64_t` [voltage](#)
Voltage coordinate (in mV)

7.9.1 Detailed Description

This structure represents a point on the frequency-voltage plane.

The documentation for this struct was generated from the following file:

- [rocm_smi.h](#)

7.10 rsmi_od_volt_curve_t Struct Reference

```
#include <rocm_smi.h>
```

Data Fields

- `rsmi_od_vddc_point_t` [vc_points](#) [RSMI_NUM_VOLTAGE_CURVE_POINTS]

7.10.1 Detailed Description

[RSMI_NUM_VOLTAGE_CURVE_POINTS](#) number of `rsmi_od_vddc_point_t`'s

7.10.2 Field Documentation

7.10.2.1 vc_points

```
rsmi_od_vddc_point_t rsmi_od_volt_curve_t::vc_points[RSMI_NUM_VOLTAGE_CURVE_POINTS]
```

Array of [RSMI_NUM_VOLTAGE_CURVE_POINTS rsmi_od_vddc_point_t](#)'s that make up the voltage frequency curve points.

The documentation for this struct was generated from the following file:

- [rocm_smi.h](#)

7.11 rsmi_od_volt_freq_data_t Struct Reference

This structure holds the frequency-voltage values for a device.

```
#include <rocm_smi.h>
```

Data Fields

- [rsmi_range_t curr_sclk_range](#)
The current SCLK frequency range.
- [rsmi_range_t curr_mclk_range](#)
- [rsmi_range_t sclk_freq_limits](#)
The range possible of SCLK values.
- [rsmi_range_t mclk_freq_limits](#)
The range possible of MCLK values.
- [rsmi_od_volt_curve_t curve](#)
The current voltage curve.
- [uint32_t num_regions](#)
The number of voltage curve regions.

7.11.1 Detailed Description

This structure holds the frequency-voltage values for a device.

7.11.2 Field Documentation

7.11.2.1 curr_mclk_range

```
rsmi_range_t rsmi_od_volt_freq_data_t::curr_mclk_range
```

The current MCLK frequency range; (upper bound only)

The documentation for this struct was generated from the following file:

- [rocm_smi.h](#)

7.12 rsmi_pcie_bandwidth_t Struct Reference

This structure holds information about the possible PCIe bandwidths. Specifically, the possible transfer rates and their associated numbers of lanes are stored here.

```
#include <rocm_smi.h>
```

Data Fields

- [rsmi_frequencies_t transfer_rate](#)
- `uint32_t lanes` [[RSMI_MAX_NUM_FREQUENCIES](#)]

7.12.1 Detailed Description

This structure holds information about the possible PCIe bandwidths. Specifically, the possible transfer rates and their associated numbers of lanes are stored here.

7.12.2 Field Documentation

7.12.2.1 transfer_rate

```
rsmi_frequencies_t rsmi_pcie_bandwidth_t::transfer_rate
```

Transfer rates (T/s) that are possible

7.12.2.2 lanes

```
uint32_t rsmi_pcie_bandwidth_t::lanes [RSMI\_MAX\_NUM\_FREQUENCIES]
```

List of lanes for corresponding transfer rate. Only the first num_supported bandwidths are valid.

The documentation for this struct was generated from the following file:

- [rocm_smi.h](#)

7.13 rsmi_power_profile_status_t Struct Reference

This structure contains information about which power profiles are supported by the system for a given device, and which power profile is currently active.

```
#include <rocm_smi.h>
```

Data Fields

- [rsmi_bit_field_t available_profiles](#)
- [rsmi_power_profile_preset_masks_t current](#)
- [uint32_t num_profiles](#)

7.13.1 Detailed Description

This structure contains information about which power profiles are supported by the system for a given device, and which power profile is currently active.

7.13.2 Field Documentation

7.13.2.1 available_profiles

```
rsmi_bit_field_t rsmi_power_profile_status_t::available_profiles
```

Which profiles are supported by this system

7.13.2.2 current

```
rsmi_power_profile_preset_masks_t rsmi_power_profile_status_t::current
```

Which power profile is currently active

7.13.2.3 num_profiles

```
uint32_t rsmi_power_profile_status_t::num_profiles
```

How many power profiles are available

The documentation for this struct was generated from the following file:

- [rocm_smi.h](#)

7.14 rsmi_process_info_t Struct Reference

This structure contains information specific to a process.

```
#include <rocm_smi.h>
```

Data Fields

- `uint32_t process_id`
Process ID.
- `uint32_t pasid`
PASID.
- `uint64_t vram_usage`
VRAM usage.
- `uint64_t sdma_usage`
SDMA usage in microseconds.
- `uint32_t cu_occupancy`
Compute Unit usage in percent.

7.14.1 Detailed Description

This structure contains information specific to a process.

The documentation for this struct was generated from the following file:

- [rocm_smi.h](#)

7.15 rsmi_range_t Struct Reference

This structure represents a range (e.g., frequencies or voltages).

```
#include <rocm_smi.h>
```

Data Fields

- `uint64_t lower_bound`
Lower bound of range.
- `uint64_t upper_bound`
Upper bound of range.

7.15.1 Detailed Description

This structure represents a range (e.g., frequencies or voltages).

The documentation for this struct was generated from the following file:

- [rocm_smi.h](#)

7.16 rsmi_retired_page_record_t Struct Reference

Reserved Memory Page Record.

```
#include <rocm_smi.h>
```

Data Fields

- [uint64_t page_address](#)
Start address of page.
- [uint64_t page_size](#)
Page size.
- [rsmi_memory_page_status_t status](#)
Page "reserved" status.

7.16.1 Detailed Description

Reserved Memory Page Record.

The documentation for this struct was generated from the following file:

- [rocm_smi.h](#)

7.17 rsmi_utilization_counter_t Struct Reference

The utilization counter data.

```
#include <rocm_smi.h>
```

Data Fields

- [RSMI_UTILIZATION_COUNTER_TYPE](#) type
Utilization counter type.
- [uint64_t value](#)
Utilization counter value.

7.17.1 Detailed Description

The utilization counter data.

The documentation for this struct was generated from the following file:

- [rocm_smi.h](#)

7.18 rsmi_version_t Struct Reference

This structure holds version information.

```
#include <rocm_smi.h>
```

Data Fields

- `uint32_t major`
Major version.
- `uint32_t minor`
Minor version.
- `uint32_t patch`
Patch, build or stepping version.
- `const char * build`
Build string.

7.18.1 Detailed Description

This structure holds version information.

The documentation for this struct was generated from the following file:

- [rocm_smi.h](#)

Chapter 8

File Documentation

8.1 rocm_smi.h File Reference

The rocm_smi library api is new, and therefore subject to change either at the ABI or API level. Instead of marking every function prototype as "unstable", we are instead saying the API is unstable (i.e., changes are possible) while the major version remains 0. This means that if the API/ABI changes, we will not increment the major version to 1. Once the ABI stabilizes, we will increment the major version to 1, and thereafter increment it on all ABI breaks.

```
#include <stdint.h>
#include <stddef.h>
#include <stdbool.h>
#include "rocm_smi/kfd_ioctl.h"
```

Data Structures

- struct [rsmi_counter_value_t](#)
- struct [rsmi_evt_notification_data_t](#)
- struct [rsmi_utilization_counter_t](#)
The utilization counter data.
- struct [rsmi_retired_page_record_t](#)
Reserved Memory Page Record.
- struct [rsmi_power_profile_status_t](#)
This structure contains information about which power profiles are supported by the system for a given device, and which power profile is currently active.
- struct [rsmi_frequencies_t](#)
This structure holds information about clock frequencies.
- struct [rsmi_pcie_bandwidth_t](#)
This structure holds information about the possible PCIe bandwidths. Specifically, the possible transfer rates and their associated numbers of lanes are stored here.
- struct [rsmi_version_t](#)
This structure holds version information.
- struct [rsmi_range_t](#)
This structure represents a range (e.g., frequencies or voltages).
- struct [rsmi_od_vddc_point_t](#)
This structure represents a point on the frequency-voltage plane.
- struct [rsmi_freq_volt_region_t](#)

This structure holds 2 *rsmi_range_t*'s, one for frequency and one for voltage. These 2 ranges indicate the range of possible values for the corresponding *rsmi_od_vddc_point_t*.

- struct [rsmi_od_volt_curve_t](#)
- struct [rsmi_od_volt_freq_data_t](#)

This structure holds the frequency-voltage values for a device.

- struct [metrics_table_header_t](#)

The following structures hold the gpu metrics values for a device.

- struct [rsmi_gpu_metrics_t](#)
- struct [rsmi_error_count_t](#)

This structure holds error counts.

- struct [rsmi_process_info_t](#)

This structure contains information specific to a process.

- union [id](#)

This union holds the value of an *rsmi_func_id_iter_handle_t*. The value may be a function name, or an enumerated variant value of types such as *rsmi_memory_type_t*, *rsmi_temperature_metric_t*, etc.

Macros

- #define [RSMI_MAX_NUM_FREQUENCIES](#) 32
Guaranteed maximum possible number of supported frequencies.
- #define [RSMI_MAX_FAN_SPEED](#) 255
- #define [RSMI_NUM_VOLTAGE_CURVE_POINTS](#) 3
The number of points that make up a voltage-frequency curve definition.
- #define [RSMI_EVENT_MASK_FROM_INDEX](#)(i) (1ULL << ((i) - 1))
- #define [MAX_EVENT_NOTIFICATION_MSG_SIZE](#) 64
Maximum number of characters an event notification message will be.
- #define [RSMI_MAX_NUM_POWER_PROFILES](#) (sizeof([rsmi_bit_field_t](#)) * 8)
Number of possible power profiles that a system could support.
- #define [RSMI_GPU_METRICS_API_FORMAT_VER](#) 1
The following structure holds the gpu metrics values for a device.
- #define [RSMI_GPU_METRICS_API_CONTENT_VER_1](#) 1
- #define [RSMI_GPU_METRICS_API_CONTENT_VER_2](#) 2
- #define [RSMI_GPU_METRICS_API_CONTENT_VER_3](#) 3
- #define [RSMI_NUM_HBM_INSTANCES](#) 4
- #define [CENTRIGRADE_TO_MILLI_CENTIGRADE](#) 1000
- #define [RSMI_DEFAULT_VARIANT](#) 0xFFFFFFFFFFFFFFFF

Typedefs

- typedef uintptr_t [rsmi_event_handle_t](#)
Handle to performance event counter.
- typedef uint64_t [rsmi_bit_field_t](#)
Bitfield used in various RSMI calls.
- typedef enum [_RSMI_IO_LINK_TYPE](#) [RSMI_IO_LINK_TYPE](#)
Types for IO Link.
- typedef struct [rsmi_func_id_iter_handle](#) * [rsmi_func_id_iter_handle_t](#)
Opaque handle to function-support object.
- typedef union [id](#) [rsmi_func_id_value_t](#)
This union holds the value of an *rsmi_func_id_iter_handle_t*. The value may be a function name, or an enumerated variant value of types such as *rsmi_memory_type_t*, *rsmi_temperature_metric_t*, etc.

Enumerations

- enum `rsmi_status_t` {
`RSMI_STATUS_SUCCESS` = 0x0, `RSMI_STATUS_INVALID_ARGS`, `RSMI_STATUS_NOT_SUPPORTED`,
`RSMI_STATUS_FILE_ERROR`,
`RSMI_STATUS_PERMISSION`, `RSMI_STATUS_OUT_OF_RESOURCES`, `RSMI_STATUS_INTERNAL_EXCEPTION`,
`RSMI_STATUS_INPUT_OUT_OF_BOUNDS`,
`RSMI_STATUS_INIT_ERROR`, **`RSMI_INITIALIZATION_ERROR`** = `RSMI_STATUS_INIT_ERROR`,
`RSMI_STATUS_NOT_YET_IMPLEMENTED`, `RSMI_STATUS_NOT_FOUND`,
`RSMI_STATUS_INSUFFICIENT_SIZE`, `RSMI_STATUS_INTERRUPT`, `RSMI_STATUS_UNEXPECTED_SIZE`,
`RSMI_STATUS_NO_DATA`,
`RSMI_STATUS_UNEXPECTED_DATA`, `RSMI_STATUS_BUSY`, `RSMI_STATUS_REFCOUNT_OVERFLOW`,
`RSMI_STATUS_SETTING_UNAVAILABLE`,
`RSMI_STATUS_AMDGPU_RESTART_ERR`, `RSMI_STATUS_UNKNOWN_ERROR` = 0xFFFFFFFF }

Error codes returned by rocm_smi_lib functions.
- enum `rsmi_init_flags_t` { `RSMI_INIT_FLAG_ALL_GPUS` = 0x1, `RSMI_INIT_FLAG_RESRV_TEST1` =
0x8000000000000000 }

Initialization flags.
- enum `rsmi_dev_perf_level_t` {
`RSMI_DEV_PERF_LEVEL_AUTO` = 0, **`RSMI_DEV_PERF_LEVEL_FIRST`** = `RSMI_DEV_PERF_LEVEL_`↵
`AUTO`, `RSMI_DEV_PERF_LEVEL_LOW`, `RSMI_DEV_PERF_LEVEL_HIGH`,
`RSMI_DEV_PERF_LEVEL_MANUAL`, `RSMI_DEV_PERF_LEVEL_STABLE_STD`, `RSMI_DEV_PERF_LEVEL_STABLE_PEA`↵
`RSMI_DEV_PERF_LEVEL_STABLE_MIN_MCLK`,
`RSMI_DEV_PERF_LEVEL_STABLE_MIN_SCLK`, `RSMI_DEV_PERF_LEVEL_DETERMINISM`, **`RSMI_D`↵
`EV_PERF_LEVEL_LAST`** = `RSMI_DEV_PERF_LEVEL_DETERMINISM`, `RSMI_DEV_PERF_LEVEL_UNKNOWN`
= 0x100 }

PowerPlay performance levels.
- enum `rsmi_sw_component_t` { **`RSMI_SW_COMP_FIRST`** = 0x0, `RSMI_SW_COMP_DRIVER` = `RSMI_SW`↵
`_COMP_FIRST`, **`RSMI_SW_COMP_LAST`** = `RSMI_SW_COMP_DRIVER` }

Available clock types.
- enum `rsmi_event_group_t` { `RSMI_EVNT_GRP_XGMI` = 0, `RSMI_EVNT_GRP_XGMI_DATA_OUT` = 10, **`R`↵
`SMI_EVNT_GRP_INVALID`** = 0xFFFFFFFF }

Enum denoting an event group. The value of the enum is the base value for all the event enums in the group.
- enum `rsmi_event_type_t` {
`RSMI_EVNT_FIRST` = `RSMI_EVNT_GRP_XGMI`, **`RSMI_EVNT_XGMI_FIRST`** = `RSMI_EVNT_GRP_XGMI`,
`RSMI_EVNT_XGMI_0_NOP_TX` = `RSMI_EVNT_XGMI_FIRST`, `RSMI_EVNT_XGMI_0_REQUEST_TX`,
`RSMI_EVNT_XGMI_0_RESPONSE_TX`, `RSMI_EVNT_XGMI_0_BEATS_TX`, `RSMI_EVNT_XGMI_1_NOP_TX`,
`RSMI_EVNT_XGMI_1_REQUEST_TX`,
`RSMI_EVNT_XGMI_1_RESPONSE_TX`, `RSMI_EVNT_XGMI_1_BEATS_TX`, **`RSMI_EVNT_XGMI_LAST`** =
`RSMI_EVNT_XGMI_1_BEATS_TX`, **`RSMI_EVNT_XGMI_DATA_OUT_FIRST`** = `RSMI_EVNT_GRP_XGM`↵
`I_DATA_OUT`,
`RSMI_EVNT_XGMI_DATA_OUT_0` = `RSMI_EVNT_XGMI_DATA_OUT_FIRST`, **`RSMI_EVNT_XGMI_DATA_OUT_1`**,
`RSMI_EVNT_XGMI_DATA_OUT_2`, `RSMI_EVNT_XGMI_DATA_OUT_3`,
`RSMI_EVNT_XGMI_DATA_OUT_4`, `RSMI_EVNT_XGMI_DATA_OUT_5`, **`RSMI_EVNT_XGMI_DATA_O`↵
`UT_LAST`** = `RSMI_EVNT_XGMI_DATA_OUT_5`, **`RSMI_EVNT_LAST`** = `RSMI_EVNT_XGMI_DATA_OUT`↵
`_LAST` }

Event type enum. Events belonging to a particular event group `rsmi_event_group_t` should begin enumerating at the `rsmi_event_group_t` value for that group.
- enum `rsmi_counter_command_t` { `RSMI_CNTR_CMD_START` = 0, `RSMI_CNTR_CMD_STOP` }
- enum `rsmi_evt_notification_type_t` {
`RSMI_EVT_NOTIF_VMFALUT` = `KFD_SMI_EVENT_VMFALUT`, **`RSMI_EVT_NOTIF_FIRST`** = `RSMI_EV`↵
`T_NOTIF_VMFALUT`, **`RSMI_EVT_NOTIF_THERMAL_THROTTLE`** = `KFD_SMI_EVENT_THERMAL_THR`↵
`OTTLE`, **`RSMI_EVT_NOTIF_GPU_PRE_RESET`** = `KFD_SMI_EVENT_GPU_PRE_RESET`,
`RSMI_EVT_NOTIF_GPU_POST_RESET` = `KFD_SMI_EVENT_GPU_POST_RESET`, **`RSMI_EVT_NOTIF`↵
`_LAST`** = `RSMI_EVT_NOTIF_GPU_POST_RESET` }

- enum `rsmi_clk_type_t` {
`RSMI_CLK_TYPE_SYS` = 0x0, `RSMI_CLK_TYPE_FIRST` = `RSMI_CLK_TYPE_SYS`, `RSMI_CLK_TYPE_DF`,
`RSMI_CLK_TYPE_DCEF`,
`RSMI_CLK_TYPE_SOC`, `RSMI_CLK_TYPE_MEM`, `RSMI_CLK_TYPE_PCIE`, `RSMI_CLK_TYPE_LAST` =
`RSMI_CLK_TYPE_MEM`,
`RSMI_CLK_INVALID` = 0xFFFFFFFF }
- enum `rsmi_compute_partition_type_t` {
`RSMI_COMPUTE_PARTITION_INVALID` = 0, `RSMI_COMPUTE_PARTITION_CPX`, `RSMI_COMPUTE_PARTITION_SPX`,
`RSMI_COMPUTE_PARTITION_DPX`,
`RSMI_COMPUTE_PARTITION_TPX`, `RSMI_COMPUTE_PARTITION_QPX` }
Compute Partition. This enum is used to identify various compute partitioning settings.
- enum `rsmi_nps_mode_type_t` {
`RSMI_MEMORY_PARTITION_UNKNOWN` = 0, `RSMI_MEMORY_PARTITION_NPS1`, `RSMI_MEMORY_PARTITION_NPS2`,
`RSMI_MEMORY_PARTITION_NPS4`,
`RSMI_MEMORY_PARTITION_NPS8` }
NPS Modes. This enum is used to identify various NPS mode types.
- enum `rsmi_temperature_metric_t` {
`RSMI_TEMP_CURRENT` = 0x0, `RSMI_TEMP_FIRST` = `RSMI_TEMP_CURRENT`, `RSMI_TEMP_MAX`,
`RSMI_TEMP_MIN`,
`RSMI_TEMP_MAX_HYST`, `RSMI_TEMP_MIN_HYST`, `RSMI_TEMP_CRITICAL`, `RSMI_TEMP_CRITICAL_HYST`,
`RSMI_TEMP_EMERGENCY`, `RSMI_TEMP_EMERGENCY_HYST`, `RSMI_TEMP_CRIT_MIN`, `RSMI_TEMP_CRIT_MIN_HYST`,
`RSMI_TEMP_OFFSET`, `RSMI_TEMP_LOWEST`, `RSMI_TEMP_HIGHEST`, `RSMI_TEMP_LAST` = `RSMI_TEMP_HIGHEST` }
Temperature Metrics. This enum is used to identify various temperature metrics. Corresponding values will be in millidegrees Celcius.
- enum `rsmi_temperature_type_t` {
`RSMI_TEMP_TYPE_FIRST` = 0, `RSMI_TEMP_TYPE_EDGE` = `RSMI_TEMP_TYPE_FIRST`, `RSMI_TEMP_TYPE_JUNCTION`,
`RSMI_TEMP_TYPE_MEMORY`,
`RSMI_TEMP_TYPE_HBM_0`, `RSMI_TEMP_TYPE_HBM_1`, `RSMI_TEMP_TYPE_HBM_2`, `RSMI_TEMP_TYPE_HBM_3`,
`RSMI_TEMP_TYPE_LAST` = `RSMI_TEMP_TYPE_HBM_3`, `RSMI_TEMP_TYPE_INVALID` = 0xFFFFFFFF }
- enum `rsmi_voltage_metric_t` {
`RSMI_VOLT_CURRENT` = 0x0, `RSMI_VOLT_FIRST` = `RSMI_VOLT_CURRENT`, `RSMI_VOLT_MAX`,
`RSMI_VOLT_MIN_CRIT`,
`RSMI_VOLT_MIN`, `RSMI_VOLT_MAX_CRIT`, `RSMI_VOLT_AVERAGE`, `RSMI_VOLT_LOWEST`,
`RSMI_VOLT_HIGHEST`, `RSMI_VOLT_LAST` = `RSMI_VOLT_HIGHEST` }
Voltage Metrics. This enum is used to identify various Voltage metrics. Corresponding values will be in millivolt.
- enum `rsmi_voltage_type_t` { `RSMI_VOLT_TYPE_FIRST` = 0, `RSMI_VOLT_TYPE_VDDGFX` = `RSMI_VOLT_TYPE_FIRST`, `RSMI_VOLT_TYPE_INVALID` = 0xFFFFFFFF }
- enum `rsmi_power_profile_preset_masks_t` {
`RSMI_PWR_PROF_PRST_CUSTOM_MASK` = 0x1, `RSMI_PWR_PROF_PRST_VIDEO_MASK` = 0x2,
`RSMI_PWR_PROF_PRST_POWER_SAVING_MASK` = 0x4, `RSMI_PWR_PROF_PRST_COMPUTE_MASK`
= 0x8,
`RSMI_PWR_PROF_PRST_VR_MASK` = 0x10, `RSMI_PWR_PROF_PRST_3D_FULL_SCR_MASK` = 0x20,
`RSMI_PWR_PROF_PRST_BOOTUP_DEFAULT` = 0x40, `RSMI_PWR_PROF_PRST_LAST` = `RSMI_PWR_PROF_PRST_BOOTUP_DEFAULT`,
`RSMI_PWR_PROF_PRST_INVALID` = 0xFFFFFFFFFFFFFFFF }
- enum `rsmi_gpu_block_t` {
`RSMI_GPU_BLOCK_INVALID` = 0x0000000000000000, `RSMI_GPU_BLOCK_FIRST` = 0x0000000000000001,
`RSMI_GPU_BLOCK_UMC` = `RSMI_GPU_BLOCK_FIRST`, `RSMI_GPU_BLOCK_SDMA` = 0x0000000000000002,
`RSMI_GPU_BLOCK_GFX` = 0x0000000000000004, `RSMI_GPU_BLOCK_MMHUB` = 0x0000000000000008,
`RSMI_GPU_BLOCK_ATHUB` = 0x0000000000000010, `RSMI_GPU_BLOCK_PCIE_BIF` = 0x0000000000000020,

```
RSMI_GPU_BLOCK_HDP = 0x0000000000000040, RSMI_GPU_BLOCK_XGMI_WAFL = 0x0000000000000080,
RSMI_GPU_BLOCK_DF = 0x0000000000000100, RSMI_GPU_BLOCK_SMN = 0x0000000000000200,
RSMI_GPU_BLOCK_SEM = 0x0000000000000400, RSMI_GPU_BLOCK_MPO = 0x0000000000000800,
RSMI_GPU_BLOCK_MP1 = 0x0000000000001000, RSMI_GPU_BLOCK_FUSE = 0x0000000000002000,
RSMI_GPU_BLOCK_LAST = RSMI_GPU_BLOCK_FUSE, RSMI_GPU_BLOCK_RESERVED = 0x8000000000000000
}
```

This enum is used to identify different GPU blocks.

- enum `rsmi_ras_err_state_t` {
RSMI_RAS_ERR_STATE_NONE = 0, **RSMI_RAS_ERR_STATE_DISABLED**, **RSMI_RAS_ERR_STATE_PARITY**,
RSMI_RAS_ERR_STATE_SING_C,
RSMI_RAS_ERR_STATE_MULT_UC, **RSMI_RAS_ERR_STATE_POISON**, **RSMI_RAS_ERR_STATE_ENABLED**,
RSMI_RAS_ERR_STATE_LAST = **RSMI_RAS_ERR_STATE_ENABLED**,
RSMI_RAS_ERR_STATE_INVALID = 0xFFFFFFFF }

The current ECC state.

- enum `rsmi_memory_type_t` {
RSMI_MEM_TYPE_FIRST = 0, **RSMI_MEM_TYPE_VRAM** = **RSMI_MEM_TYPE_FIRST**, **RSMI_MEM_TYPE_VIS_VRAM**,
RSMI_MEM_TYPE_GTT,
RSMI_MEM_TYPE_LAST = **RSMI_MEM_TYPE_GTT** }

Types of memory.

- enum `rsmi_freq_ind_t` { **RSMI_FREQ_IND_MIN** = 0, **RSMI_FREQ_IND_MAX** = 1, **RSMI_FREQ_IND_INVALID**
= 0xFFFFFFFF }

The values of this enum are used as frequency identifiers.

- enum `rsmi_fw_block_t` {
RSMI_FW_BLOCK_FIRST = 0, **RSMI_FW_BLOCK_ASD** = **RSMI_FW_BLOCK_FIRST**, **RSMI_FW_BLOCK_CK_CE**,
RSMI_FW_BLOCK_DMCU,
RSMI_FW_BLOCK_MC, **RSMI_FW_BLOCK_ME**, **RSMI_FW_BLOCK_MEC**, **RSMI_FW_BLOCK_MEC2**,
RSMI_FW_BLOCK_PFP, **RSMI_FW_BLOCK_RLC**, **RSMI_FW_BLOCK_RLC_SRLC**, **RSMI_FW_BLOCK_K_RLC_SRLG**,
RSMI_FW_BLOCK_RLC_SRLS, **RSMI_FW_BLOCK_SDMA**, **RSMI_FW_BLOCK_SDMA2**, **RSMI_FW_BLOCK_SMC**,
RSMI_FW_BLOCK_SOS, **RSMI_FW_BLOCK_TA_RAS**, **RSMI_FW_BLOCK_TA_XGMI**, **RSMI_FW_BLOCK_UVD**,
RSMI_FW_BLOCK_VCE, **RSMI_FW_BLOCK_VCN**, **RSMI_FW_BLOCK_LAST** = **RSMI_FW_BLOCK_VCN** }

The values of this enum are used to identify the various firmware blocks.

- enum `rsmi_xgmi_status_t` { **RSMI_XGMI_STATUS_NO_ERRORS** = 0, **RSMI_XGMI_STATUS_ERROR**,
RSMI_XGMI_STATUS_MULTIPLE_ERRORS }

XGMI Status.

- enum `rsmi_memory_page_status_t` { **RSMI_MEM_PAGE_STATUS_RESERVED** = 0, **RSMI_MEM_PAGE_STATUS_PENDING**,
RSMI_MEM_PAGE_STATUS_UNRESERVABLE }

Reserved Memory Page States.

- enum `_RSMI_IO_LINK_TYPE` {
RSMI_IOLINK_TYPE_UNDEFINED = 0, **RSMI_IOLINK_TYPE_PCIEEXPRESS** = 1, **RSMI_IOLINK_TYPE_XGMI**
= 2, **RSMI_IOLINK_TYPE_NUMIOLINKTYPES**,
RSMI_IOLINK_TYPE_SIZE = 0xFFFFFFFF }

Types for IO Link.

- enum `RSMI_UTILIZATION_COUNTER_TYPE` { **RSMI_UTILIZATION_COUNTER_FIRST** = 0, **RSMI_COARSE_GRAIN_MEM_ACTIVITY**,
RSMI_UTILIZATION_COUNTER_LAST = **RSMI_COARSE_GRAIN_MEM_ACTIVITY** }

The utilization counter type.

Functions

- `rsmi_status_t rsmi_init` (uint64_t init_flags)

- Initialize ROCm SMI.*

 - [rsmi_status_t rsmi_shut_down](#) (void)
- Shutdown ROCm SMI.*

 - [rsmi_status_t rsmi_num_monitor_devices](#) (uint32_t *num_devices)

Get the number of devices that have monitor information.
- [rsmi_status_t rsmi_dev_id_get](#) (uint32_t dv_ind, uint16_t *id)

Get the device id associated with the device with provided device index.
- [rsmi_status_t rsmi_dev_sku_get](#) (uint32_t dv_ind, char *sku)

Get the SKU for a desired device associated with the device with provided device index.
- [rsmi_status_t rsmi_dev_vendor_id_get](#) (uint32_t dv_ind, uint16_t *id)

Get the device vendor id associated with the device with provided device index.
- [rsmi_status_t rsmi_dev_name_get](#) (uint32_t dv_ind, char *name, size_t len)

Get the name string of a gpu device.
- [rsmi_status_t rsmi_dev_brand_get](#) (uint32_t dv_ind, char *brand, uint32_t len)

Get the brand string of a gpu device.
- [rsmi_status_t rsmi_dev_vendor_name_get](#) (uint32_t dv_ind, char *name, size_t len)

Get the name string for a give vendor ID.
- [rsmi_status_t rsmi_dev_vram_vendor_get](#) (uint32_t dv_ind, char *brand, uint32_t len)

Get the vram vendor string of a gpu device.
- [rsmi_status_t rsmi_dev_serial_number_get](#) (uint32_t dv_ind, char *serial_num, uint32_t len)

Get the serial number string for a device.
- [rsmi_status_t rsmi_dev_subsystem_id_get](#) (uint32_t dv_ind, uint16_t *id)

Get the subsystem device id associated with the device with provided device index.
- [rsmi_status_t rsmi_dev_subsystem_name_get](#) (uint32_t dv_ind, char *name, size_t len)

Get the name string for the device subsystem.
- [rsmi_status_t rsmi_dev_drm_render_minor_get](#) (uint32_t dv_ind, uint32_t *minor)

Get the drm minor number associated with this device.
- [rsmi_status_t rsmi_dev_subsystem_vendor_id_get](#) (uint32_t dv_ind, uint16_t *id)

Get the device subsystem vendor id associated with the device with provided device index.
- [rsmi_status_t rsmi_dev_unique_id_get](#) (uint32_t dv_ind, uint64_t *id)

Get Unique ID.
- [rsmi_status_t rsmi_dev_pci_bandwidth_get](#) (uint32_t dv_ind, [rsmi_pcie_bandwidth_t](#) *bandwidth)

Get the list of possible PCIe bandwidths that are available.
- [rsmi_status_t rsmi_dev_pci_id_get](#) (uint32_t dv_ind, uint64_t *bdfid)

Get the unique PCI device identifier associated for a device.
- [rsmi_status_t rsmi_topo_numa_affinity_get](#) (uint32_t dv_ind, uint32_t *numa_node)

Get the NUMA node associated with a device.
- [rsmi_status_t rsmi_dev_pci_throughput_get](#) (uint32_t dv_ind, uint64_t *sent, uint64_t *received, uint64_t *max_pkt_sz)

Get PCIe traffic information.
- [rsmi_status_t rsmi_dev_pci_replay_counter_get](#) (uint32_t dv_ind, uint64_t *counter)

Get PCIe replay counter.
- [rsmi_status_t rsmi_dev_pci_bandwidth_set](#) (uint32_t dv_ind, uint64_t bw_bitmask)

Control the set of allowed PCIe bandwidths that can be used.
- [rsmi_status_t rsmi_dev_power_ave_get](#) (uint32_t dv_ind, uint32_t sensor_ind, uint64_t *power)

Get the average power consumption of the device with provided device index.
- [rsmi_status_t rsmi_dev_energy_count_get](#) (uint32_t dv_ind, uint64_t *power, float *counter_resolution, uint64_t *timestamp)

Get the energy accumulator counter of the device with provided device index.
- [rsmi_status_t rsmi_dev_power_cap_get](#) (uint32_t dv_ind, uint32_t sensor_ind, uint64_t *cap)

Get the cap on power which, when reached, causes the system to take action to reduce power.

- [rsmi_status_t rsmi_dev_power_cap_default_get](#) (uint32_t dv_ind, uint64_t *default_cap)
Get the default power cap for the device specified by dv_ind.
- [rsmi_status_t rsmi_dev_power_cap_range_get](#) (uint32_t dv_ind, uint32_t sensor_ind, uint64_t *max, uint64_t *min)
Get the range of valid values for the power cap.
- [rsmi_status_t rsmi_dev_power_cap_set](#) (uint32_t dv_ind, uint32_t sensor_ind, uint64_t cap)
Set the power cap value.
- [rsmi_status_t rsmi_dev_power_profile_set](#) (uint32_t dv_ind, uint32_t reserved, [rsmi_power_profile_preset_masks_t](#) profile)
Set the power profile.
- [rsmi_status_t rsmi_dev_memory_total_get](#) (uint32_t dv_ind, [rsmi_memory_type_t](#) mem_type, uint64_t *total)
Get the total amount of memory that exists.
- [rsmi_status_t rsmi_dev_memory_usage_get](#) (uint32_t dv_ind, [rsmi_memory_type_t](#) mem_type, uint64_t *used)
Get the current memory usage.
- [rsmi_status_t rsmi_dev_memory_busy_percent_get](#) (uint32_t dv_ind, uint32_t *busy_percent)
Get percentage of time any device memory is being used.
- [rsmi_status_t rsmi_dev_memory_reserved_pages_get](#) (uint32_t dv_ind, uint32_t *num_pages, [rsmi_retired_page_record_t](#) *records)
Get information about reserved ("retired") memory pages.
- [rsmi_status_t rsmi_dev_fan_rpms_get](#) (uint32_t dv_ind, uint32_t sensor_ind, int64_t *speed)
Get the fan speed in RPMs of the device with the specified device index and 0-based sensor index.
- [rsmi_status_t rsmi_dev_fan_speed_get](#) (uint32_t dv_ind, uint32_t sensor_ind, int64_t *speed)
Get the fan speed for the specified device as a value relative to [RSMI_MAX_FAN_SPEED](#).
- [rsmi_status_t rsmi_dev_fan_speed_max_get](#) (uint32_t dv_ind, uint32_t sensor_ind, uint64_t *max_speed)
Get the max. fan speed of the device with provided device index.
- [rsmi_status_t rsmi_dev_temp_metric_get](#) (uint32_t dv_ind, uint32_t sensor_type, [rsmi_temperature_metric_t](#) metric, int64_t *temperature)
Get the temperature metric value for the specified metric, from the specified temperature sensor on the specified device.
- [rsmi_status_t rsmi_dev_volt_metric_get](#) (uint32_t dv_ind, [rsmi_voltage_type_t](#) sensor_type, [rsmi_voltage_metric_t](#) metric, int64_t *voltage)
Get the voltage metric value for the specified metric, from the specified voltage sensor on the specified device.
- [rsmi_status_t rsmi_dev_fan_reset](#) (uint32_t dv_ind, uint32_t sensor_ind)
Reset the fan to automatic driver control.
- [rsmi_status_t rsmi_dev_fan_speed_set](#) (uint32_t dv_ind, uint32_t sensor_ind, uint64_t speed)
Set the fan speed for the specified device with the provided speed, in RPMs.
- [rsmi_status_t rsmi_dev_busy_percent_get](#) (uint32_t dv_ind, uint32_t *busy_percent)
Get percentage of time device is busy doing any processing.
- [rsmi_status_t rsmi_utilization_count_get](#) (uint32_t dv_ind, [rsmi_utilization_counter_t](#) utilization_counters[], uint32_t count, uint64_t *timestamp)
Get coarse grain utilization counter of the specified device.
- [rsmi_status_t rsmi_dev_perf_level_get](#) (uint32_t dv_ind, [rsmi_dev_perf_level_t](#) *perf)
Get the performance level of the device with provided device index.
- [rsmi_status_t rsmi_perf_determinism_mode_set](#) (uint32_t dv_ind, uint64_t clkvalue)
Enter performance determinism mode with provided device index.
- [rsmi_status_t rsmi_dev_overdrive_level_get](#) (uint32_t dv_ind, uint32_t *od)
Get the overdrive percent associated with the device with provided device index.
- [rsmi_status_t rsmi_dev_mem_overdrive_level_get](#) (uint32_t dv_ind, uint32_t *od)
Get the memory clock overdrive percent associated with the device with provided device index.
- [rsmi_status_t rsmi_dev_gpu_clk_freq_get](#) (uint32_t dv_ind, [rsmi_clk_type_t](#) clk_type, [rsmi_frequencies_t](#) *f)

- Get the list of possible system clock speeds of device for a specified clock type.*

 - [rsmi_status_t rsmi_dev_gpu_reset](#) (int32_t dv_ind)

Reset the gpu associated with the device with provided device index.
- [rsmi_status_t rsmi_dev_od_volt_info_get](#) (uint32_t dv_ind, [rsmi_od_volt_freq_data_t](#) *odv)

This function retrieves the voltage/frequency curve information.
- [rsmi_status_t rsmi_dev_gpu_metrics_info_get](#) (uint32_t dv_ind, [rsmi_gpu_metrics_t](#) *pgpu_metrics)

This function retrieves the gpu metrics information.
- [rsmi_status_t rsmi_dev_clk_range_set](#) (uint32_t dv_ind, uint64_t minclkvalue, uint64_t maxclkvalue, [rsmi_clk_type_t](#) clkType)

This function sets the clock range information.
- [rsmi_status_t rsmi_dev_od_clk_info_set](#) (uint32_t dv_ind, [rsmi_freq_ind_t](#) level, uint64_t clkvalue, [rsmi_clk_type_t](#) clkType)

This function sets the clock frequency information.
- [rsmi_status_t rsmi_dev_od_volt_info_set](#) (uint32_t dv_ind, uint32_t vpoint, uint64_t clkvalue, uint64_t voltage)

This function sets 1 of the 3 voltage curve points.
- [rsmi_status_t rsmi_dev_od_volt_curve_regions_get](#) (uint32_t dv_ind, uint32_t *num_regions, [rsmi_freq_volt_region_t](#) *buffer)

This function will retrieve the current valid regions in the frequency/voltage space.
- [rsmi_status_t rsmi_dev_power_profile_presets_get](#) (uint32_t dv_ind, uint32_t sensor_ind, [rsmi_power_profile_status_t](#) *status)

Get the list of available preset power profiles and an indication of which profile is currently active.
- [rsmi_status_t rsmi_dev_perf_level_set](#) (int32_t dv_ind, [rsmi_dev_perf_level_t](#) perf_lvl)

Set the PowerPlay performance level associated with the device with provided device index with the provided value.
- [rsmi_status_t rsmi_dev_perf_level_set_v1](#) (uint32_t dv_ind, [rsmi_dev_perf_level_t](#) perf_lvl)

Set the PowerPlay performance level associated with the device with provided device index with the provided value.
- [rsmi_status_t rsmi_dev_overdrive_level_set](#) (int32_t dv_ind, uint32_t od)

Set the overdrive percent associated with the device with provided device index with the provided value. See details for WARNING.
- [rsmi_status_t rsmi_dev_overdrive_level_set_v1](#) (uint32_t dv_ind, uint32_t od)

Set the overdrive percent associated with the device with provided device index with the provided value. See details for WARNING.
- [rsmi_status_t rsmi_dev_gpu_clk_freq_set](#) (uint32_t dv_ind, [rsmi_clk_type_t](#) clk_type, uint64_t freq_bitmask)

Control the set of allowed frequencies that can be used for the specified clock.
- [rsmi_status_t rsmi_version_get](#) ([rsmi_version_t](#) *version)

Get the build version information for the currently running build of RSMI.
- [rsmi_status_t rsmi_version_str_get](#) ([rsmi_sw_component_t](#) component, char *ver_str, uint32_t len)

Get the driver version string for the current system.
- [rsmi_status_t rsmi_dev_vbios_version_get](#) (uint32_t dv_ind, char *vbios, uint32_t len)

Get the VBIOS identifier string.
- [rsmi_status_t rsmi_dev_firmware_version_get](#) (uint32_t dv_ind, [rsmi_fw_block_t](#) block, uint64_t *fw_version)

Get the firmware versions for a device.
- [rsmi_status_t rsmi_dev_ecc_count_get](#) (uint32_t dv_ind, [rsmi_gpu_block_t](#) block, [rsmi_error_count_t](#) *ec)

Retrieve the error counts for a GPU block.
- [rsmi_status_t rsmi_dev_ecc_enabled_get](#) (uint32_t dv_ind, uint64_t *enabled_blocks)

Retrieve the enabled ECC bit-mask.
- [rsmi_status_t rsmi_dev_ecc_status_get](#) (uint32_t dv_ind, [rsmi_gpu_block_t](#) block, [rsmi_ras_err_state_t](#) *state)

Retrieve the ECC status for a GPU block.
- [rsmi_status_t rsmi_status_string](#) ([rsmi_status_t](#) status, const char **status_string)

Get a description of a provided RSMI error status.
- [rsmi_status_t rsmi_dev_counter_group_supported](#) (uint32_t dv_ind, [rsmi_event_group_t](#) group)

- Tell if an event group is supported by a given device.*
- [rsmi_status_t rsmi_dev_counter_create](#) (uint32_t dv_ind, [rsmi_event_type_t](#) type, [rsmi_event_handle_t](#) *evnt_handle)
Create a performance counter object.
 - [rsmi_status_t rsmi_dev_counter_destroy](#) ([rsmi_event_handle_t](#) evnt_handle)
Deallocate a performance counter object.
 - [rsmi_status_t rsmi_counter_control](#) ([rsmi_event_handle_t](#) evt_handle, [rsmi_counter_command_t](#) cmd, void *cmd_args)
Issue performance counter control commands.
 - [rsmi_status_t rsmi_counter_read](#) ([rsmi_event_handle_t](#) evt_handle, [rsmi_counter_value_t](#) *value)
Read the current value of a performance counter.
 - [rsmi_status_t rsmi_counter_available_counters_get](#) (uint32_t dv_ind, [rsmi_event_group_t](#) grp, uint32_t *available)
Get the number of currently available counters.
 - [rsmi_status_t rsmi_compute_process_info_get](#) ([rsmi_process_info_t](#) *procs, uint32_t *num_items)
Get process information about processes currently using GPU.
 - [rsmi_status_t rsmi_compute_process_info_by_pid_get](#) (uint32_t pid, [rsmi_process_info_t](#) *proc)
Get process information about a specific process.
 - [rsmi_status_t rsmi_compute_process_gpus_get](#) (uint32_t pid, uint32_t *dv_indices, uint32_t *num_devices)
Get the device indices currently being used by a process.
 - [rsmi_status_t rsmi_dev_xgmi_error_status](#) (uint32_t dv_ind, [rsmi_xgmi_status_t](#) *status)
Retrieve the XGMI error status for a device.
 - [rsmi_status_t rsmi_dev_xgmi_error_reset](#) (uint32_t dv_ind)
Reset the XGMI error status for a device.
 - [rsmi_status_t rsmi_dev_xgmi_hive_id_get](#) (uint32_t dv_ind, uint64_t *hive_id)
Retrieve the XGMI hive id for a device.
 - [rsmi_status_t rsmi_topo_get_numa_node_number](#) (uint32_t dv_ind, uint32_t *numa_node)
Retrieve the NUMA CPU node number for a device.
 - [rsmi_status_t rsmi_topo_get_link_weight](#) (uint32_t dv_ind_src, uint32_t dv_ind_dst, uint64_t *weight)
Retrieve the weight for a connection between 2 GPUs.
 - [rsmi_status_t rsmi_minmax_bandwidth_get](#) (uint32_t dv_ind_src, uint32_t dv_ind_dst, uint64_t *min_bandwidth, uint64_t *max_bandwidth)
Retrieve minimal and maximal io link bandwidth between 2 GPUs.
 - [rsmi_status_t rsmi_topo_get_link_type](#) (uint32_t dv_ind_src, uint32_t dv_ind_dst, uint64_t *hops, [RSMI_IO_LINK_TYPE](#) *type)
Retrieve the hops and the connection type between 2 GPUs.
 - [rsmi_status_t rsmi_is_P2P_accessible](#) (uint32_t dv_ind_src, uint32_t dv_ind_dst, bool *accessible)
Return P2P availability status between 2 GPUs.
 - [rsmi_status_t rsmi_dev_compute_partition_get](#) (uint32_t dv_ind, char *compute_partition, uint32_t len)
Retrieves the current compute partitioning for a desired device.
 - [rsmi_status_t rsmi_dev_compute_partition_set](#) (uint32_t dv_ind, [rsmi_compute_partition_type_t](#) compute_partition)
Modifies a selected device's compute partition setting.
 - [rsmi_status_t rsmi_dev_compute_partition_reset](#) (uint32_t dv_ind)
Reverts a selected device's compute partition setting back to its boot state.
 - [rsmi_status_t rsmi_dev_nps_mode_get](#) (uint32_t dv_ind, char *nps_mode, uint32_t len)
Retrieves the NPS mode (memory partition) for a desired device.
 - [rsmi_status_t rsmi_dev_nps_mode_set](#) (uint32_t dv_ind, [rsmi_nps_mode_type_t](#) nps_mode)
Modifies a selected device's NPS mode (memory partition) setting.
 - [rsmi_status_t rsmi_dev_nps_mode_reset](#) (uint32_t dv_ind)
Reverts a selected device's NPS mode setting back to its boot state.

- `rsmi_status_t rsmi_dev_supported_func_iterator_open` (`uint32_t dv_ind`, `rsmi_func_id_iter_handle_t *handle`)
Get a function name iterator of supported RSMI functions for a device.
- `rsmi_status_t rsmi_dev_supported_variant_iterator_open` (`rsmi_func_id_iter_handle_t obj_h`, `rsmi_func_id_iter_handle_t *var_iter`)
Get a variant iterator for a given handle.
- `rsmi_status_t rsmi_func_iter_next` (`rsmi_func_id_iter_handle_t handle`)
Advance a function identifier iterator.
- `rsmi_status_t rsmi_dev_supported_func_iterator_close` (`rsmi_func_id_iter_handle_t *handle`)
Close a variant iterator handle.
- `rsmi_status_t rsmi_func_iter_value_get` (`rsmi_func_id_iter_handle_t handle`, `rsmi_func_id_value_t *value`)
Get the value associated with a function/variant iterator.
- `rsmi_status_t rsmi_event_notification_init` (`uint32_t dv_ind`)
Prepare to collect event notifications for a GPU.
- `rsmi_status_t rsmi_event_notification_mask_set` (`uint32_t dv_ind`, `uint64_t mask`)
Specify which events to collect for a device.
- `rsmi_status_t rsmi_event_notification_get` (`int timeout_ms`, `uint32_t *num_elem`, `rsmi_evt_notification_data_t *data`)
Collect event notifications, waiting a specified amount of time.
- `rsmi_status_t rsmi_event_notification_stop` (`uint32_t dv_ind`)
Close any file handles and free any resources used by event notification for a GPU.

8.1.1 Detailed Description

The `rocm_smi` library api is new, and therefore subject to change either at the ABI or API level. Instead of marking every function prototype as "unstable", we are instead saying the API is unstable (i.e., changes are possible) while the major version remains 0. This means that if the API/ABI changes, we will not increment the major version to 1. Once the ABI stabilizes, we will increment the major version to 1, and thereafter increment it on all ABI breaks.

Main header file for the ROCm SMI library. All required function, structure, enum, etc. definitions should be defined in this file.

8.1.2 Macro Definition Documentation

8.1.2.1 RSMI_MAX_FAN_SPEED

```
#define RSMI_MAX_FAN_SPEED 255
```

Maximum possible value for fan speed. Should be used as the denominator when determining fan speed percentage.

8.1.2.2 RSMI_EVENT_MASK_FROM_INDEX

```
#define RSMI_EVENT_MASK_FROM_INDEX(  
    i ) (1ULL << ((i) - 1))
```

Macro to generate event bitmask from event id

8.1.2.3 RSMI_DEFAULT_VARIANT

```
#define RSMI_DEFAULT_VARIANT 0xFFFFFFFFFFFFFFFF
```

Place-holder "variant" for functions that have don't have any variants, but do have monitors or sensors.

8.1.3 Typedef Documentation

8.1.3.1 rsmi_event_handle_t

```
typedef uintptr_t rsmi_event_handle_t
```

Handle to performance event counter.

Event counter types

8.1.4 Enumeration Type Documentation

8.1.4.1 rsmi_status_t

```
enum rsmi_status_t
```

Error codes returned by rocm_smi_lib functions.

Enumerator

RSMI_STATUS_SUCCESS	Operation was successful.
RSMI_STATUS_INVALID_ARGS	Passed in arguments are not valid.
RSMI_STATUS_NOT_SUPPORTED	The requested information or action is not available for the given input, on the given system
RSMI_STATUS_FILE_ERROR	Problem accessing a file. This may because the operation is not supported by the Linux kernel version running on the executing machine
RSMI_STATUS_PERMISSION	Permission denied/EACCESS file error. Many functions require root access to run.
RSMI_STATUS_OUT_OF_RESOURCES	Unable to acquire memory or other resource
RSMI_STATUS_INTERNAL_EXCEPTION	An internal exception was caught.
RSMI_STATUS_INPUT_OUT_OF_BOUNDS	The provided input is out of allowable or safe range
RSMI_STATUS_INIT_ERROR	An error occurred when rsmi initializing internal data structures
RSMI_STATUS_NOT_YET_IMPLEMENTED	The requested function has not yet been implemented in the current system for the current devices
RSMI_STATUS_NOT_FOUND	An item was searched for but not found
RSMI_STATUS_INSUFFICIENT_SIZE	Not enough resources were available for the operation

Enumerator

RSMI_STATUS_INTERRUPT	An interrupt occurred during execution of function
RSMI_STATUS_UNEXPECTED_SIZE	An unexpected amount of data was read
RSMI_STATUS_NO_DATA	No data was found for a given input
RSMI_STATUS_UNEXPECTED_DATA	The data read or provided to function is not what was expected
RSMI_STATUS_BUSY	A resource or mutex could not be acquired because it is already being used
RSMI_STATUS_REFCOUNT_OVERFLOW	An internal reference counter exceeded INT32_MAX
RSMI_STATUS_SETTING_UNAVAILABLE	Requested setting is unavailable for the current device
RSMI_STATUS_AMDGPU_RESTART_ERR	Could not successfully restart the amdgpu driver
RSMI_STATUS_UNKNOWN_ERROR	An unknown error occurred.

8.1.4.2 rsmi_init_flags_t

```
enum rsmi_init_flags_t
```

Initialization flags.

Initialization flags may be OR'd together and passed to [rsmi_init\(\)](#).

Enumerator

RSMI_INIT_FLAG_ALL_GPUS	Attempt to add all GPUs found (including non-AMD) to the list of devices from which SMI information can be retrieved. By default, only AMD devices are enumerated by RSMI.
RSMI_INIT_FLAG_RESRV_TEST1	Reserved for test.

8.1.4.3 rsmi_dev_perf_level_t

```
enum rsmi_dev_perf_level_t
```

PowerPlay performance levels.

Enumerator

RSMI_DEV_PERF_LEVEL_AUTO	Performance level is "auto".
RSMI_DEV_PERF_LEVEL_LOW	Keep PowerPlay levels "low", regardless of workload
RSMI_DEV_PERF_LEVEL_HIGH	Keep PowerPlay levels "high", regardless of workload
RSMI_DEV_PERF_LEVEL_MANUAL	Only use values defined by manually setting the RSMI_CLK_TYPE_SYS speed
RSMI_DEV_PERF_LEVEL_STABLE_STD	Stable power state with profiling clocks
RSMI_DEV_PERF_LEVEL_STABLE_PEAK	Stable power state with peak clocks.
RSMI_DEV_PERF_LEVEL_STABLE_MIN_MCLK	Stable power state with minimum memory clock

Enumerator

RSMI_DEV_PERF_LEVEL_STABLE_MIN_SCLK	Stable power state with minimum system clock
RSMI_DEV_PERF_LEVEL_DETERMINISM	Performance determinism state.
RSMI_DEV_PERF_LEVEL_UNKNOWN	Unknown performance level.

8.1.4.4 rsmi_sw_component_t

```
enum rsmi_sw_component_t
```

Available clock types.

Software components

Enumerator

RSMI_SW_COMP_DRIVER	Driver.
---------------------	---------

8.1.4.5 rsmi_event_group_t

```
enum rsmi_event_group_t
```

Enum denoting an event group. The value of the enum is the base value for all the event enums in the group.

Event Groups

Enumerator

RSMI_EVNT_GRP_XGMI	Data Fabric (XGMI) related events.
RSMI_EVNT_GRP_XGMI_DATA_OUT	XGMI Outbound data.

8.1.4.6 rsmi_event_type_t

```
enum rsmi_event_type_t
```

Event type enum. Events belonging to a particular event group [rsmi_event_group_t](#) should begin enumerating at the [rsmi_event_group_t](#) value for that group.

Event types

Enumerator

RSMI_EVNT_XGMI_0_NOP_TX	NOPs sent to neighbor 0.
RSMI_EVNT_XGMI_0_REQUEST_TX	Outgoing requests to neighbor 0
RSMI_EVNT_XGMI_0_RESPONSE_TX	Outgoing responses to neighbor 0
RSMI_EVNT_XGMI_0_BEATS_TX	Data beats sent to neighbor 0; Each beat represents 32 bytes. XGMI throughput can be calculated by multiplying a BEATS event such as RSMI_EVNT_XGMI_0_BEATS_TX by 32 and dividing by the time for which event collection occurred, rsmi_counter_value_t.time_running (which is in nanoseconds). To get bytes per second, multiply this value by 10^9 . Throughput = BEATS/time_running * 10^9 (bytes/second)
RSMI_EVNT_XGMI_1_NOP_TX	NOPs sent to neighbor 1.
RSMI_EVNT_XGMI_1_REQUEST_TX	neighbor 1 Outgoing requests to
RSMI_EVNT_XGMI_1_RESPONSE_TX	Outgoing responses to neighbor 1
RSMI_EVNT_XGMI_1_BEATS_TX	Data beats sent to neighbor 1; Each beat represents 32 bytes
RSMI_EVNT_XGMI_DATA_OUT_1	Outbound beats to neighbor 1.
RSMI_EVNT_XGMI_DATA_OUT_2	Outbound beats to neighbor 2.
RSMI_EVNT_XGMI_DATA_OUT_3	Outbound beats to neighbor 3.
RSMI_EVNT_XGMI_DATA_OUT_4	Outbound beats to neighbor 4.
RSMI_EVNT_XGMI_DATA_OUT_5	Outbound beats to neighbor 5.

8.1.4.7 `rsmi_counter_command_t`

```
enum rsmi_counter_command_t
```

Event counter commands

Enumerator

RSMI_CNTR_CMD_START	Start the counter.
RSMI_CNTR_CMD_STOP	Stop the counter; note that this should not be used before reading.

8.1.4.8 `rsmi_evt_notification_type_t`

```
enum rsmi_evt_notification_type_t
```

Event notification event types

Enumerator

RSMI_EVT_NOTIF_VMFFAULT	VM page fault.
-------------------------	----------------

8.1.4.9 rsmi_clk_type_t

enum `rsmi_clk_type_t`

Clock types

Enumerator

RSMI_CLK_TYPE_SYS	System clock.
RSMI_CLK_TYPE_DF	Data Fabric clock (for ASICs running on a separate clock)
RSMI_CLK_TYPE_DCEF	Display Controller Engine clock.
RSMI_CLK_TYPE_SOC	SOC clock.
RSMI_CLK_TYPE_MEM	Memory clock.
RSMI_CLK_TYPE_PCIE	PCIE clock.

8.1.4.10 rsmi_compute_partition_type_t

enum `rsmi_compute_partition_type_t`

Compute Partition. This enum is used to identify various compute partitioning settings.

Enumerator

RSMI_COMPUTE_PARTITION_CPX	Core mode (CPX)- Per-chip XCC with shared memory
RSMI_COMPUTE_PARTITION_SPX	Single GPU mode (SPX)- All XCCs work together with shared memory
RSMI_COMPUTE_PARTITION_DPX	Dual GPU mode (DPX)- Half XCCs work together with shared memory
RSMI_COMPUTE_PARTITION_TPX	Triple GPU mode (TPX)- One-third XCCs work together with shared memory
RSMI_COMPUTE_PARTITION_QPX	Quad GPU mode (QPX)- Quarter XCCs work together with shared memory

8.1.4.11 rsmi_nps_mode_type_t

enum `rsmi_nps_mode_type_t`

NPS Modes. This enum is used to identify various NPS mode types.

Enumerator

RSMI_MEMORY_PARTITION_NPS1	NPS1 - All CCD & XCD data is interleaved accross all 8 HBM stacks (all stacks/1).
RSMI_MEMORY_PARTITION_NPS2	NPS2 - 2 sets of CCDs or 4 XCD interleaved accross the 4 HBM stacks per AID pair (8 stacks/2).
RSMI_MEMORY_PARTITION_NPS4	NPS4 - Each XCD data is interleaved accross accross 2 (or single) HBM stacks (8 stacks/8 or 8 stacks/4).
RSMI_MEMORY_PARTITION_NPS8	NPS8 - Each XCD uses a single HBM stack (8 stacks/8). Or each XCD uses a single HBM stack & CCDs share 2 non-interleaved HBM stacks on its AID (AID[1,2,3] = 6 stacks/6).

8.1.4.12 rsmi_temperature_metric_t

```
enum rsmi_temperature_metric_t
```

Temperature Metrics. This enum is used to identify various temperature metrics. Corresponding values will be in millidegrees Celcius.

Enumerator

RSMI_TEMP_CURRENT	Temperature current value.
RSMI_TEMP_MAX	Temperature max value.
RSMI_TEMP_MIN	Temperature min value.
RSMI_TEMP_MAX_HYST	Temperature hysteresis value for max limit. (This is an absolute temperature, not a delta).
RSMI_TEMP_MIN_HYST	Temperature hysteresis value for min limit. (This is an absolute temperature, not a delta).
RSMI_TEMP_CRITICAL	Temperature critical max value, typically greater than corresponding temp_max values.
RSMI_TEMP_CRITICAL_HYST	Temperature hysteresis value for critical limit. (This is an absolute temperature, not a delta).
RSMI_TEMP_EMERGENCY	Temperature emergency max value, for chips supporting more than two upper temperature limits. Must be equal or greater than corresponding temp_crit values.
RSMI_TEMP_EMERGENCY_HYST	Temperature hysteresis value for emergency limit. (This is an absolute temperature, not a delta).
RSMI_TEMP_CRIT_MIN	Temperature critical min value, typically lower than corresponding temperature minimum values.
RSMI_TEMP_CRIT_MIN_HYST	Temperature hysteresis value for critical minimum limit. (This is an absolute temperature, not a delta).
RSMI_TEMP_OFFSET	Temperature offset which is added to the temperature reading by the chip.
RSMI_TEMP_LOWEST	Historical minimum temperature.
RSMI_TEMP_HIGHEST	Historical maximum temperature.

8.1.4.13 rsmi_temperature_type_t

```
enum rsmi_temperature_type_t
```

This enumeration is used to indicate from which part of the device a temperature reading should be obtained.

Enumerator

RSMI_TEMP_TYPE_EDGE	Edge GPU temperature.
RSMI_TEMP_TYPE_JUNCTION	Junction/hotspot temperature
RSMI_TEMP_TYPE_MEMORY	VRAM temperature.
RSMI_TEMP_TYPE_HBM_0	HBM temperature instance 0.
RSMI_TEMP_TYPE_HBM_1	HBM temperature instance 1.
RSMI_TEMP_TYPE_HBM_2	HBM temperature instance 2.
RSMI_TEMP_TYPE_HBM_3	HBM temperature instance 3.
RSMI_TEMP_TYPE_INVALID	Invalid type.

8.1.4.14 rsmi_voltage_metric_t

```
enum rsmi_voltage_metric_t
```

Voltage Metrics. This enum is used to identify various Voltage metrics. Corresponding values will be in millivolt.

Enumerator

RSMI_VOLT_CURRENT	Voltage current value.
RSMI_VOLT_MAX	Voltage max value.
RSMI_VOLT_MIN_CRIT	Voltage critical min value.
RSMI_VOLT_MIN	Voltage min value.
RSMI_VOLT_MAX_CRIT	Voltage critical max value.
RSMI_VOLT_AVERAGE	Average voltage.
RSMI_VOLT_LOWEST	Historical minimum voltage.
RSMI_VOLT_HIGHEST	Historical maximum voltage.

8.1.4.15 rsmi_voltage_type_t

```
enum rsmi_voltage_type_t
```

This enumeration is used to indicate which type of voltage reading should be obtained.

Enumerator

RSMI_VOLT_TYPE_VDDGFX	Vddgfx GPU voltage
RSMI_VOLT_TYPE_INVALID	Invalid type.

8.1.4.16 rsmi_power_profile_preset_masks_t

enum [rsmi_power_profile_preset_masks_t](#)

Pre-set Profile Selections. These bitmasks can be AND'd with the [rsmi_power_profile_status_t.available_profiles](#) returned from [rsmi_dev_power_profile_presets_get](#) to determine which power profiles are supported by the system.

Enumerator

RSMI_PWR_PROF_PRST_CUSTOM_MASK	Custom Power Profile.
RSMI_PWR_PROF_PRST_VIDEO_MASK	Video Power Profile.
RSMI_PWR_PROF_PRST_POWER_SAVING_MASK	Power Saving Profile.
RSMI_PWR_PROF_PRST_COMPUTE_MASK	Compute Saving Profile.
RSMI_PWR_PROF_PRST_VR_MASK	VR Power Profile. 3D Full Screen Power Profile
RSMI_PWR_PROF_PRST_BOOTUP_DEFAULT	Default Boot Up Profile.
RSMI_PWR_PROF_PRST_LAST	Invalid power profile.

8.1.4.17 rsmi_gpu_block_t

enum [rsmi_gpu_block_t](#)

This enum is used to identify different GPU blocks.

Enumerator

RSMI_GPU_BLOCK_INVALID	Used to indicate an invalid block
RSMI_GPU_BLOCK_UMC	UMC block.
RSMI_GPU_BLOCK_SDMA	SDMA block.
RSMI_GPU_BLOCK_GFX	GFX block.
RSMI_GPU_BLOCK_MMHUB	MMHUB block.
RSMI_GPU_BLOCK_ATHUB	ATHUB block.
RSMI_GPU_BLOCK_PCIE_BIF	PCIE_BIF block.
RSMI_GPU_BLOCK_HDP	HDP block.
RSMI_GPU_BLOCK_XGMI_WAFL	XGMI block.
RSMI_GPU_BLOCK_DF	DF block.
RSMI_GPU_BLOCK_SMN	SMN block.
RSMI_GPU_BLOCK_SEM	SEM block.
RSMI_GPU_BLOCK_MP0	MP0 block.
RSMI_GPU_BLOCK_MP1	MP1 block.
RSMI_GPU_BLOCK_FUSE	Fuse block.
RSMI_GPU_BLOCK_LAST	for supported blocks The highest bit position

8.1.4.18 rsmi_ras_err_state_t

```
enum rsmi_ras_err_state_t
```

The current ECC state.

Enumerator

RSMI_RAS_ERR_STATE_NONE	No current errors.
RSMI_RAS_ERR_STATE_DISABLED	ECC is disabled.
RSMI_RAS_ERR_STATE_PARITY	ECC errors present, but type unknown.
RSMI_RAS_ERR_STATE_SING_C	Single correctable error.
RSMI_RAS_ERR_STATE_MULT_UC	Multiple uncorrectable errors.
RSMI_RAS_ERR_STATE_POISON	Firmware detected error and isolated page. Treat as uncorrectable.
RSMI_RAS_ERR_STATE_ENABLED	ECC is enabled.

8.1.4.19 rsmi_memory_type_t

```
enum rsmi_memory_type_t
```

Types of memory.

Enumerator

RSMI_MEM_TYPE_VRAM	VRAM memory.
RSMI_MEM_TYPE_VIS_VRAM	VRAM memory that is visible.
RSMI_MEM_TYPE_GTT	GTT memory.

8.1.4.20 rsmi_freq_ind_t

```
enum rsmi_freq_ind_t
```

The values of this enum are used as frequency identifiers.

Enumerator

RSMI_FREQ_IND_MIN	Index used for the minimum frequency value.
RSMI_FREQ_IND_MAX	Index used for the maximum frequency value.
RSMI_FREQ_IND_INVALID	An invalid frequency index.

8.1.4.21 rsmi_memory_page_status_t

```
enum rsmi_memory_page_status_t
```

Reserved Memory Page States.

Enumerator

RSMI_MEM_PAGE_STATUS_RESERVED	Reserved. This gpu page is reserved and not available for use
RSMI_MEM_PAGE_STATUS_PENDING	Pending. This gpu page is marked as bad and will be marked reserved at the next window.
RSMI_MEM_PAGE_STATUS_UNRESERVABLE	Unable to reserve this page.

8.1.4.22 _RSMI_IO_LINK_TYPE

```
enum _RSMI_IO_LINK_TYPE
```

Types for IO Link.

Enumerator

RSMI_IOLINK_TYPE_UNDEFINED	unknown type.
RSMI_IOLINK_TYPE_PCIEEXPRESS	PCI Express.
RSMI_IOLINK_TYPE_XGMI	XGMI.
RSMI_IOLINK_TYPE_NUMIOLINKTYPES	Number of IO Link types.
RSMI_IOLINK_TYPE_SIZE	Max of IO Link types.

8.1.4.23 RSMI_UTILIZATION_COUNTER_TYPE

```
enum RSMI_UTILIZATION_COUNTER_TYPE
```

The utilization counter type.

Enumerator

RSMI_UTILIZATION_COUNTER_FIRST	GFX Activity.
RSMI_COARSE_GRAIN_MEM_ACTIVITY	Memory Activity.

Index

- [_RSMI_IO_LINK_TYPE](#)
 - [rocm_smi.h, 128](#)
- [available_profiles](#)
 - [rsmi_power_profile_status_t, 105](#)
- [Clock, Power and Performance Control, 57](#)
 - [rsmi_dev_gpu_clk_freq_set, 60](#)
 - [rsmi_dev_overdrive_level_set, 58](#)
 - [rsmi_dev_overdrive_level_set_v1, 59](#)
 - [rsmi_dev_perf_level_set, 57](#)
 - [rsmi_dev_perf_level_set_v1, 58](#)
- [Clock, Power and Performance Queries, 46](#)
 - [rsmi_dev_busy_percent_get, 47](#)
 - [rsmi_dev_clk_range_set, 52](#)
 - [rsmi_dev_gpu_clk_freq_get, 50](#)
 - [rsmi_dev_gpu_metrics_info_get, 52](#)
 - [rsmi_dev_gpu_reset, 51](#)
 - [rsmi_dev_mem_overdrive_level_get, 50](#)
 - [rsmi_dev_od_clk_info_set, 53](#)
 - [rsmi_dev_od_volt_curve_regions_get, 54](#)
 - [rsmi_dev_od_volt_info_get, 51](#)
 - [rsmi_dev_od_volt_info_set, 54](#)
 - [rsmi_dev_overdrive_level_get, 49](#)
 - [rsmi_dev_perf_level_get, 48](#)
 - [rsmi_dev_power_profile_presets_get, 55](#)
 - [rsmi_perf_determinism_mode_set, 49](#)
 - [rsmi_utilization_count_get, 47](#)
- [Compute Partition Functions, 83](#)
 - [rsmi_dev_compute_partition_get, 83](#)
 - [rsmi_dev_compute_partition_reset, 84](#)
 - [rsmi_dev_compute_partition_set, 84](#)
- [curr_mclk_range](#)
 - [rsmi_od_volt_freq_data_t, 103](#)
- [current](#)
 - [rsmi_frequencies_t, 101](#)
 - [rsmi_power_profile_status_t, 105](#)
- [Error Queries, 65](#)
 - [rsmi_dev_ecc_count_get, 65](#)
 - [rsmi_dev_ecc_enabled_get, 66](#)
 - [rsmi_dev_ecc_status_get, 66](#)
 - [rsmi_status_string, 68](#)
- [Event Notification Functions, 94](#)
 - [rsmi_event_notification_get, 95](#)
 - [rsmi_event_notification_init, 94](#)
 - [rsmi_event_notification_mask_set, 94](#)
 - [rsmi_event_notification_stop, 96](#)
- [frequency](#)
 - [rsmi_frequencies_t, 101](#)
- [Hardware Topology Functions, 79](#)
 - [rsmi_is_P2P_accessible, 81](#)
 - [rsmi_minmax_bandwidth_get, 80](#)
 - [rsmi_topo_get_link_type, 81](#)
 - [rsmi_topo_get_link_weight, 80](#)
 - [rsmi_topo_get_numa_node_number, 79](#)
- [id, 97](#)
 - [memory_type, 98](#)
- [Identifier Queries, 15](#)
 - [rsmi_dev_brand_get, 18](#)
 - [rsmi_dev_drm_render_minor_get, 22](#)
 - [rsmi_dev_id_get, 16](#)
 - [rsmi_dev_name_get, 17](#)
 - [rsmi_dev_serial_number_get, 20](#)
 - [rsmi_dev_sku_get, 16](#)
 - [rsmi_dev_subsystem_id_get, 21](#)
 - [rsmi_dev_subsystem_name_get, 21](#)
 - [rsmi_dev_subsystem_vendor_id_get, 22](#)
 - [rsmi_dev_unique_id_get, 23](#)
 - [rsmi_dev_vendor_id_get, 17](#)
 - [rsmi_dev_vendor_name_get, 19](#)
 - [rsmi_dev_vram_vendor_get, 19](#)
 - [rsmi_num_monitor_devices, 15](#)
- [Initialization and Shutdown, 13](#)
 - [rsmi_init, 13](#)
 - [rsmi_shut_down, 14](#)
- [lanes](#)
 - [rsmi_pcie_bandwidth_t, 104](#)
- [Memory Queries, 36](#)
 - [rsmi_dev_memory_busy_percent_get, 37](#)
 - [rsmi_dev_memory_reserved_pages_get, 38](#)
 - [rsmi_dev_memory_total_get, 36](#)
 - [rsmi_dev_memory_usage_get, 37](#)
- [memory_type](#)
 - [id, 98](#)
- [metrics_table_header_t, 98](#)
- [NPS Mode Functions, 86](#)
 - [rsmi_dev_nps_mode_get, 86](#)
 - [rsmi_dev_nps_mode_reset, 87](#)
 - [rsmi_dev_nps_mode_set, 87](#)
- [num_profiles](#)
 - [rsmi_power_profile_status_t, 105](#)
- [num_supported](#)
 - [rsmi_frequencies_t, 101](#)

- PCIe Control, 29
 - rsmi_dev_pci_bandwidth_set, 29
- PCIe Queries, 24
 - rsmi_dev_pci_bandwidth_get, 24
 - rsmi_dev_pci_id_get, 25
 - rsmi_dev_pci_replay_counter_get, 27
 - rsmi_dev_pci_throughput_get, 27
 - rsmi_topo_numa_affinity_get, 25
- Performance Counter Functions, 69
 - rsmi_counter_available_counters_get, 73
 - rsmi_counter_control, 72
 - rsmi_counter_read, 72
 - rsmi_dev_counter_create, 70
 - rsmi_dev_counter_destroy, 71
 - rsmi_dev_counter_group_supported, 70
- Physical State Control, 44
 - rsmi_dev_fan_reset, 44
 - rsmi_dev_fan_speed_set, 44
- Physical State Queries, 40
 - rsmi_dev_fan_rpms_get, 40
 - rsmi_dev_fan_speed_get, 41
 - rsmi_dev_fan_speed_max_get, 41
 - rsmi_dev_temp_metric_get, 42
 - rsmi_dev_volt_metric_get, 43
- Power Control, 34
 - rsmi_dev_power_cap_set, 34
 - rsmi_dev_power_profile_set, 34
- Power Queries, 30
 - rsmi_dev_energy_count_get, 31
 - rsmi_dev_power_ave_get, 30
 - rsmi_dev_power_cap_default_get, 32
 - rsmi_dev_power_cap_get, 31
 - rsmi_dev_power_cap_range_get, 33
- rocm_smi.h, 109
 - _RSMI_IO_LINK_TYPE, 128
 - RSMI_CLK_TYPE_DCEF, 123
 - RSMI_CLK_TYPE_DF, 123
 - RSMI_CLK_TYPE_MEM, 123
 - RSMI_CLK_TYPE_PCIE, 123
 - RSMI_CLK_TYPE_SOC, 123
 - RSMI_CLK_TYPE_SYS, 123
 - rsmi_clk_type_t, 123
 - RSMI_CNTR_CMD_START, 122
 - RSMI_CNTR_CMD_STOP, 122
 - RSMI_COARSE_GRAIN_MEM_ACTIVITY, 128
 - RSMI_COMPUTE_PARTITION_CPX, 123
 - RSMI_COMPUTE_PARTITION_DPX, 123
 - RSMI_COMPUTE_PARTITION_QPX, 123
 - RSMI_COMPUTE_PARTITION_SPX, 123
 - RSMI_COMPUTE_PARTITION_TPX, 123
 - rsmi_compute_partition_type_t, 123
 - rsmi_counter_command_t, 122
 - RSMI_DEFAULT_VARIANT, 118
 - RSMI_DEV_PERF_LEVEL_AUTO, 120
 - RSMI_DEV_PERF_LEVEL_DETERMINISM, 121
 - RSMI_DEV_PERF_LEVEL_HIGH, 120
 - RSMI_DEV_PERF_LEVEL_LOW, 120
 - RSMI_DEV_PERF_LEVEL_MANUAL, 120
 - RSMI_DEV_PERF_LEVEL_STABLE_MIN_MCLK, 120
 - RSMI_DEV_PERF_LEVEL_STABLE_MIN_SCLK, 121
 - RSMI_DEV_PERF_LEVEL_STABLE_PEAK, 120
 - RSMI_DEV_PERF_LEVEL_STABLE_STD, 120
 - rsmi_dev_perf_level_t, 120
 - RSMI_DEV_PERF_LEVEL_UNKNOWN, 121
 - rsmi_event_group_t, 121
 - rsmi_event_handle_t, 119
 - RSMI_EVENT_MASK_FROM_INDEX, 118
 - rsmi_event_type_t, 121
 - RSMI_EVNT_GRP_XGMI, 121
 - RSMI_EVNT_GRP_XGMI_DATA_OUT, 121
 - RSMI_EVNT_XGMI_0_BEATS_TX, 122
 - RSMI_EVNT_XGMI_0_NOP_TX, 122
 - RSMI_EVNT_XGMI_0_REQUEST_TX, 122
 - RSMI_EVNT_XGMI_0_RESPONSE_TX, 122
 - RSMI_EVNT_XGMI_1_BEATS_TX, 122
 - RSMI_EVNT_XGMI_1_NOP_TX, 122
 - RSMI_EVNT_XGMI_1_REQUEST_TX, 122
 - RSMI_EVNT_XGMI_1_RESPONSE_TX, 122
 - RSMI_EVNT_XGMI_DATA_OUT_1, 122
 - RSMI_EVNT_XGMI_DATA_OUT_2, 122
 - RSMI_EVNT_XGMI_DATA_OUT_3, 122
 - RSMI_EVNT_XGMI_DATA_OUT_4, 122
 - RSMI_EVNT_XGMI_DATA_OUT_5, 122
 - RSMI_EVT_NOTIF_VMFAULT, 122
 - rsmi_evt_notification_type_t, 122
 - RSMI_FREQ_IND_INVALID, 127
 - RSMI_FREQ_IND_MAX, 127
 - RSMI_FREQ_IND_MIN, 127
 - rsmi_freq_ind_t, 127
 - RSMI_GPU_BLOCK_ATHUB, 126
 - RSMI_GPU_BLOCK_DF, 126
 - RSMI_GPU_BLOCK_FUSE, 126
 - RSMI_GPU_BLOCK_GFX, 126
 - RSMI_GPU_BLOCK_HDP, 126
 - RSMI_GPU_BLOCK_INVALID, 126
 - RSMI_GPU_BLOCK_LAST, 126
 - RSMI_GPU_BLOCK_MMHUB, 126
 - RSMI_GPU_BLOCK_MP0, 126
 - RSMI_GPU_BLOCK_MP1, 126
 - RSMI_GPU_BLOCK_PCIE_BIF, 126
 - RSMI_GPU_BLOCK_SDMA, 126
 - RSMI_GPU_BLOCK_SEM, 126
 - RSMI_GPU_BLOCK_SMN, 126
 - rsmi_gpu_block_t, 126
 - RSMI_GPU_BLOCK_UMC, 126
 - RSMI_GPU_BLOCK_XGMI_WAFL, 126
 - RSMI_INIT_FLAG_ALL_GPUS, 120
 - RSMI_INIT_FLAG_RESRV_TEST1, 120
 - rsmi_init_flags_t, 120
 - RSMI_IOLINK_TYPE_NUMIOLINKTYPES, 128
 - RSMI_IOLINK_TYPE_PCIEEXPRESS, 128
 - RSMI_IOLINK_TYPE_SIZE, 128
 - RSMI_IOLINK_TYPE_UNDEFINED, 128
 - RSMI_IOLINK_TYPE_XGMI, 128

- RSMI_MAX_FAN_SPEED, 118
- RSMI_MEM_PAGE_STATUS_PENDING, 128
- RSMI_MEM_PAGE_STATUS_RESERVED, 128
- RSMI_MEM_PAGE_STATUS_UNRESERVABLE, 128
- RSMI_MEM_TYPE_GTT, 127
- RSMI_MEM_TYPE_VIS_VRAM, 127
- RSMI_MEM_TYPE_VRAM, 127
- rsmi_memory_page_status_t, 127
- RSMI_MEMORY_PARTITION_NPS1, 124
- RSMI_MEMORY_PARTITION_NPS2, 124
- RSMI_MEMORY_PARTITION_NPS4, 124
- RSMI_MEMORY_PARTITION_NPS8, 124
- rsmi_memory_type_t, 127
- rsmi_nps_mode_type_t, 123
- rsmi_power_profile_preset_masks_t, 126
- RSMI_PWR_PROF_PRST_BOOTUP_DEFAULT, 126
- RSMI_PWR_PROF_PRST_COMPUTE_MASK, 126
- RSMI_PWR_PROF_PRST_CUSTOM_MASK, 126
- RSMI_PWR_PROF_PRST_LAST, 126
- RSMI_PWR_PROF_PRST_POWER_SAVING_MASK, 126
- RSMI_PWR_PROF_PRST_VIDEO_MASK, 126
- RSMI_PWR_PROF_PRST_VR_MASK, 126
- RSMI_RAS_ERR_STATE_DISABLED, 127
- RSMI_RAS_ERR_STATE_ENABLED, 127
- RSMI_RAS_ERR_STATE_MULT_UC, 127
- RSMI_RAS_ERR_STATE_NONE, 127
- RSMI_RAS_ERR_STATE_PARITY, 127
- RSMI_RAS_ERR_STATE_POISON, 127
- RSMI_RAS_ERR_STATE_SING_C, 127
- rsmi_ras_err_state_t, 126
- RSMI_STATUS_AMDGPU_RESTART_ERR, 120
- RSMI_STATUS_BUSY, 120
- RSMI_STATUS_FILE_ERROR, 119
- RSMI_STATUS_INIT_ERROR, 119
- RSMI_STATUS_INPUT_OUT_OF_BOUNDS, 119
- RSMI_STATUS_INSUFFICIENT_SIZE, 119
- RSMI_STATUS_INTERNAL_EXCEPTION, 119
- RSMI_STATUS_INTERRUPT, 120
- RSMI_STATUS_INVALID_ARGS, 119
- RSMI_STATUS_NO_DATA, 120
- RSMI_STATUS_NOT_FOUND, 119
- RSMI_STATUS_NOT_SUPPORTED, 119
- RSMI_STATUS_NOT_YET_IMPLEMENTED, 119
- RSMI_STATUS_OUT_OF_RESOURCES, 119
- RSMI_STATUS_PERMISSION, 119
- RSMI_STATUS_REFCOUNT_OVERFLOW, 120
- RSMI_STATUS_SETTING_UNAVAILABLE, 120
- RSMI_STATUS_SUCCESS, 119
- rsmi_status_t, 119
- RSMI_STATUS_UNEXPECTED_DATA, 120
- RSMI_STATUS_UNEXPECTED_SIZE, 120
- RSMI_STATUS_UNKNOWN_ERROR, 120
- RSMI_SW_COMP_DRIVER, 121
- rsmi_sw_component_t, 121
- RSMI_TEMP_CRIT_MIN, 124
- RSMI_TEMP_CRIT_MIN_HYST, 124
- RSMI_TEMP_CRITICAL, 124
- RSMI_TEMP_CRITICAL_HYST, 124
- RSMI_TEMP_CURRENT, 124
- RSMI_TEMP_EMERGENCY, 124
- RSMI_TEMP_EMERGENCY_HYST, 124
- RSMI_TEMP_HIGHEST, 124
- RSMI_TEMP_LOWEST, 124
- RSMI_TEMP_MAX, 124
- RSMI_TEMP_MAX_HYST, 124
- RSMI_TEMP_MIN, 124
- RSMI_TEMP_MIN_HYST, 124
- RSMI_TEMP_OFFSET, 124
- RSMI_TEMP_TYPE_EDGE, 125
- RSMI_TEMP_TYPE_HBM_0, 125
- RSMI_TEMP_TYPE_HBM_1, 125
- RSMI_TEMP_TYPE_HBM_2, 125
- RSMI_TEMP_TYPE_HBM_3, 125
- RSMI_TEMP_TYPE_INVALID, 125
- RSMI_TEMP_TYPE_JUNCTION, 125
- RSMI_TEMP_TYPE_MEMORY, 125
- rsmi_temperature_metric_t, 124
- rsmi_temperature_type_t, 124
- RSMI_UTILIZATION_COUNTER_FIRST, 128
- RSMI_UTILIZATION_COUNTER_TYPE, 128
- RSMI_VOLT_AVERAGE, 125
- RSMI_VOLT_CURRENT, 125
- RSMI_VOLT_HIGHEST, 125
- RSMI_VOLT_LOWEST, 125
- RSMI_VOLT_MAX, 125
- RSMI_VOLT_MAX_CRIT, 125
- RSMI_VOLT_MIN, 125
- RSMI_VOLT_MIN_CRIT, 125
- RSMI_VOLT_TYPE_INVALID, 125
- RSMI_VOLT_TYPE_VDDGFX, 125
- rsmi_voltage_metric_t, 125
- rsmi_voltage_type_t, 125
- RSMI_CLK_TYPE_DCEF
 - rocm_smi.h, 123
- RSMI_CLK_TYPE_DF
 - rocm_smi.h, 123
- RSMI_CLK_TYPE_MEM
 - rocm_smi.h, 123
- RSMI_CLK_TYPE_PCIE
 - rocm_smi.h, 123
- RSMI_CLK_TYPE_SOC
 - rocm_smi.h, 123
- RSMI_CLK_TYPE_SYS
 - rocm_smi.h, 123
- rsmi_clk_type_t
 - rocm_smi.h, 123
- RSMI_CNTR_CMD_START
 - rocm_smi.h, 122
- RSMI_CNTR_CMD_STOP
 - rocm_smi.h, 122
- RSMI_COARSE_GRAIN_MEM_ACTIVITY
 - rocm_smi.h, 128

- RSMI_COMPUTE_PARTITION_CPX
 - rocm_smi.h, 123
- RSMI_COMPUTE_PARTITION_DPX
 - rocm_smi.h, 123
- RSMI_COMPUTE_PARTITION_QPX
 - rocm_smi.h, 123
- RSMI_COMPUTE_PARTITION_SPX
 - rocm_smi.h, 123
- RSMI_COMPUTE_PARTITION_TPX
 - rocm_smi.h, 123
- rsmi_compute_partition_type_t
 - rocm_smi.h, 123
- rsmi_compute_process_gpus_get
 - System Information Functions, 75
- rsmi_compute_process_info_by_pid_get
 - System Information Functions, 75
- rsmi_compute_process_info_get
 - System Information Functions, 74
- rsmi_counter_available_counters_get
 - Performance Counter Functions, 73
- rsmi_counter_command_t
 - rocm_smi.h, 122
- rsmi_counter_control
 - Performance Counter Functions, 72
- rsmi_counter_read
 - Performance Counter Functions, 72
- rsmi_counter_value_t, 98
 - time_enabled, 99
 - time_running, 99
- RSMI_DEFAULT_VARIANT
 - rocm_smi.h, 118
- rsmi_dev_brand_get
 - Identifier Queries, 18
- rsmi_dev_busy_percent_get
 - Clock, Power and Performance Queries, 47
- rsmi_dev_clk_range_set
 - Clock, Power and Performance Queries, 52
- rsmi_dev_compute_partition_get
 - Compute Partition Functions, 83
- rsmi_dev_compute_partition_reset
 - Compute Partition Functions, 84
- rsmi_dev_compute_partition_set
 - Compute Partition Functions, 84
- rsmi_dev_counter_create
 - Performance Counter Functions, 70
- rsmi_dev_counter_destroy
 - Performance Counter Functions, 71
- rsmi_dev_counter_group_supported
 - Performance Counter Functions, 70
- rsmi_dev_drm_render_minor_get
 - Identifier Queries, 22
- rsmi_dev_ecc_count_get
 - Error Queries, 65
- rsmi_dev_ecc_enabled_get
 - Error Queries, 66
- rsmi_dev_ecc_status_get
 - Error Queries, 66
- rsmi_dev_energy_count_get
 - Power Queries, 31
- rsmi_dev_fan_reset
 - Physical State Control, 44
- rsmi_dev_fan_rpms_get
 - Physical State Queries, 40
- rsmi_dev_fan_speed_get
 - Physical State Queries, 41
- rsmi_dev_fan_speed_max_get
 - Physical State Queries, 41
- rsmi_dev_fan_speed_set
 - Physical State Control, 44
- rsmi_dev_firmware_version_get
 - Version Queries, 64
- rsmi_dev_gpu_clk_freq_get
 - Clock, Power and Performance Queries, 50
- rsmi_dev_gpu_clk_freq_set
 - Clock, Power and Performance Control, 60
- rsmi_dev_gpu_metrics_info_get
 - Clock, Power and Performance Queries, 52
- rsmi_dev_gpu_reset
 - Clock, Power and Performance Queries, 51
- rsmi_dev_id_get
 - Identifier Queries, 16
- rsmi_dev_mem_overdrive_level_get
 - Clock, Power and Performance Queries, 50
- rsmi_dev_memory_busy_percent_get
 - Memory Queries, 37
- rsmi_dev_memory_reserved_pages_get
 - Memory Queries, 38
- rsmi_dev_memory_total_get
 - Memory Queries, 36
- rsmi_dev_memory_usage_get
 - Memory Queries, 37
- rsmi_dev_name_get
 - Identifier Queries, 17
- rsmi_dev_nps_mode_get
 - NPS Mode Functions, 86
- rsmi_dev_nps_mode_reset
 - NPS Mode Functions, 87
- rsmi_dev_nps_mode_set
 - NPS Mode Functions, 87
- rsmi_dev_od_clk_info_set
 - Clock, Power and Performance Queries, 53
- rsmi_dev_od_volt_curve_regions_get
 - Clock, Power and Performance Queries, 54
- rsmi_dev_od_volt_info_get
 - Clock, Power and Performance Queries, 51
- rsmi_dev_od_volt_info_set
 - Clock, Power and Performance Queries, 54
- rsmi_dev_overdrive_level_get
 - Clock, Power and Performance Queries, 49
- rsmi_dev_overdrive_level_set
 - Clock, Power and Performance Control, 58
- rsmi_dev_overdrive_level_set_v1
 - Clock, Power and Performance Control, 59
- rsmi_dev_pci_bandwidth_get
 - PCIe Queries, 24
- rsmi_dev_pci_bandwidth_set

- PCIe Control, [29](#)
- `rsmi_dev_pci_id_get`
 - PCIe Queries, [25](#)
- `rsmi_dev_pci_replay_counter_get`
 - PCIe Queries, [27](#)
- `rsmi_dev_pci_throughput_get`
 - PCIe Queries, [27](#)
- `RSMI_DEV_PERF_LEVEL_AUTO`
 - `rocm_smi.h`, [120](#)
- `RSMI_DEV_PERF_LEVEL_DETERMINISM`
 - `rocm_smi.h`, [121](#)
- `rsmi_dev_perf_level_get`
 - Clock, Power and Performance Queries, [48](#)
- `RSMI_DEV_PERF_LEVEL_HIGH`
 - `rocm_smi.h`, [120](#)
- `RSMI_DEV_PERF_LEVEL_LOW`
 - `rocm_smi.h`, [120](#)
- `RSMI_DEV_PERF_LEVEL_MANUAL`
 - `rocm_smi.h`, [120](#)
- `rsmi_dev_perf_level_set`
 - Clock, Power and Performance Control, [57](#)
- `rsmi_dev_perf_level_set_v1`
 - Clock, Power and Performance Control, [58](#)
- `RSMI_DEV_PERF_LEVEL_STABLE_MIN_MCLK`
 - `rocm_smi.h`, [120](#)
- `RSMI_DEV_PERF_LEVEL_STABLE_MIN_SCLK`
 - `rocm_smi.h`, [121](#)
- `RSMI_DEV_PERF_LEVEL_STABLE_PEAK`
 - `rocm_smi.h`, [120](#)
- `RSMI_DEV_PERF_LEVEL_STABLE_STD`
 - `rocm_smi.h`, [120](#)
- `rsmi_dev_perf_level_t`
 - `rocm_smi.h`, [120](#)
- `RSMI_DEV_PERF_LEVEL_UNKNOWN`
 - `rocm_smi.h`, [121](#)
- `rsmi_dev_power_ave_get`
 - Power Queries, [30](#)
- `rsmi_dev_power_cap_default_get`
 - Power Queries, [32](#)
- `rsmi_dev_power_cap_get`
 - Power Queries, [31](#)
- `rsmi_dev_power_cap_range_get`
 - Power Queries, [33](#)
- `rsmi_dev_power_cap_set`
 - Power Control, [34](#)
- `rsmi_dev_power_profile_presets_get`
 - Clock, Power and Performance Queries, [55](#)
- `rsmi_dev_power_profile_set`
 - Power Control, [34](#)
- `rsmi_dev_serial_number_get`
 - Identifier Queries, [20](#)
- `rsmi_dev_sku_get`
 - Identifier Queries, [16](#)
- `rsmi_dev_subsystem_id_get`
 - Identifier Queries, [21](#)
- `rsmi_dev_subsystem_name_get`
 - Identifier Queries, [21](#)
- `rsmi_dev_subsystem_vendor_id_get`
 - Identifier Queries, [22](#)
- `rsmi_dev_supported_func_iterator_close`
 - Supported Functions, [92](#)
- `rsmi_dev_supported_func_iterator_open`
 - Supported Functions, [90](#)
- `rsmi_dev_supported_variant_iterator_open`
 - Supported Functions, [91](#)
- `rsmi_dev_temp_metric_get`
 - Physical State Queries, [42](#)
- `rsmi_dev_unique_id_get`
 - Identifier Queries, [23](#)
- `rsmi_dev_vbios_version_get`
 - Version Queries, [63](#)
- `rsmi_dev_vendor_id_get`
 - Identifier Queries, [17](#)
- `rsmi_dev_vendor_name_get`
 - Identifier Queries, [19](#)
- `rsmi_dev_volt_metric_get`
 - Physical State Queries, [43](#)
- `rsmi_dev_vram_vendor_get`
 - Identifier Queries, [19](#)
- `rsmi_dev_xgmi_error_reset`
 - XGMI Functions, [78](#)
- `rsmi_dev_xgmi_error_status`
 - XGMI Functions, [77](#)
- `rsmi_dev_xgmi_hive_id_get`
 - XGMI Functions, [78](#)
- `rsmi_error_count_t`, [99](#)
- `rsmi_event_group_t`
 - `rocm_smi.h`, [121](#)
- `rsmi_event_handle_t`
 - `rocm_smi.h`, [119](#)
- `RSMI_EVENT_MASK_FROM_INDEX`
 - `rocm_smi.h`, [118](#)
- `rsmi_event_notification_get`
 - Event Notification Functions, [95](#)
- `rsmi_event_notification_init`
 - Event Notification Functions, [94](#)
- `rsmi_event_notification_mask_set`
 - Event Notification Functions, [94](#)
- `rsmi_event_notification_stop`
 - Event Notification Functions, [96](#)
- `rsmi_event_type_t`
 - `rocm_smi.h`, [121](#)
- `RSMI_EVT_GRP_XGMI`
 - `rocm_smi.h`, [121](#)
- `RSMI_EVT_GRP_XGMI_DATA_OUT`
 - `rocm_smi.h`, [121](#)
- `RSMI_EVT_XGMI_0_BEATS_TX`
 - `rocm_smi.h`, [122](#)
- `RSMI_EVT_XGMI_0_NOP_TX`
 - `rocm_smi.h`, [122](#)
- `RSMI_EVT_XGMI_0_REQUEST_TX`
 - `rocm_smi.h`, [122](#)
- `RSMI_EVT_XGMI_0_RESPONSE_TX`
 - `rocm_smi.h`, [122](#)
- `RSMI_EVT_XGMI_1_BEATS_TX`
 - `rocm_smi.h`, [122](#)

- RSMI_EVNT_XGMI_1_NOP_TX
roc_m_smi.h, [122](#)
- RSMI_EVNT_XGMI_1_REQUEST_TX
roc_m_smi.h, [122](#)
- RSMI_EVNT_XGMI_1_RESPONSE_TX
roc_m_smi.h, [122](#)
- RSMI_EVNT_XGMI_DATA_OUT_1
roc_m_smi.h, [122](#)
- RSMI_EVNT_XGMI_DATA_OUT_2
roc_m_smi.h, [122](#)
- RSMI_EVNT_XGMI_DATA_OUT_3
roc_m_smi.h, [122](#)
- RSMI_EVNT_XGMI_DATA_OUT_4
roc_m_smi.h, [122](#)
- RSMI_EVNT_XGMI_DATA_OUT_5
roc_m_smi.h, [122](#)
- RSMI_EVT_NOTIF_VMFAULT
roc_m_smi.h, [122](#)
- rsmi_evt_notification_data_t, [100](#)
- rsmi_evt_notification_type_t
roc_m_smi.h, [122](#)
- RSMI_FREQ_IND_INVALID
roc_m_smi.h, [127](#)
- RSMI_FREQ_IND_MAX
roc_m_smi.h, [127](#)
- RSMI_FREQ_IND_MIN
roc_m_smi.h, [127](#)
- rsmi_freq_ind_t
roc_m_smi.h, [127](#)
- rsmi_freq_volt_region_t, [100](#)
- rsmi_frequencies_t, [101](#)
current, [101](#)
frequency, [101](#)
num_supported, [101](#)
- rsmi_func_iter_next
Supported Functions, [91](#)
- rsmi_func_iter_value_get
Supported Functions, [92](#)
- RSMI_GPU_BLOCK_ATHUB
roc_m_smi.h, [126](#)
- RSMI_GPU_BLOCK_DF
roc_m_smi.h, [126](#)
- RSMI_GPU_BLOCK_FUSE
roc_m_smi.h, [126](#)
- RSMI_GPU_BLOCK_GFX
roc_m_smi.h, [126](#)
- RSMI_GPU_BLOCK_HDP
roc_m_smi.h, [126](#)
- RSMI_GPU_BLOCK_INVALID
roc_m_smi.h, [126](#)
- RSMI_GPU_BLOCK_LAST
roc_m_smi.h, [126](#)
- RSMI_GPU_BLOCK_MMHUB
roc_m_smi.h, [126](#)
- RSMI_GPU_BLOCK_MP0
roc_m_smi.h, [126](#)
- RSMI_GPU_BLOCK_MP1
roc_m_smi.h, [126](#)
- RSMI_GPU_BLOCK_PCIE_BIF
roc_m_smi.h, [126](#)
- RSMI_GPU_BLOCK_SDMA
roc_m_smi.h, [126](#)
- RSMI_GPU_BLOCK_SEM
roc_m_smi.h, [126](#)
- RSMI_GPU_BLOCK_SMN
roc_m_smi.h, [126](#)
- rsmi_gpu_block_t
roc_m_smi.h, [126](#)
- RSMI_GPU_BLOCK_UMC
roc_m_smi.h, [126](#)
- RSMI_GPU_BLOCK_XGMI_WAFL
roc_m_smi.h, [126](#)
- rsmi_gpu_metrics_t, [102](#)
- rsmi_init
Initialization and Shutdown, [13](#)
- RSMI_INIT_FLAG_ALL_GPUS
roc_m_smi.h, [120](#)
- RSMI_INIT_FLAG_RESRV_TEST1
roc_m_smi.h, [120](#)
- rsmi_init_flags_t
roc_m_smi.h, [120](#)
- RSMI_IOLINK_TYPE_NUMIOLINKTYPES
roc_m_smi.h, [128](#)
- RSMI_IOLINK_TYPE_PCIEEXPRESS
roc_m_smi.h, [128](#)
- RSMI_IOLINK_TYPE_SIZE
roc_m_smi.h, [128](#)
- RSMI_IOLINK_TYPE_UNDEFINED
roc_m_smi.h, [128](#)
- RSMI_IOLINK_TYPE_XGMI
roc_m_smi.h, [128](#)
- rsmi_is_P2P_accessible
Hardware Topology Functions, [81](#)
- RSMI_MAX_FAN_SPEED
roc_m_smi.h, [118](#)
- RSMI_MEM_PAGE_STATUS_PENDING
roc_m_smi.h, [128](#)
- RSMI_MEM_PAGE_STATUS_RESERVED
roc_m_smi.h, [128](#)
- RSMI_MEM_PAGE_STATUS_UNRESERVABLE
roc_m_smi.h, [128](#)
- RSMI_MEM_TYPE_GTT
roc_m_smi.h, [127](#)
- RSMI_MEM_TYPE_VIS_VRAM
roc_m_smi.h, [127](#)
- RSMI_MEM_TYPE_VRAM
roc_m_smi.h, [127](#)
- rsmi_memory_page_status_t
roc_m_smi.h, [127](#)
- RSMI_MEMORY_PARTITION_NPS1
roc_m_smi.h, [124](#)
- RSMI_MEMORY_PARTITION_NPS2
roc_m_smi.h, [124](#)
- RSMI_MEMORY_PARTITION_NPS4
roc_m_smi.h, [124](#)
- RSMI_MEMORY_PARTITION_NPS8

- rocm_smi.h, [124](#)
- rsmi_memory_type_t
 - rocm_smi.h, [127](#)
- rsmi_minmax_bandwidth_get
 - Hardware Topology Functions, [80](#)
- rsmi_nps_mode_type_t
 - rocm_smi.h, [123](#)
- rsmi_num_monitor_devices
 - Identifier Queries, [15](#)
- rsmi_od_vddc_point_t, [102](#)
- rsmi_od_volt_curve_t, [102](#)
 - vc_points, [102](#)
- rsmi_od_volt_freq_data_t, [103](#)
 - curr_mclk_range, [103](#)
- rsmi_pcie_bandwidth_t, [104](#)
 - lanes, [104](#)
 - transfer_rate, [104](#)
- rsmi_perf_determinism_mode_set
 - Clock, Power and Performance Queries, [49](#)
- rsmi_power_profile_preset_masks_t
 - rocm_smi.h, [126](#)
- rsmi_power_profile_status_t, [104](#)
 - available_profiles, [105](#)
 - current, [105](#)
 - num_profiles, [105](#)
- rsmi_process_info_t, [105](#)
- RSMI_PWR_PROF_PRST_BOOTUP_DEFAULT
 - rocm_smi.h, [126](#)
- RSMI_PWR_PROF_PRST_COMPUTE_MASK
 - rocm_smi.h, [126](#)
- RSMI_PWR_PROF_PRST_CUSTOM_MASK
 - rocm_smi.h, [126](#)
- RSMI_PWR_PROF_PRST_LAST
 - rocm_smi.h, [126](#)
- RSMI_PWR_PROF_PRST_POWER_SAVING_MASK
 - rocm_smi.h, [126](#)
- RSMI_PWR_PROF_PRST_VIDEO_MASK
 - rocm_smi.h, [126](#)
- RSMI_PWR_PROF_PRST_VR_MASK
 - rocm_smi.h, [126](#)
- rsmi_range_t, [106](#)
- RSMI_RAS_ERR_STATE_DISABLED
 - rocm_smi.h, [127](#)
- RSMI_RAS_ERR_STATE_ENABLED
 - rocm_smi.h, [127](#)
- RSMI_RAS_ERR_STATE_MULT_UC
 - rocm_smi.h, [127](#)
- RSMI_RAS_ERR_STATE_NONE
 - rocm_smi.h, [127](#)
- RSMI_RAS_ERR_STATE_PARITY
 - rocm_smi.h, [127](#)
- RSMI_RAS_ERR_STATE_POISON
 - rocm_smi.h, [127](#)
- RSMI_RAS_ERR_STATE_SING_C
 - rocm_smi.h, [127](#)
- rsmi_ras_err_state_t
 - rocm_smi.h, [126](#)
- rsmi_retired_page_record_t, [106](#)
- rsmi_shut_down
 - Initialization and Shutdown, [14](#)
- RSMI_STATUS_AMDGPU_RESTART_ERR
 - rocm_smi.h, [120](#)
- RSMI_STATUS_BUSY
 - rocm_smi.h, [120](#)
- RSMI_STATUS_FILE_ERROR
 - rocm_smi.h, [119](#)
- RSMI_STATUS_INIT_ERROR
 - rocm_smi.h, [119](#)
- RSMI_STATUS_INPUT_OUT_OF_BOUNDS
 - rocm_smi.h, [119](#)
- RSMI_STATUS_INSUFFICIENT_SIZE
 - rocm_smi.h, [119](#)
- RSMI_STATUS_INTERNAL_EXCEPTION
 - rocm_smi.h, [119](#)
- RSMI_STATUS_INTERRUPT
 - rocm_smi.h, [120](#)
- RSMI_STATUS_INVALID_ARGS
 - rocm_smi.h, [119](#)
- RSMI_STATUS_NO_DATA
 - rocm_smi.h, [120](#)
- RSMI_STATUS_NOT_FOUND
 - rocm_smi.h, [119](#)
- RSMI_STATUS_NOT_SUPPORTED
 - rocm_smi.h, [119](#)
- RSMI_STATUS_NOT_YET_IMPLEMENTED
 - rocm_smi.h, [119](#)
- RSMI_STATUS_OUT_OF_RESOURCES
 - rocm_smi.h, [119](#)
- RSMI_STATUS_PERMISSION
 - rocm_smi.h, [119](#)
- RSMI_STATUS_REFCOUNT_OVERFLOW
 - rocm_smi.h, [120](#)
- RSMI_STATUS_SETTING_UNAVAILABLE
 - rocm_smi.h, [120](#)
- rsmi_status_string
 - Error Queries, [68](#)
- RSMI_STATUS_SUCCESS
 - rocm_smi.h, [119](#)
- rsmi_status_t
 - rocm_smi.h, [119](#)
- RSMI_STATUS_UNEXPECTED_DATA
 - rocm_smi.h, [120](#)
- RSMI_STATUS_UNEXPECTED_SIZE
 - rocm_smi.h, [120](#)
- RSMI_STATUS_UNKNOWN_ERROR
 - rocm_smi.h, [120](#)
- RSMI_SW_COMP_DRIVER
 - rocm_smi.h, [121](#)
- rsmi_sw_component_t
 - rocm_smi.h, [121](#)
- RSMI_TEMP_CRIT_MIN
 - rocm_smi.h, [124](#)
- RSMI_TEMP_CRIT_MIN_HYST
 - rocm_smi.h, [124](#)
- RSMI_TEMP_CRITICAL
 - rocm_smi.h, [124](#)

- RSMI_TEMP_CRITICAL_HYST
 - rocm_smi.h, [124](#)
- RSMI_TEMP_CURRENT
 - rocm_smi.h, [124](#)
- RSMI_TEMP_EMERGENCY
 - rocm_smi.h, [124](#)
- RSMI_TEMP_EMERGENCY_HYST
 - rocm_smi.h, [124](#)
- RSMI_TEMP_HIGHEST
 - rocm_smi.h, [124](#)
- RSMI_TEMP_LOWEST
 - rocm_smi.h, [124](#)
- RSMI_TEMP_MAX
 - rocm_smi.h, [124](#)
- RSMI_TEMP_MAX_HYST
 - rocm_smi.h, [124](#)
- RSMI_TEMP_MIN
 - rocm_smi.h, [124](#)
- RSMI_TEMP_MIN_HYST
 - rocm_smi.h, [124](#)
- RSMI_TEMP_OFFSET
 - rocm_smi.h, [124](#)
- RSMI_TEMP_TYPE_EDGE
 - rocm_smi.h, [125](#)
- RSMI_TEMP_TYPE_HBM_0
 - rocm_smi.h, [125](#)
- RSMI_TEMP_TYPE_HBM_1
 - rocm_smi.h, [125](#)
- RSMI_TEMP_TYPE_HBM_2
 - rocm_smi.h, [125](#)
- RSMI_TEMP_TYPE_HBM_3
 - rocm_smi.h, [125](#)
- RSMI_TEMP_TYPE_INVALID
 - rocm_smi.h, [125](#)
- RSMI_TEMP_TYPE_JUNCTION
 - rocm_smi.h, [125](#)
- RSMI_TEMP_TYPE_MEMORY
 - rocm_smi.h, [125](#)
- rsmi_temperature_metric_t
 - rocm_smi.h, [124](#)
- rsmi_temperature_type_t
 - rocm_smi.h, [124](#)
- rsmi_topo_get_link_type
 - Hardware Topology Functions, [81](#)
- rsmi_topo_get_link_weight
 - Hardware Topology Functions, [80](#)
- rsmi_topo_get_numa_node_number
 - Hardware Topology Functions, [79](#)
- rsmi_topo_numa_affinity_get
 - PCIe Queries, [25](#)
- rsmi_utilization_count_get
 - Clock, Power and Performance Queries, [47](#)
- RSMI_UTILIZATION_COUNTER_FIRST
 - rocm_smi.h, [128](#)
- rsmi_utilization_counter_t, [107](#)
- RSMI_UTILIZATION_COUNTER_TYPE
 - rocm_smi.h, [128](#)
- rsmi_version_get
 - Version Queries, [62](#)
- rsmi_version_str_get
 - Version Queries, [62](#)
- rsmi_version_t, [107](#)
- RSMI_VOLT_AVERAGE
 - rocm_smi.h, [125](#)
- RSMI_VOLT_CURRENT
 - rocm_smi.h, [125](#)
- RSMI_VOLT_HIGHEST
 - rocm_smi.h, [125](#)
- RSMI_VOLT_LOWEST
 - rocm_smi.h, [125](#)
- RSMI_VOLT_MAX
 - rocm_smi.h, [125](#)
- RSMI_VOLT_MAX_CRIT
 - rocm_smi.h, [125](#)
- RSMI_VOLT_MIN
 - rocm_smi.h, [125](#)
- RSMI_VOLT_MIN_CRIT
 - rocm_smi.h, [125](#)
- RSMI_VOLT_TYPE_INVALID
 - rocm_smi.h, [125](#)
- RSMI_VOLT_TYPE_VDDGFX
 - rocm_smi.h, [125](#)
- rsmi_voltage_metric_t
 - rocm_smi.h, [125](#)
- rsmi_voltage_type_t
 - rocm_smi.h, [125](#)
- Supported Functions, [89](#)
 - rsmi_dev_supported_func_iterator_close, [92](#)
 - rsmi_dev_supported_func_iterator_open, [90](#)
 - rsmi_dev_supported_variant_iterator_open, [91](#)
 - rsmi_func_iter_next, [91](#)
 - rsmi_func_iter_value_get, [92](#)
- System Information Functions, [74](#)
 - rsmi_compute_process_gpus_get, [75](#)
 - rsmi_compute_process_info_by_pid_get, [75](#)
 - rsmi_compute_process_info_get, [74](#)
- time_enabled
 - rsmi_counter_value_t, [99](#)
- time_running
 - rsmi_counter_value_t, [99](#)
- transfer_rate
 - rsmi_pcie_bandwidth_t, [104](#)
- vc_points
 - rsmi_od_volt_curve_t, [102](#)
- Version Queries, [62](#)
 - rsmi_dev_firmware_version_get, [64](#)
 - rsmi_dev_vbios_version_get, [63](#)
 - rsmi_version_get, [62](#)
 - rsmi_version_str_get, [62](#)
- XGMI Functions, [77](#)
 - rsmi_dev_xgmi_error_reset, [78](#)
 - rsmi_dev_xgmi_error_status, [77](#)
 - rsmi_dev_xgmi_hive_id_get, [78](#)